

ELECTRONIC SUPPLEMENTARY INFORMATION

New insights on exciton binding and relaxation from high time resolution ultrafast spectroscopy of $\text{CH}_3\text{NH}_3\text{PbI}_3$ and $\text{CH}_3\text{NH}_3\text{PbBr}_3$ films

Vinay sharma^a, Sigalit Aharon^a, Itay Gdor^a, Chunfan Yang^a, Lioz Etgar^a
and Sanford Ruhman^{a*}

a. The Institute of chemistry, The Hebrew University of Jerusalem, Jerusalem 91904, Israel




Figure S1. Absorption and photoluminescence of the two samples studied. (PL) was measured on an Edinburgh Instruments FLS920 fluorimeter equipped with a film holder. Samples were excited using Fianium SC400 laser output monochromatized at 405 nm (MAPbBr₃) or at 500 nm (MAPbI₃). The emission from

the sample was collected at a right angle, through long pass filter and a monochromator to suppress the scattering from excitation source, and collected using a Hamamatsu H10720 high speed PMT.

SEM images




Figure S2. SEM images of the samples.