

Supporting Information

Efficient Light Harvesting within C153@Zr- Based MOF Embedded in a Polymeric Film: Spectral and Dynamical Characterization

Mario Gutiérrez,¹ Mar López-González,² Félix Sánchez³ and Abderrazzak

Douhal^{1*}

¹Departamento de Química Física, Facultad de Ciencias Ambientales y Bioquímica, and INAMOL, Universidad de Castilla-La Mancha, Avenida Carlos III, S.N., 45071 Toledo, Spain.

²Departamento de Química-Física de Polímeros, Instituto de Ciencia y Tecnología de Polímeros (ICTP-CSIC). C/Juan de la Cierva 3, 28006 Madrid, Spain.

³ Instituto de Química Orgánica, CSIC, Juan de la Cierva, 3, 28006 Madrid, Spain.

*Corresponding author at Universidad de Castilla-La Mancha.

Tel.: +34 925 265 717; E-mail address: abderrazzak.douhal@uclm.es

Thermal Gravimetric Analysis

Thermogravimetric and differential thermal analyses (TGA-DTA) were performed using a TA Q-500 device at a heating rate of $10\text{ }^{\circ}\text{C min}^{-1}$ under nitrogen atmosphere. Figure S3 shows the TGA of 2,6-NDC, C153, Zr-NDC and C153@Zr-NDC, while Figure S4 displayed those for PC, Zr-NDC/PC and C153@Zr-NDC/PC films. The organic linker 2,6-NDC is stable up to 377°C , while the laser dye C153 presents a lower decomposition temperature of 230°C . When the organic linker 2,6-NDC is taking part of the Zr-NDC three-dimensional network, their degradation temperature is higher, being stable up to 575°C . Moreover, Zr-NDC presents two more steps at ~ 130 and $\sim 250\text{ }^{\circ}\text{C}$, which can be assigned to the loss of solvent (THF, DMF or/and acetic acid, respectively) during heating. The TGA of C153@Zr-NDC is similar to that obtained for Zr-NDC, as the molar mass of C153 is not high enough to precisely detect its degradation temperature. Otherwise, the polymeric membrane PC lost the 85 % of its mass at 520°C while the remaining 15 % is stable up to 720°C . By incorporating Zr-NDC into the PC membrane, Zr-NDC/PC, we observed two steps, one at 460°C due to the PC decomposition and the other at 600°C due to the Zr-NDC thermal degradation. So, the incorporation of Zr-NDC into PC polymer makes the former more thermally stable (from 575 to 600°C). Finally, as well as we described for C153@Zr-NDC, when we incorporated the related composite material into the PC film, we do not observe any significant change when compared to that of Zr-NDC/PC system, as the quantity of C153 is so low that the system cannot detect its thermal degradation.




Figure S1. TGA curves for the organic linker 2,6-NDC (green), the laser dye C153 (black), Zr-NDC MOF (blue) and C153@Zr-NDC (red) composite material.




Figure S2. TGA curves for A) PC (red) and Zr-NDC/PC (black) films; and for B) C153@Zr-NDC/PC mixed matrix membrane.




Figure S3. Photograph of the physical appearance before and after UV-irradiation of (A) Zr-NDC/PC and (B) C153@Zr-NDC/PC mixed matrix membranes.




Figure S4. X-ray diffraction patterns of polycarbonate PC (black line), C153@Zr-NDC (green line), and C153@Zr-NDC/PC (red line).




Figure S5. Normalized UV-visible absorption (black lines) and emission (red lines) spectra of (A) PC (dashed line) and 2,6-NDC/PC (solid lines), and (B) a mixture of C153/2,6-NDC/PC films. For emission the excitation wavelength was 370 nm.




Figure S6. Representation of the spectral overlap between Zr-NDC/PC emission (red line) and C153@Zr-NDC/PC absorption (black line). Both spectra are normalized in a way to obtain a similar value at the maxima. For emission, the excitation wavelength was 370 nm.

Acknowledgements

This work was supported by the MINECO and JCCM through projects: Consolider Ingenio 2010 (CSD2009-0050, MULTICAT), MAT2014-52085-C2-2-P, MAT2014-57429-R, MAT2014-57646-P and PEII-2014-003-P. M. Gutiérrez thanks the MINECO for the FPI Fellowship.