

ELECTRONIC SUPPLEMENTARY INFORMATION

Functional SrF₂ Coated Separator Enabling Robust and Dendrite-Free Solid Electrolyte Interphase on Lithium Metal Anode

Xing Li^{a*}, Yang Liu^a, Yong Pan^a, Mingshan Wang^a, Junchen Chen^a, Hao Xu^a, Yun Huang^a, Woon Ming Lau^b, Aixian Shan^{b*}, Jianming Zheng^{c*}, David Mitlin^{d*}

^a *The Center of New Energy Materials and Technology, School of Materials Science and Engineering, Southwest Petroleum University, Chengdu, Sichuan 610500, China*

^b *Center for Green Innovation, School of Mathematics and Physics, University of Science and Technology Beijing, Beijing 100083, China*

^c *Research Institute (RI), NingDe Amperex Technology Limited, Ningde, Fujian 352100, China*

^d *Walker Department of Mechanical Engineering, The University of Texas at Austin, Austin, Texas 78712-1591*

Corresponding authors: lixing@swpu.edu.cn (X.L.); axshan@ustb.edu.cn (A.S.); Zhengjm@atlbattery.com (J.M.Z.); David.Mitlin@austin.utexas.edu (D.M.)




Figure S1. (a), (b) SEM images of the as-synthesized SrF₂ microspheres, taken at different magnifications (scale bars on bottom right).




Figure S1 cont. (c) XRD pattern of the as-synthesized SrF_2 microspheres.




Figure S2. SEM images for **(a)** the pristine PP separator and **(b)** the SrF_2 microspheres coated PP separator.




Figure S3. (a), (c) N₂ isotherm absorption-desorption curves of pristine and SrF₂ coated separator. (b), (d) Pore size distribution of pristine and SrF₂ coated separator.




Figure S4. (a) Expanded potential-time plots of the Li||Li cells using, (b) pristine separator, and (c), (d) SrF₂ coated separator.




Figure S5. (a) Cycling performance of Li||NCM cells with pristine and SrF₂ modified separators. Tested at a current density of 400 mA/g (2C) at an elevated temperature of 60 °C. **(a)** and **(c)** The galvanostatic charge-discharge data from which (a) was derived.




Figure S6. SEM images of the cross-sections of the post cycled Li metal anodes from Li||NCM cells (a) - (e) pristine separator, (f) - (j) SrF₂ coated separator. Samples are shown at 20th, 40th, 80th, 160th and 200th cycles, tested at 200 mA/g for 2 hrs. per cycle.




Figure S7. Top-down (a) - (b) and cross-section (c) - (d) SEM images of the formed SEI morphologies of Li metal anodes from Li||NCM cells using the (a), (c) of pristine separator and (b), (d) of SrF₂ coated separator after 200 cycles at 400 mA/g (2C) and 60 °C.




Figure S8. (a) Pristine PP separator uncycled. (b) SrF₂ coated separator, uncycled. (c) Post-cycled Li metal anode with pristine. (d) Post-cycled Li anode with SrF₂ coated. (e) Post-cycled pristine separator. (f) Post-cycled SrF₂ coated separator.




Figure S9. (a) Nyquist plots of Li||NMC coin cells, comparing pristine and SrF₂ coated separators at the 100th cycle, tested at 400 mA/g for 1 h per cycle, and 60°C. The impedance spectra were collected at charged state of 4.1 V. (b) and (c) Enlarged view of the high-frequency region as labeled by the green rectangles.





Figure S10. XPS survey spectra for the Li metal anodes under different Li deposition times at 20 mA/g (C/10) for 1h, 2h, 4h, 8h and 10h, corresponding to total 20, 40, 80, 160 and 200 mAh/g, respectively using (a) - (e) the pristine separator, and (f) - (j) the SrF₂ coated separator.



Supplementary Figure S11. XPS survey spectra for the Li metal anodes under different electrochemical cycles of 20, 40, 80, 160 and 200 at 200 mA/g (1C) using (a) – (e) the pristine separator, and (f) – (j) the SrF₂ coated separator.




Figure S12. High resolution C1s spectra for the Li metal anodes under different Li deposition times of 1 h, 2 h, 4 h, 8 h and 10 h using (a) – (e) the pristine separator, and (f) – (j) SrF₂ coated separator. High resolution C1s spectra under different cycles of 20, 40, 80, 160 and 200 for using (k) – (o) the pristine separator, and (p) – (t) the SrF₂ coated separator.




Figure S13. High resolution O1s spectra for the Li metal anodes under different Li deposition times of 1 h, 2 h, 4 h, 8 h and 10 h using (a) – (e) the pristine PP separator, and (f) – (j) the SrF₂ coated PP separator. High resolution O1s spectra under different cycles of 20, 40, 80, 160 and 200 for using (k) – (o) the pristine separator, and (p) – (t) SrF₂ coated separator.




Figure S14. (a) - (f) and (a') - (f') High – resolution XPS spectra for post-cycled Li metal anodes with pristine vs. SrF_2 modified separator. (a) - (i) Testing conditions are the same as in **Fig. 3**, 20 mA g^{-1} for 2h and 10h. (a') – (i') Tested for 40 and 160 cycles at 200 mA g^{-1} for 2 hrs. (a, a') – (b, b') and (c, c') – (d, d') F1s spectra for baseline and SrF_2 coated, (e, e') – (f, f') Sr3d spectra for SrF_2 coated.




Figure S15. High resolution Sr3d spectrum for the as-prepared SrF₂ sample.