

Supplementary Information

for

Stacking of Short DNA Induces the Gyroid Cubic-to-Inverted Hexagonal Phase Transition in Lipid–DNA Complexes

Cecília Leal*, Kai K. Ewert, Nathan F. Bouxsein, Rahau S. Shirazi, Youli Li, and Cyrus R. Safinya*

Table of Contents

Figure S1. Example of fit to SAXS data to determine %Q _{II} ^{G, sDNA}	S2
Table S1. Sequences of the sense and antisense strands of the sDNAs.....	S3
Calculation of sDNA concentrations	S4
Figure S2. Calculated sDNA melting profiles	S5
Table S2. Calculated melting temperatures of sDNAs	S7

Figure S1. Synchrotron small-angle X-ray scattering scan taken at 51.4 °C for isoelectric complexes of 5 bp DNAs with dAdT overhangs (black line). The data show coexistence of the gyroid cubic ($Q_{II}^{G, sDNA}$) and the inverted hexagonal (H_{II}^C) phase. The first peaks of the $Q_{II}^{G, sDNA}$ and the H_{II}^C phases (centered at q_{211} and q_{10} , respectively) were fit to a double Lorentzian line shape (orange line). The areas of the peaks were integrated between the limits indicated by the arrowheads and the percentage of cubic phase ($\%Q_{II}^{G, sDNA}$) was calculated as $\%Q_{II}^{G, sDNA}=A^Q(q_{211})/[A^Q(q_{211})+A^H(q_{10})]$, where $A^Q(q_{211})$ and $A^H(q_{10})$ are the areas under the peaks centered at q_{211} and q_{10} , respectively.




Table S1. Sequences of the sense (s) and antisense (as) strands of the sDNA molecules used in this study.

Sequence	Duplex name
s ACGCTAT	5bp dAdT
as AGCGTAT	
s ACGCT	5bp blunt
as AGCGT	
s ACGCTTT	5bp dTdT
as AGCGTTT	
s CTTACGCTGAGAT	11bp dAdT
as CTCAGCGTAAGAT	
s CTTACGCTGAG	11bp blunt
as CTCAGCGTAAG	
s CTTACGCTGAGTT	11 bp dTdT
as CTCAGCGTAAGTT	
s ATCACTTACGCTGAGTACTTCGAAAT	24bp dAdT
as TTCGAAGTACTCAGCGTAAGTGATAT	
s ATCACTTACGCTGAGTACTTCGAA	24bp blunt
as TTCGAAGTACTCAGCGTAAGTGAT	
s ATCACTTACGCTGAGTACTTCGAATT	24bp dTdT
as TTCGAAGTACTCAGCGTAAGTGATT	
s ACAGATGCACATATCGAGGTGGACATCACTTACGCTGAGTACTTCGAAAT	48bp dAdT
as TTCGAAGTACTCAGCGTAAGTGATGTCCACCTCGATATGTGCATCTGTAT	
s ACAGATGCACATATCGAGGTGGACATCACTTACGCTGAGTACTTCGAA	48bp blunt
as TTCGAAGTACTCAGCGTAAGTGATGTCCACCTCGATATGTGCATCTGT	
s ACAGATGCACATATCGAGGTGGACATCACTTACGCTGAGTACTTCGAATT	48bp dTdT
as TTCGAAGTACTCAGCGTAAGTGATGTCCACCTCGATATGTGCATCTGTTT	

Calculation of the concentration of sDNA strands in the CL-sDNA complex pellets


The volume of the CL-sDNA sample (V_p) was calculated by approximating the pellet as a sphere of 1 mm diameter, yielding $V_p = 0.52 \mu\text{L}$. The molar mass of the sDNA strands (M_{sDNA}) was approximated by multiplying the number of bases with the average molar mass of a base of 330 g/mol. Each sample contained 50 µg of sDNA (m_{sDNA}), corresponding to an amount of sDNA (in mol) of $n_{\text{sDNA}} = m_{\text{sDNA}}/M_{\text{sDNA}}$. The concentration of each sDNA strand in the sample pellet, C_{sDNA} , then is $C_{\text{sDNA}} = 0.5 \times n_{\text{sDNA}}/V_p$.

As an example, a sample containing blunt 5 bp sDNA with $M_{\text{sDNA}}=5\times 330=1650 \text{ g/mol}$ will have $n_{\text{sDNA}} = 50 \mu\text{g}/(1650 \text{ g/mol}) = 30.3 \text{ nmol}$ and $C_{\text{sDNA}} = 0.5 \times 30.3 \text{ nmol} / (0.52 \mu\text{L}) = 28.9 \text{ mM}$.


Figure S2. Melting profiles (percentage of unpaired strands vs. Temperature) for all sDNA used in this work estimated using the *Nupack* software package (J. N. Zadeh et al. *J. Comput. Chem.*, 2011, 32, 170–173).

5 bp (1 M NaCl)


dAdT (20.6 mM)



Blunt (28.9 mM)




dTdT (20.6 mM)




11 bp (1 M NaCl)

dAdT (11.1 mM)



Blunt (13.2 mM)



dTdT (11.1 mM)







Figure S2 ctd.

24 bp (1 M NaCl)

dAdT (5.6 mM)

Blunt (6.0 mM)

dTdT (5.6 mM)



48 bp (1 M NaCl)

dAdT (2.9 mM)

Blunt (3.0 mM)

dTdT (2.9 mM)






Table S2. sDNA dehybridization temperatures (T_m , the temperature where 50% of the bases are unpaired) for all sDNAs determined from calculated melting profiles (Figure S2).

sDNA	T_m (°C)
5 bp dAdT	59.0
5 bp blunt	64.5
5 bp dTdT	61.0
11 bp dAdT	78.0
11 bp blunt	76.5
11 bp dTdT	77.5
24 bp dAdT	> 85
24 bp blunt	> 85
24 bp dTdT	> 85
48 bp dAdT	> 85
48 bp blunt	> 85
48 bp dTdT	> 85