## **Supplementary Information**

## Improved Sensing from Methionine Capped CdTe and CdTe/ZnS Quantum Dots for the Detection of Trace Amount of Explosive Chemicals (DNT, NB and NT) in Liquid Medium

T. Pazhanivel<sup>a,b</sup>, D. Nataraj\*<sup>a,b</sup>, V. P. Devarajan<sup>a</sup>, V. Mageshwari<sup>a</sup>, K. Senthil<sup>c</sup>, D. Soundararajan<sup>d</sup>

<sup>a</sup>Thinfilms&Nanomaterials Research Laboratory, Department of Physics, Bharathiar University,

Coimbatore, India. Fax: 91-422-2422387; Tel: 0422-2428444;

\*corresponding author

E-mail: de.natraj2011@gmail.com

<sup>b</sup>DRDO-BU Centre for Life Sciences, Bharathiar University Campus, Coimbatore, India.

<sup>c</sup>School of Advanced Materials Science & Engineering, Sungkyunkwan University (Suwon Campus), Cheoncheon-dong 300, Jangan-gu, Suwon 440-746, South Korea

<sup>d</sup>Department of Physics, Yeungnam University, Gyeongsan 712-749, Korea.



**Figure S1.** Shows the HRTEM image of **(A)**Methionine and **(B)** L-Cysteine capped CdTe QDs.



**Figure S2.**Shows the FTIR spectrum for core/shell QDs capped with (A) Methionine and (B) L – Cysteine.



**Figure S3.** Shows the absorption spectrum for (a) Methionine capped; (b) L-cysteine capped CdTe/ZnS core/shell QDs.



**Figure S4.** Fluorescence quenching spectrum of (a-c) Methionine capped core/shell QDs and (d-f) L-Cysteine capped core/shell QDs in DNT, NB and NT explosives respectively. The analytes concentration varies from top to bottom are 0, 0.5  $\times 10^{-7}$ , 1  $\times 10^{-7}$ , 1.5  $\times 10^{-7}$ , 2  $\times 10^{-7}$ , 2.5  $\times 10^{-7}$ , 3  $\times 10^{-7}$ , 4  $\times 10^{-7}$ , 4.5  $\times 10^{-7}$  and 5  $\times 10^{-7}$ mol/L respectively.

|           | Concentration<br>of explosive | <b>Core/shell</b> average lifetime x 10 <sup>-9</sup> S |                                   |
|-----------|-------------------------------|---|-----------------------------------|
| Explosive |                               | Methionine capped<br>CdTe/ZnS QDs                       | L-Cysteine capped<br>CdTe/ZnS QDs |
|           | 0 M                           | 23.99   | 22.83                             |
| DNT       | 2 M                           | 16.77   | 17.21                             |
|           | 4 M                           | 9.08  | 12.18                             |
|           | 2 M                           | 17.20   | 19.36                             |
| NB        | 4 M                           | 12.13   | 15.23                             |
|           | 2 M                           | 17.93   | 20.67                             |
| NT        | 4 M                           | 16.14   | 16.42                             |
|           |                               | <b>Bare</b> average lifetime x 10 <sup>-9</sup> S       |                                   |
|           |                               | Methionine capped<br>CdTe QDs                           | L-Cysteine capped<br>CdTe QDs     |
|           | 0 M                           | 7.33  | 7.19                              |
| DNT       | 10 M                          | 5.50  | 6.70                              |
|           | 20 M                          | 5.02  | 6.18                              |
|           | 10 M                          | 5.93  | 6.88                              |
| NB        | 20 M                          | 5.71  | 6.62                              |
|           | 10 M                          | 6.50  | 7.17                              |
| NT        | 20 M                          | 5.84  | 6.82                              |

**Table T1.** Average Lifetime values for Methionine and L-Cysteine capped CdTe and CdTe/ZnS core/shell QDs with different concentrations of DNT, NB and NT analytes.

|           | Concentration of explosive | <b>Core/shell</b> Charge Transfer Rate x 10 <sup>7</sup> S <sup>-1</sup> |                                   |
|-----------|----------------------------|--|-----------------------------------|
| Explosive |                            | Methionine capped<br>CdTe/ZnS QDs  | L-Cysteine capped<br>CdTe/ZnS QDs |
|           | 2 M                        | 1.79   | 1.42                              |
| DNT       | 4 M                        | 6.83   | 3.82                              |
|           | 2 M                        | 1.64   | 0.78                              |
| NB        | 4 M                        | 4.07   | 2.18                              |
|           | 2 M                        | 1.40   | 0.45                              |
| NT        | 4 M                        | 2.02   | 1.70                              |
|           |                            | <b>bare</b> Charge Transfer Rate x 10 <sup>7</sup> S <sup>-1</sup>       |                                   |
|           |                            | Methionine capped<br>CdTe QDs  | L-Cysteine capped<br>CdTe QDs     |
|           | 10 M                       | 4.54   | 1.00                              |
| DNT       | 20 M                       | 6.26   | 2.26                              |
|           | 10 M                       | 3.22   | 0.60                              |
| NB        | 20 M                       | 3.85   | 1.17                              |
|           | 10 M                       | 1.74   | 0.02                              |
| NT        | 20 M                       | 3.47   | 0.74                              |

**Table T2.** Charge transfer rate for Methionine and L-Cysteine capped CdTe and CdTe/ZnS core/shell QDs with different concentrations of DNT, NB and NT analytes.