

CO₂ controlled flocculation of microalgae using pH responsive cellulose nanocrystals - Supplementary Information

Samuel Eyley, Dries Vandamme, Sanjaya Lama, Guy Van den Mooter

Koenraad Muylaert, Wim Thielemans

15th July 2015

Contents

S1 FTIR Spectrscopy	5
S2 TGA	6
S3 X-ray photoelectron spectroscopy	7
S3.1 Tables	7
S3.2 Wide scans	8
S3.3 Carbon 1s scans	11
S3.4 Oxygen 1s scans	13
S3.5 Sulfur 2p scans	15
S3.6 Nitrogen 1s scans	17
S3.7 Chlorine 2p scans	17
S3.8 Bromide 3d scans	19
S4 XRD	20

List of Tables

S3.1	Table of XPS data for CNCs	7
S3.2	Table of XPS data for ImBnOO-g-CNCs	8

List of Figures

S1.1	FTIR spectra of modified CNCs displayed as offset absorbance spectra	5
S2.1	TGA data for CNCs and ImBnOO-g-CNCs showing mass loss due to bound water at 125 °C.	6
S3.1	XPS wide scan of CNCs	9
S3.2	XPS wide scan of ImBnOO-g-CNCs	10
S3.3	XPS carbon 1s high resolution scan of CNCs	11
S3.4	XPS carbon 1s high resolution scan of ImBnOO-g-CNCs	12
S3.5	XPS oxygen 1s high resolution scan of CNCs	13
S3.6	XPS oxygen 1s high resolution scan of ImBnOO-g-CNCs	14
S3.7	XPS sulfur 2p high resolution scan of CNCs	15
S3.8	XPS sulfur 2p high resolution scan of ImBnOO-g-CNCs	16
S3.9	XPS nitrogen 1s high resolution scan of ImBnOO-g-CNCs	17
S3.10	XPS chlorine 2p high resolution scan of ImBnOO-g-CNCs	18
S3.11	XPS bromine 3d high resolution scan of ImBnOO-g-CNCs	19
S4.1	X-ray diffractogram of CNCs showing integral curves, and calculated crystallinity index.	20
S4.2	X-ray diffractogram of ImBnOO-g-CNCs showing integral curves, and calculated crystallinity index. . .	21

S1 FTIR Spectrscopy




Fig. S1.1 FTIR spectra of modified CNCs displayed as offset absorbance spectra

S2 TGA




Fig. S2.1 TGA data for CNCs and ImBnOO-g-CNCs showing mass loss due to bound water at 125 °C.

S3 X-ray photoelectron spectroscopy

S3.1 Tables

Table S3.1 Table of XPS data for CNCs

Orbital	Component	Binding Energy /eV	FWHM /eV	Rel. A /% ^a	At %
C 1s	C–C	285.0	1.1	7.78	4.74
	C–O	286.6	1.1	77.47	47.22
	O–C–O	288.3	1.1	14.75	8.99
	All			100	60.95
O 1s	C–O–H	532.7	1.2	60 ^b	23.39
	O–C–O	533.3	1.2	40 ^b	15.60
	All			100	38.99
S 2p ^c	$j = 3/2$	169.4	1.8	66.25	0.04
	$j = 1/2$	171.1	1.8	33.75	0.02
	All			100	0.06

^a Area relative to other components of same orbital

^b Fixed to reflect stoichiometry

^c Rel. A/separation fixed to reflect spin-orbit splitting¹

Table S3.2 Table of XPS data for ImBnOO-g-CNCs

Orbital	Component	Binding Energy /eV	FWHM /eV	Rel. A /% ^a	At %
C 1s	C–C	285.0	1.1	15.81	10.09
	C–O	286.5	1.1	69.66	44.44
	O–C–O	288.2	1.1	12.93	8.25
	O–C=O	289.6	1.1	1.60	1.02
	All			100	63.80
O 1s	C–O–H	532.6	1.3	59.89 ^b	20.98
	O–C–O	533.2	1.3	40.11 ^b	14.05
	All			100	35.03
N 1s ^c	Imidazole N 1	399.1	1.4	24.69	0.17
	Imidazole N 2	400.8	1.4	24.66	0.17
	Imidazolium N	402.0	1.4	50.65	0.34
	All			100	0.68
S 2p ^d	$j = 3/2$	168.6	1.4	66.25	0.11
	$j = 1/2$	170.2	1.4	33.75	0.05
	All			100	0.16
Cl 2p	$j = 3/2$	200.6	1.2	64.61	0.18
	$j = 1/2$	202.4	1.2	35.39	0.10
	All			100	0.28
Br 3d ^d	$j = 5/2$ Env. 1	68.1	1.0	36.84	0.02
	$j = 3/2$ Env. 1	69.1	1.0	24.54	0.01
	$j = 5/2$ Env. 2	70.7	1.0	23.18	0.01
	$j = 3/2$ Env. 2	71.7	1.0	15.44	0.01
	All			100	0.06

^a Area relative to other components of same orbital^b Fixed to reflect stoichiometry^c Imidazole separation fixed based on Nolting et al.²^d Rel. A/separation fixed to reflect spin-orbit splitting^{1,3}

S3.2 Wide scans




Fig. S3.1 XPS wide scan of CNCs




Fig. S3.2 XPS wide scan of ImBnOO-g-CNCs

S3.3 Carbon 1s scans




Fig. S3.3 XPS carbon 1s high resolution scan of CNCs




Fig. S3.4 XPS carbon 1s high resolution scan of ImBnOO-g-CNCs

S3.4 Oxygen 1s scans




Fig. S3.5 XPS oxygen 1s high resolution scan of CNCs




Fig. S3.6 XPS oxygen 1s high resolution scan of ImBnOO-g-CNCs

S3.5 Sulfur 2p scans




Fig. S3.7 XPS sulfur 2p high resolution scan of CNCs




Fig. S3.8 XPS sulfur 2p high resolution scan of ImBnOO-g-CNCs

S3.6 Nitrogen 1s scans




Fig. S3.9 XPS nitrogen 1s high resolution scan of ImBnOO-g-CNCs

S3.7 Chlorine 2p scans




Fig. S3.10 XPS chlorine 2p high resolution scan of ImBnOO-g-CNCs

S3.8 Bromide 3d scans




Fig. S3.11 XPS bromine 3d high resolution scan of ImBnOO-g-CNCs

S4 XRD




Fig. S4.1 X-ray diffractogram of CNCs showing integral curves, and calculated crystallinity index.




Fig. S4.2 X-ray diffractogram of ImBnOO-g-CNCs showing integral curves, and calculated crystallinity index.

Bibliography

- [1] *Thermo Scientific XPS Knowledge Base - Sulfur*, accessed April 2015, <http://xpssimplified.com/elements/sulfur.php>.
- [2] D. Nolting, N. Ottosson, M. Faubel, I. V. Hertel and B. Winter, *J. A*, 2008, **130**, 8150–8151.
- [3] *Thermo Scientific XPS Knowledge Base - Bromine*, accessed April 2015, <http://xpssimplified.com/elements/bromine.php>.