

Supplementary Information for

**Highly diastereoselective Friedel-Crafts reaction of indoles  
with isatin-derived N-sulfinyl ketimines towards the efficient  
synthesis of chiral tetrasubstituted  
3-indolyl-3-amino oxindoles**

Jian-Ping Chen, Wen-Wen Chen, Yi Li and Ming-Hua Xu\*

*State Key Laboratory of Drug Research, Shanghai Institute of Materia*

*Medica, Chinese Academy of Sciences, 555 Zuchongzhi Road,*

*Shanghai 201203, China*


*E-mail: [xumh@simm.ac.cn](mailto:xumh@simm.ac.cn)*

**Table of Contents**

Copies of the HPLC Chromatograms of product <b>3</b> , <b>5</b> and <b>6</b> .....	S2
Determination of the enantioselectivity of compound <b>6</b> .....	S23
Copies of $^1\text{H}$ NMR and $^{13}\text{C}$ NMR spectra .....	S25
X-ray of product <b>3o</b> .....	S46



## Copies of the HPLC Chromatograms of product 3, 5 and 6

*(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3g): 96% de*




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 10.52 min, 12.19 min (major).

**3g**



Analytical LC-MS of reference compound **3g**: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm;


Retention time: 9.78 min, 10.01 min (major).




PDA Ch1 254nm

Peak#	Ret. Time	Area	Height	Area%
1	9.780	282257	69232	7.684
2	10.014	3391081	816367	92.316
Total		3673338	885599	100.000

**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-methyl-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3h): 98% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 15.82min, 19.18min (major).




PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	15.965	4759933	303189	15.784
2	19.103	25396394	1117090	84.216
Totals		30156326	1420279	100.000




**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-methoxy-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3i): 98% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 70:30; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 13.81 min, 15.60 min (major).







**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-fluoro-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3j): 97% de**



Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 70:30; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 15.47 min, 19.32 min (major).


**3j**






Peak#	RetTime	Area	Height	Area %
1	15.474	329503	15102	1.396
2	19.326	23267034	1067237	98.604
Totals		23596537	1082339	100.000

Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15 min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 6.96 min, 7.87 min (major).




Peak#	Ret. Time	Area	Height	Area%
1	6.958	25463	2061	1.314
2	7.870	1912752	187778	98.686
Total		1938216	189839	100.000

**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-chloro-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3k): 98% de**




Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 20min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm;

Retention time: 7.94 min, 9.10 min (major).



PDA Ch1 254nm


Peak#	Ret. Time	Area	Height	Area%
1	7.866	545476	55660	7.886
2	9.068	6371965	593929	92.114
Total		6917441	649589	100.000



PDA Ch1 254nm


Peak#	Ret. Time	Area	Height	Area%
1	7.939	17136	1451	1.155
2	9.105	1466399	137547	98.845
Total		1483535	138999	100.000

**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-bromo-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3l): 94% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 13.75 min, 17.66 min (major).

**3l**



PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	13.563	1822184	109125	10.315
2	17.526	15843976	743084	89.685
Totals		17666161	852210	100.000



PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	13.754	677236	39313	2.801
2	17.661	23500965	1133623	97.199
Totals		24178201	1172936	100.000

**(R)-N-((S)-1-((4-methoxyphenyl)phenyl)methyl)-3-(1,7-dimethyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3m): 90% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 70:30; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 11.43 min, 13.67 min (major).

**3m**



PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	11.256	12484474	853845	16.305
2	13.406	64082632	3996253	83.695
Totals		76567106	4850098	100.000





PDA Ch1 254nm 4nm

Peak#	RetTime	Area	Height	Area %
1	11.437	2355446	163927	5.012
2	13.673	44641522	2802128	94.988
Totals		46996967	2966056	100.000


**(R)-N-((S)-1-((bis(4-methoxyphenyl)(phenyl)methyl)-3-(1,6-dimethyl-1*H*-indol-3-yl)-2-oxindolin-3-yl)-2-methylpropane-2-sulfonamide (3n): 93% de**





Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 11.81 min, 14.19 min (major).




**(R)-N-((S)-1-((4-methoxyphenyl)(phenyl)methyl)-3-(6-bromo-1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3o): 95% de**



Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 13.17 min, 16.98 min (major).




**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-3-(5-methoxy-1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3p): 92% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 85:15; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 16.97 min, 19.88 min (major).

**3p**



PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	16.915	6388828	320769	16.972
2	19.789	31254071	1409178	83.028
Totals		37642899	1729947	100.000




PDA Ch1 254nm 4nm

Peak#	RetTime	Area	Height	Area %
1	16.979	787902	41271	4.111
2	19.882	18375877	836458	95.889
Totals		19163779	877728	100.000

**methyl 3-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-3-(((R)-*tert*-butylsulfinyl)amino)-2-oxoindolin-3-yl)-1 -methyl-1*H*-indole-5-carboxylate (3q): 94% de**



Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 5.54 min, 6.41 min (major).




Peak Table

PDA Ch1 254nm


Peak#	Ret. Time	Area	Height	Area%
1	5.545	57750	7201	2.952
2	6.411	1898456	189616	97.048
Total		1956206	196817	100.000

**(R)-N-((R)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-3-(1,2-dimethyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3r): 90% de**



Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 85:15; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 6.19 min, 7.05 min (major).


**3r**



Peak Table

PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	6.311	5252328	535402	45.051
2	7.156	6406404	617002	54.949
Totals		11658732	1152404	100.000




PDA Ch1 254nm 4nm

Peak#	RetTime	Area	Height	Area %
1	6.199	974501	93923	4.860
2	7.051	19076611	1818451	95.140
Totals		20051112	1912374	100.000

**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-3-(1,5-dimethyl-1*H*-indol-3-yl)-5-methoxy-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3s): 96% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 11.42 min, 12.90 min (major).




PDA Ch1 254nm 4nm

Peak#	RetTime	Area	Height	Area %
1	11.170	2550579	147512	12.001
2	12.595	18702141	1015958	87.999
Totals		21252719	1163469	100.000




Peak#	RetTime	Area	Height	Area %
1	11.422	654531	31882	2.254
2	12.905	28380192	1486900	97.746
Totals		29034723	1518782	100.000


**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-methoxy-3-(5-methoxy-1-methyl-1H-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3t): 93% de**



Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 9.19 min, 10.15 min (major).




Peak#	RetTime	Area	Height	Area %
1	9.081	1352043	100821	10.508
2	9.998	11515141	849938	89.492
Totals		12867184	950759	100.000




Peak#	RetTime	Area	Height	Area %
1	9.194	904889	51055	3.692
2	10.156	23601678	1703879	96.308
Totals		24506567	1754934	100.000

Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 6.15 min, 6.60 min (major).




PDA Ch1 254nm				
Peak#	Ret. Time	Area	Height	Area%
1	6.149	68035	4825	2.977
2	6.598	2217118	224919	97.023
Total		2285153	229745	100.000

**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-chloro-3-(5-methoxy-1-methyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfinamide (3u): 97% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 11.64 min, 14.19 min (major).



PDA Ch1 254nm 4nm


Peak#	RetTime	Area	Height	Area %
1	11.616	4792701	319036	7.505
2	14.203	59068317	4003928	92.495
Totals		63861019	4322964	100.000



PDA Ch1 254nm 4nm

Peak#	RetTime	Area	Height	Area %
1	11.646	672847	39787	1.458
2	14.191	45488839	2854610	98.542
Totals		46161686	2894398	100.000


Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 5% to 100% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 9.74 min, 10.00 min (major).




PDA Ch1 254nm

Peak#	Ret. Time	Area	Height	Area%
1	9.735	39203	6494	1.304
2	10.001	2966340	617626	98.696
Total		3005544	624120	100.000

**(R)-N-((S)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-chloro-3-(1,7-dimethyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3v): 96% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 75:25; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 15.09min, 19.98 min (major).




PDA Ch1 254nm 4nm

Peak#	RetTime	Area	Height	Area %
1	15.032	2243246	112134	9.322
2	19.996	21821394	941923	90.678
Totals		24064640	1054057	100.000




Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 8.73 min, 10.00 min (major).



PDA Ch1 254nm


Peak#	Ret. Time	Area	Height	Area%
1	8.732	72064	7358	1.784
2	10.005	3967335	372744	98.216
Total		4039398	380103	100.000

**(R)-N-((R)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-5-chloro-3-(1,2-dimethyl-1*H*-indol-3-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3w): 95% de**




Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over

15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min;  
Detected by UV at 254nm; Retention time: 8.34 min, 9.80min (major).



PDA Ch1 254nm


Peak#	Ret. Time	Area	Height	Area%
1	8.301	718696	74962	19.729
2	9.764	2924229	276920	80.271
Total		3642926	351882	100.000



PDA Ch1 254nm


Peak#	Ret. Time	Area	Height	Area%
1	8.339	77544	9838	2.447
2	9.793	3091411	297287	97.553
Total		3168954	307125	100.000

**(R)-N-((S)-3-(1-benzyl-1*H*-indol-3-yl)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (3x): 98% de**




Analytical HPLC: C18 Column (4.6×150mm, 5 micron particle size), mobile phase aqueous CH<sub>3</sub>CN/H<sub>2</sub>O = 90:10; Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 15.67 min, 17.67 min (major).

**3x**




Peak#	RetTime	Area	Height	Area %
1	15.670	16707311	607348	24.691
2	17.659	50958197	1680749	75.309
Totals		67665508	2288097	100.000




Peak#	RetTime	Area	Height	Area %
1	15.676	378839	19822	1.159
2	17.669	32313286	1524471	98.841
Totals		32692125	1544293	1.159

**(R)-N-((R)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-3-(4,7-dihydro-1*H*-indol-2-yl)-2-oxoindolin-3-yl)-2-methylpropane-2-sulfonamide (5a): 84% de**




Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15 min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 7.02 min, 7.37 min (major).


**5a**




**(R)-N-((R)-1-(bis(4-methoxyphenyl)(phenyl)methyl)-2-oxo-3-(1*H*-pyrrol-2-yl)indolin-3-yl)-2-methylpropane-2-sulfonamide (5b): 77% de**




Analytical LC-MS: C18-WP Column (2.1×50mm, 3 micron particle size), mobile phase H<sub>2</sub>O/CH<sub>3</sub>CN linear gradient over 15min (the gradient of CH<sub>3</sub>CN is from 50% to 75% during 3-15min); Flow = 1.0 mL / min; Detected by UV at 254nm; Retention time: 7.87 min, 8.19 min (major).




## Determination of the enantioselectivity of compound 6



The enantiomeric excess of compound **6** were measured by chiral HPLC analysis of its *N*-Boc-*N'*-Ac-derivative **7**, *tert*-butyl (*S*)-3-acetamido-3-(1-methyl-1*H*-indol-3-yl)-2-oxoindoline-1-carboxylate. The HPLC reference compound was a mixture of related product consisting of *R* and *S* enantiomer.




96% ee. Analytical HPLC: Chiralcel OD-H column (250 mm); detected at 220 nm; hexane/i-propanol = 85/15; flow = 0.7 mL/min; Retention time: 14.87 min, 19.39 min (major).



Results


Peak No.	Peak ID	Ret Time	Height	Area	Conc.
1		14.865	657760.813	61268404.000	47.8914
2		19.965	502539.219	66663468.000	52.1086
Total			1160300.031	127931872.000	100.0000







#### Results



Peak No.	Peak ID	Ret Time	Height	Area	Conc.
1		14.865	14606.226	1389762.875	2.1413
2		19.390	477822.531	63512788.000	97.8587
<b>Total</b>			492428.757	64902550.875	100.0000



## Copies of $^1\text{H}$ NMR and $^{13}\text{C}$ NMR spectra










































































## X-ray of product 3o



CCDC 1043242. The data can be obtained free of charge from The Cambridge Crystallographic Data Centre via [www.ccdc.cam.ac.uk/data\\_request/cif](http://www.ccdc.cam.ac.uk/data_request/cif).