1	Facile Two	-step thermal and	nealing of graphite oxide in air for graphen	e with a			
2			higher C/O ratio				
3	Suyun Tian <sup>a,b</sup> , Jing Sun <sup>b</sup> , Siwei Yang <sup>b</sup> , Peng He <sup>b</sup> , Shengju Ding <sup>b</sup> , Guqiao Ding <sup>b*</sup> ,						
4			Xiaoming Xie <sup>a,b</sup>				
5	<sup>a</sup> School of Physical Science and Technology, ShanghaiTech University, Shanghai						
6			200050, P.R. China.				
7	<sup>b</sup> State Key Laboratory of Functional Materials for Informatics, Shanghai Institute of						
8	8 Microsystem and Information Technology, Chinese Academy of Science, Shanghai						
9			20050, P. R. China				
10 11 12	Table	S1. The C/O ratio	of thermal reduced graphene from the literatu	res			
		Temperature (					
	C/O ratio	°C)	Conductions (time, atmosphere, pressure, catalyst)	Ref.			
	7.7	100	6h, Ar	6			
	6.95-10.2	100-200	3h, vacuum, metal Al as catalyst	7			
	9.3	100-200	6h, Air, benzyl alcohol	6			
	4	200	1h, Ar	8			
	7.3-9.9	500-700	60s, vacuum	4			
	6.3/12.4	500/1000	5min, Ar (80%) / H <sub>2</sub> (20%)	9			
	10	650	Ar/4%H <sub>2</sub>	10			
	25	750	Ar/4%H <sub>2</sub>	10			

3.9-14.1

5.6-7.9

24-340

110

10

200-1000

1000

1050

1050

1100

\* Corresponding author. Tel: 0086-21-62511070-3409. Fax: 0086-21-62127493

Email address: gqding@mail.sim.ac.cn (G. Q. Ding)

under Ar, Ar/H2 or UHV

with different time or second thermal

 $Ar/4\%H_2$ 

30s, Ar;

treatments

30s Ar

11 10

12

13



30 Fig. S1- the self-designed container for the thermal exfoliation and reduction: (a) 1g 31 graphite oxide in the container, (b) the obtained graphene after thermal annealing 32 under 550  $^{\circ}$ C 30s in air.

- 33
- 34
- 35 36

Table S2. The yield of graphene thermal annealed in air under 250-1050 °C for 10 to
 120s. 1g graphite oxide was used as precursor.

Temp. Time	10s	30s	60s	120s
250 ℃	/	0.53	/	0.58
350 ℃	/	0.56	/	/
450 ℃	0.46	0.57	0.56	0.48
550 ℃	0.53	0.44	0.50	0.46
650 ℃	0.56	0.55	0.46	0.25
750 ℃	0.48	0.36	0.17	0.10
850 ℃	0.43	0.35	0.23	0.09

950 ℃	/	0.32	/	/
1050 °C	/	0.29	/	/



Fig. S2 - XPS C1s and O1s spectrum of graphite oxide. (a) C1s spectrum of GO, the
proportion of C-C/C=C and C-O groups is 47.9% and 52.1% respectively. (b) O1s
spectrum of GO, the proportion of C-O and C=O groups is about 97.7% and 2.3%.

BET	Temperatur e ( ℃)	Conductions (time, atmosphere, pressure, catalyst)	Ref.	
18	100	6h, Ar	S1	
758	135	24h, vacuum	S2	
500-750	130-200	8min, ambient atmosphere, volatile HCl	S3	
368-382	200-400	5h, High vacuum	S4	
62.2-403	300-600	2h, N <sub>2</sub>	S5	
960	500	1h, inert gas, metal agglomeration, many steps	S6	
600-1500	1050	30s, Ar	S7	
1200	1050	30s, Ar (pretreat for 10min in Ar)	S8	
560 702	450	10.120g oir	This	
309-703		10-1208, all	work	
Table S3. The BET data from literatures about thermal annealing				

59
----



Fig. S3 - the SEM image (a), the TEM image (b), The HRTEM image (c) of the
samples annealed under 550 °C for 30s, and XPS C1s of samples under 450-750 °C.



Fig. S4 – TGA data: (a) TGA spectra of the graphite oxide in air and in N<sub>2</sub>. (b) TGA
spectra of the graphite oxide and one step thermal annealed graphene in air.

The TGA spectra of graphite oxide and one-step annealed graphene samples are 84 shown In Fig. S4a. Heating graphite oxide in air, the spectra exhibits three stage of 85 weight losing: the first stage happens below 100 °C due to the H<sub>2</sub>O loss; The second 86 87 stage happens between 250 and 300 °C due to the transformation from oxygencontaining groups into CO and CO<sub>2</sub>; The third stage is around 550 °C due to the 88 further transformation and removal of residual functional groups. However, for 89 heating graphite oxide in N<sub>2</sub>, because of the protection of N<sub>2</sub> atmosphere, it shows a 90 slow and gradual weight loss from 400-1000 °C. These results indicate the important 91 effect of oxygen for the thermal annealing, especially when the temperature over 400 92 °C. We also did the test to compare the TGA of reduced graphene oxide and graphite 93 94 oxide in air, as shown In Fig. S4b. For the one-step thermal annealing graphene, the

95 spectra have only a weight loss around 550 °C. It doesn't have the obvious weight loss 96 before 400 °C, and the weight loss around 550 °C is due to the carbon burning in air. 97 The fast weight loss around 550 °C on the TGA curve of one-step annealed graphene 98 indicates that one cannot treat graphene in air when the temperature is higher than 550 99 °C. We can get reduced graphene from 450 to 850 °C without air protection due to the 100 released gas protection inside the box.



## 130 REFERENCES

- S1: Geng LL, Wu SJ, Zou YG, Jia MJ, Zhang WX, Yan WF, et al. Correlation
  between the microstructures of graphite oxides and their catalytic behaviors in air
  oxidation of benzyl alcohol. Journal of Colloid and Interface Science
  2014;421:71–7.
- S2: Zhang HB, Wang JW, Yan Q, Zheng WG, Chen C, Yu ZZ. Vacuum-assisted
  synthesis of graphene from thermal exfoliation and reduction of graphite oxide. J
  Mater Chem 2011;21:5392–7.
- Si Shen B, Lu DD, Zhai WT, Zheng WG. Synthesis of graphene by low-temperature
  exfoliation and reduction of graphite oxide under ambient atmosphere. J. Mater.
  Chem. C 2013;1:50-3.
- 141 S4: Lv W, Tang DM, He YB, You CH, Shi ZQ, Chen XC, et al. Low-temperature
  142 exfoliated graphenes vacuum-promoted exfoliation and electrochemical energy
  143 storage. ACS nano 2009;3:3730-6.
- 144 S5: Kim JM, Hong WG, Lee SM, Chang SJ, Jun Y, Kim BH, et al. Energy storage of
  thermally reduced graphene oxide. International Journal of Hydrogen Energy
  2014;39:3799-804.
- 147 S6: Yamada Y, Suzuki Y, Yasuda H, Uchizawa S, Hirose-Takai K, Sato Y, et al.
  148 Functionalized graphene sheets coordinating metal cations. Carbon 2014;75:81–
  149 94.
- S7: Schniepp HC, Li JL, McAllister MJ, Sai H, Herrera-Alonso M, Adamson DH, et
  al. Functionalized single graphene sheets derived from splitting graphite oxide. J.
  Phys. Chem. B 2006;110:8535-9.
- 153 S8: Xin GQ, Sun H, Scott SM, Yao TK, Lu FY, Shao DL, et al. Advanced phase
- change composite by thermally annealed defect-free graphene for thermal energy
   storage. ACS Appl. Mater. Interfaces 2014;6:15262–71.