

Supporting Information

Photoelectrochemical Water splitting with a SrTiO₃:Nb / SrTiO₃ *n*⁺-*n* Homojunction Structur

1. XRD




Figure S1. The XRD for samples deposited under 1, 10, and 20 mTorr.

2. EDX analysis




Figure S2. The map of SEM-EDX sampling for samples. Each spot represents a sampling position.

The EDS were collected on a JEOL 7600F analytical SEM with accelerating voltage of 10 kV. Spectra were quantified with Cu K emission line. The reference SrTiO₃ single crystal was reduced at 900°C for 5 hours to gain high conductivity and get rid of charging. The Sr/Ti ratio was calculated by the following equation:

$$\text{Sr/Ti ratio} = \frac{\text{TF (Sr/Ti)} - \text{Ref(Sr/Ti)}}{\text{Ref(Sr/Ti)}} \times 100\%$$

TF(Sr/Ti) represents the Sr/Ti ratio of the deposited thin film, and the Ref(Sr/Ti) represents the Sr/Ti ratio of the reference SrTiO₃ single crystal.

3. Angle Resolved XPS




Figure S3. The experimental and fitted Angle-resolved XPS spectra of Nb and Ti obtained under $\theta = 0$, 30, and 80 degrees.

AR-XPS was performed in a standard ultra-high vacuum (UHV) chamber, equipped with a hemispherical electron energy analyzer and an Al/Mg twin anode X-ray source. The XPS spectra were obtained using unmonochromatized Mg K_{α} (1253.6 eV) radiation. All atom-specific core level spectra were taken at analyzer pass energy of 50 eV, with a step size of 0.05 eV, and dwell time of 0.1. Each region was signal averaged for 30 scans. Analysis of the XPS spectra was performed using XPSPEAK version 4.1. The Ti 2p peak at 458.4 eV of SrTiO₃ was used to calibrate the energy scale to which all the measured binding energies were adjusted. A Shirley background was applied to the spectra which were then fit with an appropriate number of peaks. The fits were allowed to optimize without constraints as long as a reasonable FWHM (below 3 eV) and goodness of fit were obtained. In cases where a FWHM greater than 3 eV occurred, widths and/or known peak separations were fixed to one another, until an acceptable fit was achieved. The atomic sensitivity factors of 0.63 (O), 1.1 (Ti), 1.05 (Sr), and 2.4 (Nb) were used to correct for differences in photoemission cross sections to obtain relative surface atomic compositions. AR-XPS was performed at different tilting angles along the manipulator.

4. Mott-Schottky analysis




Figure S4. The equivalent circuit used to model the electrochemical impedance of the cell. Impedance data for P20-T1, P20-T2, and P20-T3 in the range of -0.33 to 1.36 V_{RHE} . Nyquist plot of the experimental and fitted data for P20-T1, P20-T2, and P20-T3 at 1.26 V_{RHE} . The fitted data was based on the equivalent circuit under frequency from 10^1 to 10^3 Hz.

The impedance of the electrochemical cell (Z) was measured under dark conditions at a series of electrode potentials, in the frequency (f) range 10^1 to 10^3 Hz. To extract the space-charge region capacitance from the experimental impedance, the electrochemical cell was modeled by the equivalent circuit shown in Figure S4. The two current components flow together through the electrolyte solution and the electrical

contact to the working electrode, which were represented by a series resistance R_0 . The current passing through the cell contributes in parallel to the faradic process that is represented by the charge transfer resistance R_1 and nonfaradic interface charging that is represented by C_{sc} , the capacitance per unit area of the aqueous interface. The capacitance C includes the space-charge region capacitance (C_{sc}) and the double-layer capacitance (C_{dl}) in series, $1/C = 1/C_{sc} + 1/C_{dl}$. The experimental data shown in Figure 5a is then fit using the EIS Spectrum Analyzer (ZVIEW), software for analysis of impedance spectrum.

5. Electrical conductivity analysis




Figure S5. Device geometry for measuring the electrical conductivity of a STO/Nb:STO sample.

The conductivity of each sample is measured using an electrical probe station (Signatone). Ohmic contacts to the hematite film are established by depositing a film of 5 nm titanium and 50 nm gold over the sample, through a shadow mask that contains an array of circular holes (1.25 mm in diameter). Electrical resistance between two nearest neighbor contacts is thus given by a standard two-probe I-CV measurement. Multiple contact pairs are randomly selected and tested to give the mean resistance. Resistivity and conductivity for each sample are then calculated from the electrical flow channel geometry. For an *n*-type semiconductor, the free electron density can be roughly estimated by the following equation, $n_e \approx \frac{1}{e\mu_e\rho}$, where μ_e is electron mobility, e the elementary charge, and ρ the resistivity.

6. IPCE analysis





Figure S6. IPCE as a function of excitation wavelength potential, for P01-T2, P10-T2, P01-T3, P10-T3. The horizontal white lines indicate the thermodynamic potential for oxygen evolution (1.23 V_{RHE}).

7. Elemental Analysis of the PLD target



Testbourne Ltd
Products for Industry, Research & Development

Unit 14, The Parkway, Sunningdale, Berkshire, RG11 3JF, UK
 Tel: +44 (0)1357 537500
 Fax: +44 (0)1357 537505
 Email: info@testbourne.com

Certificate of Analysis

Product Description:
 Part No.: S7-9013-D3
 Material: Strontium Titanate SrTiO3
 Form: 50.8mm dia x 6.35mm thick target

Our Sales Ref: SCR010324
 Customer PO No.: 1023766
 Customer Name: Stony Brook University (SUNY)

Purity: 99.95%

Batch Number: Y30825-18

Customer Reference

Analysis method: ICP-AES
 Contaminants reported as: ppm

Reported	Reported	Reported	Reported
Al 16	Eu	Nb	Si 120
Ag	Fe 50	Nd	Sr
Au	Ga	Ni	Ta
As	Ge	Os	Te
B	Gd	P	Ti
Be	Hf	Pb	Tl
Ba	Hg	Pd	Tm
Br	Ho	Pr	Tb
Bi	I	Pt	Th
Ca 120	Ir	Rb	U
Cl	In	Re	V
Cr	K	Ru	Y
Co	La 13	Rh	Yb
Cu	Li	S	W
Cd	Lu	Sc	Zn
Cs	Mg 20	Se	Zr
Ce	Mn	Sb	
Dy	Mo	Sm	C
Er	Na 15	Sn	N
			O
			F
			H

Composition


wt% Reported	Reported

01/09/2016
Date:

G Richards
Completed By:

G. Stromdale
Approved:

NAGQF011



Form 11/CG

Figure S7. Elemental analysis provided by vender of the STO target.