

Supporting Information

Facile Synthesis of New *N*-Sulfonamidyl-4-thiazolidinone Derivatives and Biological Evaluation

Dnyaneshwar D. Subhedar,^a Mubarak H. Shaikh,^a Firoz A. Kalam Khan,^b Jaiprakash N. Sangshetti,^b Vijay M. Khedkar,^{c,d} Bapurao B. Shingate*^a

^a*Department of Chemistry, Dr. Babasaheb Ambedkar Marathwada University, Aurangabad, 431 004, India*

^b*Department of Pharmaceutical Chemistry, Y. B. Chavan College of Pharmacy, Aurangabad, 431 001, India*

^c*Combichem-Bioresource Centre, National Chemical Laboratory, Pune 411 008, India*


^d*School of Health Sciences, University of KwaZulu Natal, Westville Campus, Durban 4000, South Africa*

*E-mail: * bapushingate@gmail.com (B. B. Shingate)*

**Corresponding author. Tel.: (91)-240-2403311-12; Fax: (91)-240-2403113*

Experimental procedure for 4-methylbenzenesulfonohydrazide:

To the stirred solution of 4-methylbenzene-1-sulfonyl chloride (1 mmol) in THF (20 mL), hydrazine hydrate (1.5 mmol) was added dropwise at 0 °C temperature. The progress of the reaction was monitored by Thin Layer Chromatography using *n*-hexane:ethyl acetate (8:2) solvent system. After completion of reaction, mixture was slowly poured into 100 mL of ice water. A solid was formed thereafter. The precipitate was separated by filtration and washed successively with water and crystallized in ethanol to give desired product.



^aReagents and conditions: (a) hydrazine, 0 °C, THF.

Scheme S1: Synthesis of 4-methylbenzenesulfonohydrazide.

Table S1. Optimization of catalyst concentration:

Entries	Mol %	Solvent	Time (hr)	Temp (°C)	Yield ^a (%)
1	5	Solvent free	4	80	68
2	10	Solvent free	2.5	80	79
3	15	Solvent free	1.5	80	83
4	20	Solvent free	1	80	90
5	25	Solvent free	1	80	90

Reaction conditions: **1a** (1 mmol), **2** (1 mmol), **3** (1 mmol) at 80 °C for 1 hr. ^aIsolated yield.

Table S2. Recycling of the dried IL in the synthesis of 4-methyl-*N*-(4-oxo-2-phenylthiazolidin-3-yl)benzenesulfonamide.^a

Entry	Run	Time (hr)	Yield (%) ^b
1	I	1	90
2	II	1	90
3	III	1	87
4	IV	1	86

^aReaction conditions: **1a** (1 mmol), **2** (1 mmol), **3** (1 mmol) and 20% [HDBU][HSO₄] at 80 °C. ^bIsolated yield.

Table S3. Recycling of the non-dried IL in the synthesis of 4-methyl-*N*-(4-oxo-2-phenylthiazolidin-3-yl)benzenesulfonamide.^a

Entry	Run	Time (hr)	Yield (%) ^b
1	I	1	70
2	II	1	64
3	III	1	58
4	IV	1	52

^aReaction conditions: **1a** (1 mmol), **2** (1 mmol), **3** (1 mmol) and 20% [HDBU][HSO₄] at 80 °C. ^bIsolated yield.





Figure S1. Structure of 4-methyl-*N*-(4-oxo-2-phenylthiazolidin-3-yl)benzenesulfonamide derivatives.

Table S4. Results of the per-residue interaction analysis for the 4-thiazolidinone derivatives.


Com p. ID	Docking score	Binding energy	Per-residue interaction energy analysis		
			van der Waals (kcal/mol)	Electrostatic (kcal/mol)	π - π stacking
4d	-6.98	-43.42	Heme(-3.85), Val461(-2.93), Met460(-1.61), Thr459(-1.01), Cys422(-1.06), Val359(-1.35), Me358(-1.55), Leu356(-3.53), Thr295(-1.20), Ala291(-2.35), Phe290(-2.86), Ala288(-1.21), Ala287(-1.15), Met284(-1.13), Leu208(-1.22), Leu127(-1.32), Tyr116(-3.49), Phe110(-2.04), Met106(-2.15) and Tyr103(-4.70)	Heme(-16.96)	Phe110
4e	-7.04	-46.21	Heme(-2.24), Val461(-1.82), Met460(-2.01), Cys422(-1.72), Val359(-1.18), Met358(-1.11), Leu356(-2.23), Thr295(-1.06), Ala291(-2.38), Phe290(-2.37), Ala288(-1.72), Ala287(-1.29), Met284(-1.17), Leu208(-1.32), Leu130(-0.93), Leu127(-1.57), Phe110(-1.51), Met106(-1.55) and Tyr103(-1.94)	Heme(-21.78)	Tyr103
4g	-6.84	-41.49	Heme(-2.81), Val461(-1.30), Met460(-1.613), Cys422(-1.42), Val 359(-2.14), Met358(-1.17), Leu356(-1.07), Thr295(-1.41), Ala291(-2.48), Phe290(-1.18), Ala288(-1.35), Ala287(-1.48), Met284(-1.05), Leu208(-1.67), Leu130(-0.81), Leu127(-1.09), Tyr116(-2.73), Phe110(-	Heme(12.57), Tyr116(-1.19)	Tyr116

			1.55), Met106(-1.40) and Tyr103(-3.61)		
4h	-7.06	-48.81	Heme(-3.46), Val461(-2.12), Met460(-2.02), Cys422(-1.89), Val359(-1.08), Met358(-1.12), Leu356(-1.78), Ala291(-2.01), Phe290(-1.68), Ala288(-1.76), Met284(-1.20), Leu130(-0.95), Leu127(-1.55), Tyr116(-1.68), Phe110(-1.73), Met106(-1.33) and Tyr103(-1.78)	Heme(-23.30)	Tyr103
4k	-7.02	-45.81	Heme(-2.67), Val461(-1.80), Met460(-2.00), Cys422(-1.77), Val359(-1.02), Met358(-1.01), Leu356(-2.79), Thr295(-1.33), Ala291(-2.40), Phe290(-1.46), Ala288(-1.79), Met284(-1.24), Leu208(-1.00), Leu130(-0.89), Leu127(-1.62), Tyr116(-4.63), Phe110(-1.31), Met106(-1.40) and Tyr103(-1.11)	Heme(-18.78)	Tyr103 and Tyr116


4a. FT-IR




4a. HRMS




4a. ¹H NMR, 400 MHz, DMSO-d₆




4a. ¹³C NMR, 100 MHz, DMSO-d₆




4b. FT-IR




4b. ¹H NMR, 400 MHz, DMSO-d₆




4b. ^{13}C NMR, 100 MHz, DMSO-d_6




4c. FT-IR




4c. LC-MS




4c. ^1H NMR, 400 MHz, DMSO-d_6




4c. ^{13}C NMR, 100 MHz, DMSO-d_6




4d. FT-IR




4d. LC-MS





4d. ¹H NMR, 400 MHz, DMSO-d₆




4d. ¹³C NMR, 100 MHz, DMSO-d₆




4e. FT-IR




4e. HRMS




4e. ¹H NMR, 400 MHz, DMSO-d₆




4e. ¹³C NMR, 100 MHz, DMSO-d₆




4f. FT-IR




4f. HRMS




4f. ^1H NMR, 400 MHz, DMSO-d_6




4f. ^{13}C NMR, 100 MHz, DMSO-d_6




4g. FT-IR




4g. LC-MS




4g. ¹H NMR, 400 MHz, DMSO-d₆




4g. ¹³C NMR, 100 MHz, DMSO-d₆




4h. FT-IR




4h. LC-MS




4h. ¹H NMR, 400 MHz, DMSO-d₆




4h. ¹³C NMR, 100 MHz, DMSO-d₆




4i. FT-IR




4i. HRMS




4i. ¹H NMR, 400 MHz, DMSO-d₆




4i. ¹³C NMR, 100 MHz, DMSO-d₆




4j. FT-IR




4j. ¹H NMR, 400 MHz, DMSO-d₆




4j. ¹³C NMR, 100 MHz, DMSO-d₆




4k. FT-IR




4k. LC-MS




4k. ¹H NMR, 400 MHz, DMSO-d₆




4k. ¹³C NMR, 100 MHz, DMSO-d₆




41. FT-IR




4l. ¹H NMR, 400 MHz, DMSO-d₆




4l. ¹³C NMR, 100 MHz, DMSO-d₆




4m. FT-IR



4m. LC-MS



4m. ¹H NMR, 400 MHz, DMSO-d₆



4m. ¹³C NMR, 100 MHz, DMSO-d₆

