

Supporting Information

Improvement of D- π -A organic dye-based dye-sensitized solar cell performance by simple triphenylamine donor substitutions on the π -linker of the dye

T. Sudyoadsuk,^a A. Thangthong,^a N. Prachumrak,^a P. Nalaoh,^a S. Jungsuttiwong,^b R. Daengngern,^c S. Namuangruk,^c P. Pattanasattaya^a and V. Promarak^{a*}

^a Department of Material Science and Engineering, School of Molecular Science and Engineering, Vidyasirimedhi Institute of Science and Technology, Wangchan, Rayong 21210, Thailand


^b Department of Chemistry, Faculty of Science, Ubon Ratchathani University, Ubon Ratchathani 34190, Thailand

^c NANOTEC, National Science and Technology Development Agency, Pathum Thani 12120, Thailand

*e-mail: vinich.p@vistec.ac.th


1. Quantum chemical calculation results


Table S1. The optimized geometry parameters, dihedral angles (in degree), of the dyes computed at B3LYP/6-31G(d,p) level.



Dye	Dihedral angle ($^{\circ}$) / intergroup			
	$\pi 1-\pi 2$	$\pi 2-\pi 3$	$\pi 3-\pi 4$	$\pi 3-A$
T1	-24.30	10.75	-4.91	0.27
T2	-24.30	16.01	-28.05	3.03
T3	-24.35	37.82	-29.94	3.69
T4	-26.81	55.37	-30.71	3.37

Note: $\pi 1$ = Triphenylamine, $\pi 2-\pi 4$ = Thiophenes, and A = Cyanoacrylic acid








Figure S1. HOMO and LUMO of the dyes calculated by B3LYP/6-31G(d,p) level.

Table S2. Excitation energy (E_{ex}), oscillator strength (f) and transition composition of the dyes calculated by TD-CAM-B3LYP/6-31G(d,p) in CH_2Cl_2 solvent.

Dyes	Transition	E_{ex} , eV (nm)	f	Composition $\text{H}=\text{HOMO}$, $\text{L}=\text{LUMO}$, ...
T1	$S_0 \rightarrow S_1$	2.56 (485)	2.0919	$0.53 (\text{H} \rightarrow \text{L}) + 0.40 (\text{H-1} \rightarrow \text{L})$
	$S_0 \rightarrow S_3$	3.79 (327)	0.2045	$0.40 (\text{H} \rightarrow \text{L}) + 0.26 (\text{H-1} \rightarrow \text{L+1})$
	$S_0 \rightarrow S_4$	4.10 (302)	0.3119	$0.38 (\text{H-1} \rightarrow \text{L+1}) + 0.33 (\text{H} \rightarrow \text{L+1})$
T2	$S_0 \rightarrow S_1$	2.62 (473)	1.8779	$0.53 (\text{H} \rightarrow \text{L}) + 0.36 (\text{H-2} \rightarrow \text{L})$
	$S_0 \rightarrow S_2$	3.23 (384)	0.1609	$0.64 (\text{H-1} \rightarrow \text{L})$
	$S_0 \rightarrow S_3$	3.47 (357)	0.1672	$0.46 (\text{H} \rightarrow \text{L+1}) + 0.36 (\text{H-2} \rightarrow \text{L})$
	$S_0 \rightarrow S_5$	3.97 (312)	0.6677	$0.35 (\text{H} \rightarrow \text{L+2}) + 0.34 (\text{H-1} \rightarrow \text{L+1})$
T3	$S_0 \rightarrow S_1$	2.62 (474)	1.3284	$0.55 (\text{H} \rightarrow \text{L}) + 0.33 (\text{H-3} \rightarrow \text{L})$
	$S_0 \rightarrow S_3$	3.41 (364)	0.5260	$0.57 (\text{H-2} \rightarrow \text{L}) + 0.28 (\text{H-3} \rightarrow \text{L})$
	$S_0 \rightarrow S_4$	3.49 (355)	0.1797	$0.43 (\text{H} \rightarrow \text{L+1}) + 0.34 (\text{H-3} \rightarrow \text{L})$
	$S_0 \rightarrow S_5$	3.76 (330)	0.3260	$0.35 (\text{H} \rightarrow \text{L}) + 0.32 (\text{H} \rightarrow \text{L+1})$
	$S_0 \rightarrow S_6$	3.96 (313)	1.1369	$0.36 (\text{H} \rightarrow \text{L+2})$
T4	$S_0 \rightarrow S_1$	2.75 (451)	1.1432	$0.51 (\text{H} \rightarrow \text{L}) + 0.37 (\text{H-4} \rightarrow \text{L})$
	$S_0 \rightarrow S_3$	3.40 (364)	0.2165	$0.54 (\text{H-1} \rightarrow \text{L}) + 0.26 (\text{H-2} \rightarrow \text{L})$
	$S_0 \rightarrow S_4$	3.50 (354)	0.4442	$0.40 (\text{H} \rightarrow \text{L+1}) + 0.31 (\text{H-4} \rightarrow \text{L})$
	$S_0 \rightarrow S_5$	3.57 (348)	0.4432	$0.34 (\text{H-2} \rightarrow \text{L}) + 0.33 (\text{H-3} \rightarrow \text{L})$
	$S_0 \rightarrow S_6$	3.77 (329)	0.3166	$0.34 (\text{H} \rightarrow \text{L}) + 0.31 (\text{H} \rightarrow \text{L+1})$
	$S_0 \rightarrow S_7$	3.96 (313)	1.2051	$0.029 (\text{H-2} \rightarrow \text{L+1}) + 0.26 (\text{H} \rightarrow \text{L+2})$
	$S_0 \rightarrow S_8$	4.02 (309)	0.1792	$0.32 (\text{H-3} \rightarrow \text{L+1}) + 0.24 (\text{H} \rightarrow \text{L+3})$

2. Fluorescence property




Figure S2. Photoluminescence spectra of dyes **T1-4** in CH_2Cl_2 solution.

3. IMVS/IMPS plots




Figure S3 IMPS Nyquist plots of DSSCs based on dyes **T1-T4** at different light intensities





Figure S4 IMVS Nyquist plots of DSSCs based on dyes **T1-T4** at different light intensities


4. NMR and APCI-Q-TOF/MALDI-TOF spectra

Compound 3



TN07-XX_2Br



TN07-XX_2Br



TN07-XX_2Br 4 1 "C:\VISTEC NMR Data\VP\vptn"



Q-ToF MS Report | Frontier Research Center@VISTEC

Analysis Info


Analysis Name D:\Data\VISTEC Data QTOF\Winch\A-monrat\TN2Br000001.d
 Method APCI_DirectProbe.m
 Sample Name TN2Br m/z = 433.7927
 Comment

Acquisition Date 10/14/2016 10:38:33 AM



Operator VISTEC_Scientist
 Instrument compact 8255754.20068

Acquisition Parameter

Source Type	APCI	Ion Polarity	Negative	Set Nebulizer	2.0 Bar
Focus	Not active	Set Capillary	4000 V	Set Dry Heater	220 °C
Scan Begin	200 m/z	Set End Plate Offset	-500 V	Set Dry Gas	5.0 l/min
Scan End	600 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	2000 nA	Set APCI Heater	450 °C



#	m/z	I
1	431.7758	23568
2	432.7771	4037
3	433.7736	46281
4	434.7762	8499
5	435.7715	28678
6	436.7746	4296
7	437.7681	3235



Handwritten notes:


Sample: TN2Br000001.d

Instrument: Compact

Date: 10/14/2016

Compound 4

TN07-21_3Br in DMSO




Current Data Parameters
NAME TN07-XX_3Br
EXPNO 1
PROCNO 1

F2 - Acquisition Parameters
Date 20160217
Time 21.31 h
INSTRUM spect
PROBHD Z115435_0005 (bruker)
PULPROG zg30
TD 65536
SOLVENT DMSO
NS 8
DS 2
SWH 12019.230 Hz
FIDRES 0.366798 Hz
AQ 2.7262976 sec
RG 95.06
DW 4.600 usec
DE 40.00 usec
TE 303.2 K
D1 1.0000000 sec
TD0 1
SF01 600.1337058 MHz
NUC1 1H
P1 8.50 usec
PLW1 20.0000000 W

F2 - Processing parameters
SI 65536
SF 600.1300000 MHz
WDW EM
SSB 0
LB 0.30 Hz
GB 0
PC 1.00

TN07-XX_3Br_DMSO



Current Data Parameters
NAME TN07-XX_3Br_DMSO
EXPNO 8
PROCNO 1

F2 - Acquisition Parameters
Date 20161012
Time 0.50 h
INSTRUM spect
PROBHD Z115435_0005 (bruker)
PULPROG zgpp30
TD 65536
SOLVENT DMSO
NS 2048
DS 2
SWH 36231.883 Hz
FIDRES 1.105709 Hz
AQ 0.9043968 sec
RG 191.96
DW 13.800 usec
DE 18.00 usec
TE 303.1 K
D1 2.0000000 sec
D11 0.03000000 sec
TD0 1
SF01 150.9178988 MHz
NUC1 13C
P1 10.50 usec
PLW1 26.00000000 W
SF02 600.1324405 MHz
NUC2 1H
GPPBG [2] waltz16
PCPD2 70.00 usec
PLW2 20.00000000 W
PLW12 0.49388000 W
PLW13 0.24842000 W

F2 - Processing parameters
SI 32768
SF 150.9028085 MHz
WDW EM
SSB 0
LB 1.00 Hz
GB 0
PC 1.40

Q-ToF MS Report | Frontier Research Center@VISTEC

Analysis Info

Analysis Name D:\Data\VISTEC Data QTOF\Vinich\A-monrat\TN3Br 000001.d
 Method APCI_DirectProbe.m
 Sample Name TN3Br m/z = 511.7032
 Comment


Acquisition Date 10/14/2016 10:49:21 AM

Operator VISTEC_Scientist



Instrument compact 8255754.20068

Acquisition Parameter


Source Type	APCI	Ion Polarity	Negative	Set Nebulizer	2.0 Bar
Focus	Not active	Set Capillary	4000 V	Set Dry Heater	220 °C
Scan Begin	300 m/z	Set End Plate Offset	-500 V	Set Dry Gas	5.0 l/min
Scan End	700 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	2000 nA	Set APCI Heater	450 °C



#	m/z	I
1	509.6915	29055
2	510.6926	5245
3	511.6903	89229
4	512.6923	14421
5	513.6880	98559
6	514.6902	16060
7	515.6852	40652
8	516.6891	6362
9	517.6807	4310



Compound 5



TN07-XX_4Br in DMSO




Current Data Parameters
NAME TN07-XX_4Br
EXNO 25
PROCNO 1

F2 - Acquisition Parameters
Date 20160217
Time 16.34 h
INSTRUM spect
PROBID Z115435.00001
PULPROG cosygrpprf
TD 2048
DW 100.00 usec
DE 40.00 usec
TE 303.1 K
D0 0.0000300 sec
D1 1.920000 sec
D11 0.0300000 sec
D12 0.0000200 sec
D13 0.0000400 sec
D14 0.0000100 sec
INO 0.00016000 sec
TDav 1
SF01 600.1338329 MHz
NUC1 1H
P0 8.50 usec
P1 8.50 usec
P17 250.00 usec
PLW1 20.0000000 W
PLW10 2.31200004 W
GPNAME[1] SMM510.100
GPZ1 1.00 %
P16 1000.00 usec

F1 - Acquisition parameters
TD 128
SF01 600.1338 MHz
FIDRES 93.00595 Hz
SW 9.918 ppm
PwNode QF

F2 - Processing parameters
SI 1024
SF 600.1300000 MHz
WDW QSINE
SSB 0
LB 0 Hz
GB 0
FC 1.40

F1 - Processing parameters
SI 1024
NC2 1
SF02 600.1300000 MHz
WDW QSINE
SSB 0
LB 0 Hz
GB 0



TN07-XX_4Br in DMSO




Current Data Parameters
NAME TN07-XX_4Br
EXNO 27
PROCNO 1

F2 - Acquisition Parameters
Date 20160217
Time 17.17 h
INSTRUM spect
PROBID Z115435.00001
PULPROG hmbcp1lpndqf
TD 2048
DWL 0
NS 8
DS 5952.381 Hz
FIDRES 5.812872 Hz
AQ 0.172000 sec
D0 1.92 sec
DW 84.000 usec
DE 40.00 usec
TE 303.1 K
CMST2 145.0000000
CMST3 100.0000000
D0 0.0000300 sec
D1 1.9590405 sec
D2 0.1960000 sec
D3 0.0500000 sec
D16 0.0020000 sec
INO 0.00001510 sec
TDav 1
SF01 600.1338329 MHz
NUC1 1H
P0 8.50 usec
P1 17.00 usec
P17 20.0000000 W
SFO2 150.0178988 MHz
NUC2 13C
P1 18.00 usec
PLW1 26.0000000 W
GPNAME[1] SMM510.100
GPZ1 1.00 %
GPNAME[2] SMM510.100
GPZ2 30.00 %
GPNAME[3] SMM510.100
GPZ3 40.10 %
P16 1000.00 usec

F1 - Acquisition parameters
TD 2048
SF01 150.9179 MHz
FIDRES 517.384094 Hz
SW 219.480 ppm
PwNode QF

F2 - Processing parameters
SI 1024
NC2 1
SF 600.1300000 MHz
WDW SINR
SSB 0
LB 0 Hz
GB 0

F1 - Processing parameters
SI 1024
NC2 QF
SF 150.9039000 MHz
WDW SINR
SSB 0
LB 0 Hz
GB 0





Q-ToF MS Report | Frontier Research Center@VISTEC

Analysis Info


Analysis Name D:\Data\VISTEC Data QTOF\Vinich\A-monrat\TN4 Br 000001.d
Method APCI_DirectProbe.m
Sample Name TN4 Br m/z = 591.6117
Comment

Acquisition Date 10/14/2016 12:56:55 PM



Operator VISTEC_Scientist
Instrument compact 8255754.20068

Acquisition Parameter


Source Type	APCI	Ion Polarity	Negative	Set Nebulizer	2.0 Bar
Focus	Not active	Set Capillary	4000 V	Set Dry Heater	220 °C
Scan Begin	300 m/z	Set End Plate Offset	-500 V	Set Dry Gas	5.0 l/min
Scan End	800 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	2000 nA	Set APCI Heater	450 °C



#	m/z	I
1	305.1848	517
2	306.1854	202
3	341.2057	226
4	361.2142	281
5	430.7775	231
6	432.7770	181
7	509.7075	132
8	510.7030	146
9	511.7078	127
10	512.6990	120
11	513.7160	171
12	515.4973	104
13	526.6998	141
14	528.7066	109
15	551.9753	115
16	587.6295	3750
17	588.6390	804
18	589.6289	14421
19	590.6311	2584
20	591.6261	22287
21	592.6277	3441
22	593.6238	16599
23	594.6266	3090
24	595.6217	5381
25	596.6228	805
26	597.6134	518
27	607.6285	142
28	609.6340	159
29	640.2624	109
30	669.5304	181




Compound 7



Current Data Parameters
NAME TN06-11
EXPNO 1
PROCNO 1

F2 - Acquisition Parameters
Date 20160120
Time 13.04 h
INSTRUM spect
PROBHD Z115435_0005 (
PULPROG zg30
TD 65536
SOLVENT CDCl₃
NS 16
DS 2
SWH 12019.230 Hz
FIDRES 0.183399 Hz
AQ 2.7262976 sec
RG 191.96
DW 41.600 usec
DE 4.000 usec
TE 303.0 K
D1 1.0000000 sec
TD0 1
SF01 600.1337058 MHz
NUC1 1H
P1 12.50 usec
PLW1 20.0000000 W

F2 - Processing parameters
SI 65536
SF 600.1300199 MHz
WDW EM
SSB 0
LB 0.30 Hz
GB 0
PC 1.00



BRUKER

Current Data Parameters
NAME 20160120
EXPNO 1
PROCNO 1

F2 - Acquisition Parameters
Date 20160120
Time 21.18 h
INSTRUM spect
PROBHD Z115435_0005 (
PULPROG zgpg30
TD 65536
SOLVENT CDCl₃
NS 1032
DS 2
SWH 36231.883 Hz
FIDRES 0.552855 Hz
AQ 0.9043968 sec
RG 191.96
DW 13.800 usec
DE 18.00 usec
TE 303.1 K
D1 2.0000000 sec
D11 0.03000000 sec
TD0 1
SF01 150.917895 MHz
NUC1 13C
P1 10.50 usec
PLW1 26.0000000 W
SF02 600.1320000 MHz
NUC2 1H
CPDPG[2] waltz16
PCPD2 70.00 usec
PLW2 20.0000000 W
PLW12 0.63775999 W
PLW13 0.32078999 W

F2 - Processing parameters
SI 32768
SF 150.9028077 MHz
WDW EM
SSB 0
LB 1.00 Hz
GB 0
PC 1.40


Q-ToF MS Report | Frontier Research Center@VISTEC

Analysis Info



Analysis Name	D:\Data\VISTEC Data QTOF\WinichVA-monrat\TN2tpa000001.d	Acquisition Date	10/14/2016 10:42:04 AM
Method	APCI_DirectProbe.m	Operator	VISTEC_Scientist
Sample Name	TN2tpa m/z = 762.1833	Instrument	compact 8255754.20068
Comment			

Acquisition Parameter

Source Type	APCI	Ion Polarity	Negative	Set Nebulizer	2.0 Bar
Focus	Not active	Set Capillary	4000 V	Set Dry Heater	220 °C
Scan Begin	400 m/z	Set End Plate Offset	-500 V	Set Dry Gas	5.0 l/min
Scan End	900 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	2000 nA	Set APCI Heater	450 °C




#	m/z	I
1	762.1567	377847
2	763.1599	218769
3	764.1583	108607
4	765.1576	39173
5	766.1573	10338



Compound 8

TN07-30 PURE CDCl₃




Current Data Parameters
NAME TN07-30
EXPNO 2
PROCNO 1

F2 - Acquisition Parameters
Date 20160315
Time 10.35 h
INSTRUM spect
PROBHD Z115435_0095_1
PULPROG zg30
TD 65536
SOLVENT CDCl₃
NS 8
DS 2
SWH 12019.230 Hz
FIDRES 0.366798 Hz
AQ 2.7262976 sec
RG 191.96
DW 41.600 usec
DE 40.00 usec
TE 303.1 K
D1 1.0000000 sec
TD0 1
SF01 600.1337058 MHz
NUC1 1H
P1 8.50 usec
PLW1 20.0000000 W

F2 - Processing parameters
SI 65536
SF 600.1300599 MHz
WDW EM
SSB 0
LB 0.30 Hz
GB 0
PC 1.00

TN07-30 CDCl₃



Current Data Parameters
NAME TN07-30
EXPNO 6
PROCNO 1

F2 - Acquisition Parameters
Date 20160603
Time 11.53 h
INSTRUM spect
PROBHD Z114607_0208_1
PULPROG zgpp30
TD 65536
SOLVENT CDCl₃
NS 256
DS 2
SWH 36231.883 Hz
FIDRES 1.105709 Hz
AQ 0.9043968 sec
RG 191.96
DW 13.800 usec
DE 6.50 usec
TE 303.1 K
D1 2.0000000 sec
D11 0.0300000 sec
TD0 150.9178993 MHz
SF01 150.9178993 MHz
NUC1 13C
P1 9.70 usec
PLW1 100.69000244 W
SF02 600.1324005 MHz
NUC2 1H
CPDPRG[2] waltz16
PCPD2 70.00 usec
PLW2 23.0000000 W
PLW12 0.38020000 W
PLW13 0.19124000 W

F2 - Processing parameters
SI 32768
SF 150.9028090 MHz
WDW EM
SSB 0
LB 1.00 Hz
GB 0
PC 1.40


Q-ToF MS Report | Frontier Research Center@VISTEC

Analysis Info




Analysis Name	D:\Data\VISTEC Data QTOF\Winch\A-monrat\TN3 tpa new000001.d	Acquisition Date	10/14/2016 12:54:33 PM
Method	APCI_DirectProbe.m	Operator	VISTEC_Scientist
Sample Name	TN4 tpa new m/z = 1005.2881	Instrument	compact 8255754.20068
Comment			

Acquisition Parameter


Source Type	APCI	Ion Polarity	Negative	Set Nebulizer	2.0 Bar
Focus	Not active	Set Capillary	4000 V	Set Dry Heater	220 °C
Scan Begin	800 m/z	Set End Plate Offset	-500 V	Set Dry Gas	5.0 l/min
Scan End	1200 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	2000 nA	Set APCI Heater	450 °C



#	m/z	I
1	1005.3111	41543
2	1006.3154	32638
3	1007.3159	18332
4	1008.3170	7269
5	1009.3122	2515



Compound 9



Q-ToF MS Report | Frontier Research Center@VISTEC

Analysis Info


Analysis Name D:\Data\VISTEC Data QTOF\Vinich\A-monrat\TN4 tpa000001.d
 Method APCI_DirectProbe.m
 Sample Name TN 4tpa m/z = 1248.3929
 Comment

Acquisition Date 10/14/2016 1:43:16 PM




Operator VISTEC_Scientist
 Instrument compact 8255754.20068

Acquisition Parameter


Source Type	APCI	Ion Polarity	Negative	Set Nebulizer	2.0 Bar
Focus	Not active	Set Capillary	4000 V	Set Dry Heater	220 °C
Scan Begin	800 m/z	Set End Plate Offset	-500 V	Set Dry Gas	5.0 l/min
Scan End	1400 m/z	Set Charging Voltage	2000 V	Set Divert Valve	Source
		Set Corona	2000 nA	Set APCI Heater	450 °C




#	m/z	I
1	1248.4203	108465
2	1249.4229	107447
3	1250.4250	64999
4	1251.4236	28881
5	1252.4235	10822
6	1253.4267	3131



Compound T2




BRUKER



BRUKER

D:\Data\MSE\POSD\A-monrat\TN06-28-new\0_F5\1\1SLin


Comment 1 829.1891
Comment 2



Bruker Daltonics flexAnalysis


printed: 10/14/2016 5:10:29 PM

Compound T3



D:\Data\MSE\POSD\A-monrat\TN07-34-new\0_F9\1\1SL.in

Comment 1 1072.2939
Comment 2





Bruker Daltonics flexAnalysis

printed: 10/14/2016 5:14:01 PM

Compound T4

TN06-23 DMSO




Current Data Parameters
NAME TN06-23
EXPNO 5
PROCNO 1

F2 - Acquisition Parameters
Date 20160323
Time 17:33 h
INSTRUM spect
PROBHD Z115435_0005 (
PULPROG zg30
TD 65536
SOLVENT DMSO
NS 8
DS 2
SWH 12019.230 Hz
FIDRES 0.366798 Hz
AQ 2.7262976 sec
RG 86.99
DW 41.600 usec
DE 1.000 usec
TE 303.1 K
D1 1.0000000 sec
TDO 1
SF01 600.1337058 MHz
NUC1 1H
P1 9.30 usec
PLW1 20.0000000 W

F2 - Processing parameters
SI 65536
SF 600.1300000 MHz
WDW EM
SSB 0
LB 0.30 Hz
GB 0
PC 1.00

TN06-23 DMSO 13C



Current Data Parameters
NAME TN06-23
EXPNO 10
PROCNO 1


F2 - Acquisition Parameters
Date 20160330
Time 0.39 h
INSTRUM spect
PROBHD Z115435_0005 (
PULPROG zg30
TD 65536
SOLVENT DMSO
NS 1024
DS 2
SWH 36231.883 Hz
FIDRES 1.105709 Hz
AQ 0.9043968 sec
RG 191.96
DW 13.800 usec
DE 18.00 usec
TE 303.1 K
D1 2.0000000 sec
D11 0.03000000 sec
TDO 150.9178988 MHz
NUC1 13C
P1 10.50 usec
PLW1 26.00000000 W
SF02 600.1324005 MHz
NUC2 1H
CPDPRG [2 waltz16
PCPD2 70.00 usec
PLW2 20.00000000 W
PLW12 0.35302001 W
PLW13 0.17757000 W

F2 - Processing parameters
SI 32768
SF 150.9028085 MHz
WDW EM
SSB 0
LB 1.00 Hz
GB 0
PC 1.40

D:\Data\MSE\POSD\A-monrat\TN06-23\0_FI\1\ISLin

Comment 1 1315.3987

Comment 2



Bruker Daltonics flexAnalysis

printed: 10/14/2016 5:12:03 PM