Electronic Supplementary Material (ESI) for Inorganic Chemistry Frontiers. This journal is © the Partner Organisations 2017

Supplementary Information

The green synthesis of ultrafine palladium-phosphorus alloyed

nanoparticles anchored on the polydopamine functionalized

graphene used as an excellent electrocatalyst for ethanol oxidation Honglei Yang*, Hai Zou, Ming Chen, Shuwen Li*, Jun Jin and Jiantai Ma

State Key Laboratory of Applied Organic Chemistry, Gansu Provincial Engineering

Laboratory for Chemical Catalysis, College of Chemistry and Chemical Engineering,

Lanzhou University, Lanzhou 730000, P. R. China

*Corresponding authors.

E-mail addresses: yanghl@lzu.edu.cn (Honglei Yang)

lishw@lzu.edu.cn (Shuwen Li).

1. Sample characterization

Elemental analysis was conducted with a conventional combustion method (CHN, varioMLCRO) based on the burn-off mass of the sample and on the analysis of the evolved gases using a thermal conductivity detector. Inductive coupled plasma optical emission spectrometer (ICP-OES) analysis was recorded on Perkin Elmer (Optima-4300DV). Raman spectra were carried out with inVia Reinishaw confocal spectroscopy with 633 nm laser excitation. X-ray diffraction (XRD) measurements were carried out at room temperature and performed on a Rigaku D/max-2400 diffractometer using Cu-K α radiation as the X-ray source. X-ray photoelectron spectroscopy (XPS) analysis was carried on PHI-5702 X-ray photoelectron spectrometer. The TEM images were obtained by Tecnai G² F³⁰ electron microscope operating at 300 kV.

2.Tables and Figures

	V/K_2PdCl_4 (mL)	V/NaH ₂ PO ₂ (mL)	V/NaBH ₄ (mL)
Pd/GS	5.88	0	6
Pd-P/GS	5.94	0.85	16.5
Pd/PDA-GS	5.88	0	6
Pd-P/PDA-GS-1	5.94	0.85	16.5
Pd-P/PDA-GS-2	5.99	1.44	10
Pd-P/PDA-GS-3	6.21	4.46	8

 Table S1 The specific volume of different solution for preparing the catalysts.

Catalysts	Pd content (wt.%)	Molar ratio of Pd/P
Pd/GS	11.52	-
Pd/GS	11.39	23.9/1
Pd/PDA-GS	11.23	-
Pd-P/PDA-GS-1	11.43	24.8/1
Pd-P/PDA-GS-2	11.93	16.8/1
Pd-P/PDA-GS-3	12.73	5.4/1

Table S2 The Pd and molar ratio of Pd/P contents by ICP-OES analysis of as-prepared catalysts.



Fig. S1 TEM images of (A) Pd/GS, (B) Pd-P/GS, (C) Pd/PDA-GS and (D) Pd-P/PDA-GS-2.



Fig. S2 XRD patterns of (a) GS and (b) PDA-GS.



Fig. S3 XRD patterns of (a) Pd/GS, (b) Pd-P/GS, (c) Pd/PDA-GS, (d) Pd-P/PDA-GS-1, (e) Pd-P/PDA-GS-2 and (f) Pd-P/PDA-GS-3.



Fig. S4 TEM image after 500 cycles CV scans for Pd-P/PDA-GS-2.