

Rhodium-Catalyzed Asymmetric 1,4-Addition Reactions of Aryl Boronic Acids with Nitroalkenes: Reaction Mechanism and Development of Homogeneous and Heterogeneous Catalysts

Hiroyuki Miyamura, Kohei Nishino, Tomohiro Yasukawa, and Shū Kobayashi*
*Department of Chemistry, School of Science, The University of Tokyo, Hongo, Bunkyo-ku,
Tokyo 113-0033, Japan.*

Electronic Supplementary Information

Contents

| | |
|--|-------|
| 1. General | S-1 |
| 2. Preparation of chiral dienes | S-3 |
| 3. Preparation of polymer incarcerated metal nanoparticle catalysts | S-4 |
| 4. Preparation of substrates | S-8 |
| 5. Asymmetric 1,4-addition reactions | S-10 |
| 6. Reaction profiles in toluene/H ₂ O = 1/1 | S-11 |
| 7. Reaction profiles during recovery and reuse, after hot filtration | S-12 |
| 8. XPS analysis | S-14 |
| 9. Products | S-16 |
| 10. Charts | S-23 |
| 11. References | S-136 |

1. General


- JEOL JMN-LA400, 500 or 600 spectrometers were used for NMR measurement. Chloroform ($\delta = 7.24$) or tetramethylsilane ($\delta = 0.00$) was used as an internal standard for ¹H NMR and CDCl₃ ($\delta = 77.0$) for ¹³C NMR. Structures of known compounds were confirmed by comparison with commercially available compounds or data shown in literature.
- IR spectra were measured on a JASCO FT/IR-610 spectrometer.
- Direct Analysis in Real Time (DART) mass spectra were recorded on JEOL JMS-T100TD mass spectrometer.
- Specific rotations were recorded with JASCO P-1010 or P-2100.
- Melting point was determined on a standard melting point apparatus and is uncorrected.
- Preparative thin-layer chromatography was carried out using Wakogel B-5F.
- ICP analysis was performed on Shimadzu ICPS-7510 equipment.
- GC analysis. was performed on Shimadzu GC-2010 apparatus (**Condition** : column = J

& W SCIENTIFIC DB-1 0.25 mm ID, 0.25 μm , 60.0 m; Gas pressure: 157.5 kPa, Total flow: 41.3 mL/min, Column flow: 0.93 mL/min, Velocity: 21.1 cm/sec; Purge flow: 3.0 mL/min; Split ratio: 40:1; Injector: 300 $^{\circ}\text{C}$, FID: 300 $^{\circ}\text{C}$; Column program: starting from 100 $^{\circ}\text{C}$, 20 $^{\circ}\text{C}/\text{min}$ to 300 $^{\circ}\text{C}$, 10 min hold).

- HPLC analysis was performed on Shimadzu LC-20AB, SPD-M20A and DGU-20A₃.
- XPS analysis was performed on JPS-9010MC with a Mg K α X-ray source and the O 1s line at 532.9 eV was used as reference to correct the binding energies.
- The absolute configuration of reported compounds was determined by comparison to literature and that of other products was assumed by analogy.
- STEM/EDS images were obtained using a JEOL JEM-2100F instrument operated at 200 kV. All STEM specimens were prepared by placing a drop of the solution on carbon-coated Cu grids and allowed to dry in air (without staining).
- Rh₂(OAc)₄ was purchased from Strem Chemical Inc.
- [Rh(C₂H₄)₂Cl]₂ and V-70 were purchased from Wako Pure Chemical Company.
- AgSbF₆ complex was purchased from Sigma-Aldrich Co., Ltd..
- NaBH₄ was purchased from Wako Pure Chemical Company and recrystallized from diglyme by heating according to the literature¹ and stored in a glove box.
- Ketjen black EC300J was purchased from Lion Corporation.
- Toluene was purchased in dried grade from Wako Pure Chemical Company and used without further purification.
- Deionized water from a MILLIPORE MilliQ machine (Gradient A 10) was used as solvent without further treatment.
- Aliphatic unsaturated esters and cinnamate were purchased from Tokyo Kasei Kogyo Co., Ltd..
- Nitroalkenes were prepared by following the literature.
- Arylboronic acids were purchased from Wako Pure Chemical Company or prepared from the corresponding Grignard reagent. The ratio of boronic acid to boroxine was determined by ¹H NMR analysis before use.
- Chiral diene **4a**, **4b**, and **S1** were prepared by following the literatures.^{2a}
- PI/CB Rh/Ag was prepared by following the literature.³
- Asymmetric 1,4-addition reactions were conducted with CarouselTM.
- Unless otherwise stated, all reactions were carried out under argon atmosphere.
- 0.45 μm PTFE membrane filter (WhatmanTM cat. No. 6784-2504) was used for filtration of solid catalysts during hot filtration test and taking reaction profiles.
- Yields were determined by GC analysis using durene as an internal standard for taking reaction profiles.
- Procedures conducted in previous published paper (Yasukawa, T.; Suzuki, A.; Miyamura, H.; Nishino, K.; Kobayashi, S., *J. Am. Chem. Soc.* **2015**, *137*, 6616.) were followed for hot leaching test and taking reaction profile with preheating.

2. Preparation of chiral dienes


2-1. Saponification of 7-isopropyl-5-methylbicyclo[2.2.2]octa-2,5-diene-2-carboxylate **S1**²



Chiral diene **S1** (55 mg, 0.25 mmol) in MeOH (3 mL) and NaOH (40 mg, 1 mmol) in water (1.5 mL) were mixed. After stirring for 6 h at 50 °C, 1N HCl (5 mL) was added. The water layer was extracted with CH₂Cl₂, and the combined organic layers were washed with brine and dried over Na₂SO₄. The precipitation was removed by filtration and the filtrate was evaporated and dried under vacuum to afford the crude desired compound **S2** (57.0 mg, quantitative yield) as a solid, which was used in the next reaction without further purification. ¹H NMR (CDCl₃, 500 MHz) δ: 7.44 (1H, dd, *J* = 6.2, 1.7 Hz), 5.81 (1H, dt, *J* = 6.2, 1.7 Hz), 4.06 (1H, dt, *J* = 6.2, 1.7 Hz), 3.43-3.40 (1H, m), 1.59-1.54 (1H, m), 1.56 (3H, ddd, *J* = 11.3, 9.1, 2.8 Hz), 1.20-1.14 (1H, m), 1.13-1.05 (1H, m), 0.98 (3H, d, *J* = 6.8 Hz), 0.98-0.95 (1H, m), 0.82 (3H, d, *J* = 6.8 Hz). ¹H NMR (CDCl₃, 125 MHz) δ: 170.3, 148.9, 143.1, 140.5, 124.1, 47.6, 44.2, 39.2, 33.7, 31.4, 21.8, 21.3, 18.9.

2-2. Preparation of (1*R*,4*R*,7*R*)-*N*-(*tert*-butyl)-

7-isopropyl-5-methylbicyclo[2.2.2]octa-2,5-diene-2-carboxamide (**4c**)




tert-Butylamine (21.5 μL, 0.2 mmol) and *N,N*-diisopropylcarbodiimide (34.7 μL, 0.22 mmol) in CH₂Cl₂ (500 μL) were added to a solution of carboxylic acid **S2** (41.3 mg, 0.2 mmol), 1-hydroxybenzotriazole (27.0 mg, 0.2 mmol) and *N,N*-dimethyl-4-aminopyridine (1.2 mg, 0.01 mmol) in CH₂Cl₂ (500 μL) under argon. After stirring for 9 h at 50 °C, triethylamine (0.4 mmol) and then *tert*-butylamine (21.5 μL, 0.2 mmol) were added. After stirring for 24 h at 50 °C, 1N HCl (3 mL) was added. The precipitation was removed by filtration and the water layer was extracted with CH₂Cl₂. The combined organic layers were washed with brine, dried over Na₂SO₄ and concentrated under vacuum. The residue was purified by preparative TLC (hexane/EtOAc = 5/1) to afford **4c** (28.3 mg, 54% yield) as a white solid.

[α]_D²⁰ = +25.6 (c = 0.09, CHCl₃). IR (KBr) cm⁻¹: 3341, 2961, 2938, 2869, 1662, 1630, 1605, 1536, 1447, 1364, 1285, 1220, 815. M.p. = 123-126 °C. ¹H NMR (CDCl₃, 600 MHz) δ: 6.68 (1H, dd, *J* = 6.2, 1.4 Hz), 5.80 (1H, d, *J* = 6.2 Hz), 5.49 (1H, br s), 4.01-4.00 (1H, m), 3.30 (1H, dt, *J* = 6.2, 2.1 Hz), 1.81 (3H, d, *J* = 1.4 Hz), 1.58-1.56 (1H, m), 1.37 (9H, s), 1.26-1.19 (1H, m), 1.10-1.05 (1H, m), 1.00 (3H, d, *J* = 6.9 Hz), 0.94 (1H, ddd, *J* = 11.7, 4.8, 2.8 Hz), 0.81 (3H, d, *J* = 6.9 Hz). ¹³C NMR (CDCl₃, 125 MHz) δ: 165.8, 146.1, 143.9, 136.6, 124.3, 51.0, 47.7, 43.5, 40.0, 33.9, 31.9, 28.9, 21.8, 21.3, 19.0. HRMS (DART) calculated for

C₁₇H₂₈NO⁺ [*M*+H⁺] 262.21709, found 262.21643.

2-3. (1*R*,4*R*,7*R*)-*N*-(*tert*-butyl)-

7-isopropyl-*N*,5-dimethylbicyclo[2.2.2]octa-2,5-diene-2-carboxamide (**4d**)




Oxalyl chloride (65 μ L, 0.75 mmol) and dimethylformamide (8.5 μ L, 0.11 mmol) were added to the solution of carboxylic acid **S2** (103 mg, 0.5 mmol) in CH₂Cl₂ (1 mL) at 0 °C under argon. After stirring for 3 h at 0 °C, triethylamine (350 μ L, 2.5 mmol) and then *tert*-butyl methyl amine (1.5 mmol) in CH₂Cl₂ (1 mL) were added at 0 °C. After the mixture was stirred for 24 h at room temperature, sat. NH₄Cl aq. (4 mL) was added. The water layer was extracted with CH₂Cl₂ and the combined organic layers were washed with brine, dried over Na₂SO₄ and concentrated under vacuum. The residue was purified by preparative TLC (hexane/EtOAc = 5/1) to afford **4d** (42.9 mg, 62 % yield) as a liquid.

$[\alpha]_D^{20} = +28.4$ ($c = 0.31$, CHCl₃). IR (neat) cm⁻¹: 3037, 2957, 2869, 1632, 1472, 1365, 1150, 1057, 821. ¹H NMR (CDCl₃, 500 MHz) δ : 6.37 (1H, dd, $J = 6.2, 1.7$ Hz), 5.79 (1H, d, $J = 6.2$ Hz), 3.63 (1H, dt, $J = 6.2, 1.7$ Hz), 3.27-3.24 (1H, m), 2.78 (3H, s), 1.80 (3H, d, $J = 1.7$ Hz), 1.60 (1H, ddd, $J = 11.9, 8.5, 2.8$ Hz), 1.39 (9H, s), 1.37-1.32 (1H, m), 1.08-1.01 (1H, m), 0.94 (3H, d, $J = 6.8$ Hz), 0.90 (1H, ddd, $J = 11.3, 4.5, 2.3$ Hz), 0.79 (3H, d, $J = 6.8$ Hz). ¹³C NMR (CDCl₃, 125 MHz) δ : 172.2, 147.2, 144.1, 134.8, 123.9, 56.0, 48.0, 43.2, 42.4, 34.5, 34.0, 32.2, 27.8, 21.7, 21.4, 19.1. HRMS (DART) calculated for C₁₈H₃₀NO⁺ [*M*+H⁺] 276.23274, found 276.23370.


3. Preparation of polymer incarcerated metal nanoparticle catalysts

3-1. Preparation of 2-(2-(2-(2-(4-vinylbenzyloxy)ethoxy)ethoxy)ethoxy)ethanol: To



sodium hydride (55% in mineral oil, 5.7 g) suspended in THF (150 mL), tetraethyleneglycol (25.2 g) was added at 0 °C. After the reaction mixture was stirred for 1 hour at room temperature, 1-(chloromethyl)-4-vinylbenzene (13.3 g) was added and the mixture was further stirred for 2 h. The mixture was cooled to 0 °C and diluted with diethyl ether. Saturated aqueous ammonium chloride was added to quench the reaction and the aqueous layer was extracted with diethyl ether. The combined organic layers were dried over sodium sulfate and the solvent was removed in vacuo. The residue was purified by column chromatography to afford 2-(2-(2-(2-(4-vinylbenzyloxy)ethoxy)ethoxy)ethoxy)ethanol ether (21.6 g, 68%). ¹H NMR (CDCl₃, 600 MHz) δ : 7.38 (2H, d, $J = 7.9$ Hz), 7.30 (2H, d, $J = 7.9$ Hz), 6.70 (1H, dd, $J = 17.8, 11.1$ Hz), 5.74 (1H, d, $J = 17.6$ Hz), 5.23 (1H, d, $J = 10.8$ Hz), 4.55 (2H, s), 3.71-3.57 (17H, m), 2.82 (1H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 137.7, 136.9, 136.4, 127.9, 126.1, 113.7, 72.8, 72.4, 70.53, 70.51, 70.48, 70.2, 69.3, 61.6.


3-2. Preparation of 4-Vinylbenzyl glycidyl ether: To sodium hydride (55% in mineral oil,



17.5 g) suspended in DMF (300 mL), glycidol (33.1 mL) was added at 0 °C. After the reaction mixture was stirred for 1 h at 0 °C, 1-(chloromethyl)-4-vinylbenzene (28.3 mL) was added and the mixture was further stirred for 4 h. The mixture was diluted with diethyl ether at 0 °C. Saturated aqueous ammonium chloride was added to quench the reaction and the aqueous layer was extracted with dichloromethane. The combined

organic layers were dried over sodium sulfate and the solvent was removed in vacuo. The residue was purified by column chromatography to afford 4-vinylbenzyl glycidyl ether (20.2 g, 53%). ¹H NMR (CDCl₃, 400 MHz) δ: 7.39 (2H, d, *J* = 7.8 Hz), 7.30 (2H, d, *J* = 7.8 Hz), 6.71 (1H, dd, *J* = 17.9, 11.0 Hz), 5.74 (1H, d, *J* = 17.4 Hz), 5.24 (1H, d, *J* = 11.0 Hz), 4.57 (2H, q, *J* = 11.8 Hz), 3.76 (1H, dd, *J* = 11.5, 2.8 Hz), 3.42 (1H, q, *J* = 5.8 Hz), 3.20-3.15 (1H, m), 2.79 (1H, t, *J* = 4.6 Hz), 2.61 (1H, q, *J* = 2.4 Hz). ¹³C NMR (CDCl₃, 100 MHz) δ: 137.4, 137.1, 136.4, 127.9, 126.2, 113.8, 73.0, 70.7, 50.8, 44.2.


3-3. Preparation of Copolymer: Styrene (0.98 g), 4-vinylbenzyl glycidyl ether (1.8 g),



2-(2-(2-(2-(4-vinylbenzyloxy)ethoxy)ethoxy)ethoxy)ethanol (2.93 g) and 2,2'-azobis(4-methoxy)-2,4-dimethylvaleronitrile (V-70, 92.4 mg) were combined in chloroform (5.5 mL). The mixture was stirred for 48 h at room temperature. The resulting polymer solution was slowly poured into ether.


Solvent was removed by decantation and remaining precipitated polymers were washed with ether several times. Polymers were dissolved in THF, repeated to precipitate for 2 times and dried *in vacuo* to afford the desired copolymer (P4, 6.86 g, 49 % yield). The molar ratio of the components was determined by ¹H NMR analysis (x: y: z = 40: 25: 35).

3-4. Typical preparation procedure of PI/CB Rh/Ag:





Copolymer (500.0 mg), ketjen black EC300J (500.0 mg) and NaBH₄ (113.5 mg) were combined in diglyme (35 mL) at room temperature, to this solution was slowly added rhodium(II) acetate dimer (44.2 mg) and silver hexafluoroantimonate (68.7 mg) with 20 mL of THF. The mixture was stirred overnight at room temperature and diethyl ether (200 mL)

was slowly added to the mixture at room temperature. After the catalysts, which were black powders, were filtered and crashed, they were washed with diethyl ether several times and dried at room temperature. Next, the catalysts were heated at 150 °C for 5 h without solvent. The catalysts were transferred to the solution of NaBH₄ (113.5 mg) in diglyme (28 mL) and this solution was stirred under air at room temperature for 6 h. The catalysts were filtered and stirred in 1:1 ratio of THF/water co-solvent overnight. The catalysts were filtered, washed with dichloromethane and THF and dried to afford black powder. This powder was heated at 170 °C for 5 h without solvent to afford PI/CB Rh/Ag. PI/CB Rh/Ag (10-20 mg) was heated in sulfuric acid (1 mL) at 200 °C, nitric acid was added until no emission of brown gas was observed. After complete evaporation of nitric acid, the mixture was cooled to room temperature and water was added to dilute to 50 mL solution in a volumetric flask. The amount of Rh and Ag in the resulting solution was measured by ICP analysis to determine the loading of Rh and Ag. Preparations of the PI catalysts with different ratios of Rh/Ag were conducted following this procedure.




ESI Figure 1. STEM images of PI/CB Rh/Ag.






ESI Figure 2. EDS mapping of PI/CB Rh/Ag.




ESI Figure 3. Line analysis of PI/CB Rh/



ESI Figure 4. Size distribution of PI/CB Rh/Ag.

4. Preparation of substrates


(*E*)- β -nitrostyrene⁴



To benzaldehyde (20.2 mL, 0.2 mol) and nitromethane (10.7 mL, 0.2 mol) in MeOH (50 mL) under argon, NaOH (9.0 g, 0.225 mol) in water (30 mL) was slowly added for 30 min at 0 °C. After stirring for another 30 min at 0 °C, water (100 mL) was added. The reaction mixture was carefully poured to crushed ice containing concentrated HCl (32 mL). The yellow solids which were precipitated out was filtered, dried in a vacuum desiccator, and recrystallized from hot EtOH to afford 16.5 g of desired product (62% yield) as a yellow needle crystal.

¹H NMR (CDCl₃, 600 MHz) δ : 8.01 (1H, d, J = 13.8 Hz), 7.59 (1H, d, J = 13.8 Hz), 7.55 (2H, d, J = 7.6 Hz), 7.53-7.48 (1H, m), 7.47-7.44 (2H, m). ¹³C NMR (CDCl₃, 125 MHz) δ : 139.0, 137.1, 132.1, 130.0, 129.4, 129.1.


(*E*)-1-Nitrohex-1-ene⁵



To valeraldehyde (8.6 mL, 80 mmol) and nitromethane (4.5 mL, 84 mmol) in MeOH (20 mL) under argon, NaOH (3.52 g, 88 mmol) in water (10 mL) was slowly added for 30 min at 0 °C. After stirring for another 30 min at 0 °C, water (75 mL) and methanol (15 mL) were added. The reaction mixture was carefully poured to 1/1 solution (100 mL) of H₂O and concentrated HCl. The mixture was stirred for 1 hour at at 0 °C. The mixture was extracted with dichloromethane and the combined organic layers are dried over with Na₂SO₄. The solution was concentrated under vacuum and column chromatography and distillation afforded the desired product as yellow oil.

¹H NMR (CDCl₃, 600 MHz) δ : 7.31-7.26 (1H, m), 6.99 (1H, d, J = 13.1 Hz), 2.28 (2H, q, J = 7.6 Hz), 1.53-1.48 (2H, m), 1.39 (2H, td, J = 14.8, 7.6 Hz), 0.94 (4H, t, J = 7.2 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ : 142.7, 139.5, 29.7, 28.0, 22.1, 13.6.


(*E*)-3-Methyl-1-nitrobut-1-ene⁶



To isobutyraldehyde (7.3 mL, 80 mmol) and nitromethane (4.5 mL, 84 mmol) in MeOH (20 mL) under argon, NaOH (3.52 g, 88 mmol) in water (10 mL) was slowly added for 30 min at 0 °C. After stirring for another 30 min at 0 °C, water (75 mL) and methanol (15 mL) were added. The reaction mixture was carefully poured to 1/1 solution (100 mL) of H₂O and concentrated HCl. The mixture was stirred for 1 hour at at 0 °C. The mixture was extracted with dichloromethane and the combined organic layers are dried over with Na₂SO₄. The solution was concentrated under vacuum and column chromatography and distillation afforded 3.1 g of desired product (34% yield) as yellow oil.

¹H NMR (CDCl₃, 400 MHz) δ : 7.27 (1H, q, J = 6.9 Hz), 6.96 (1H, d, J = 13.3 Hz), 2.62-2.59 (1H, m), 1.17 (6H, d, J = 6.9 Hz). ¹³C NMR (CDCl₃, 100 MHz) δ : 148.4, 138.1, 28.3, 21.0.


(*E*)-(2-Nitrovinyl)cyclohexane⁷



To cyclohexanecarboxaldehyde (4.85 mL, 40 mmol) and nitromethane (2.14 mL, 40 mmol) in MeOH (10 mL) under argon, NaOH (1.76 g, 44 mmol) in water (5 mL) was slowly added for 30 min at 0 °C. After stirring for another 30 min at 0 °C, water (37.5 mL) and methanol (7.5) were added. The reaction mixture was carefully poured to 1/1 solution (50 mL) of H₂O and concentrated HCl. The mixture was stirred for 1 hour at at 0 °C. The mixture was extracted with dichloromethane and the combined organic layers are dried over with Na₂SO₄. The solution was concentrated under vacuum and column chromatography afforded desired product as yellow oil.


¹H NMR (CDCl₃, 600 MHz) δ: 7.20 (1H, q, *J* = 6.9 Hz), 6.91 (1H, d, *J* = 13.1 Hz), 2.27-2.21 (1H, m), 1.82-1.75 (4H, m), 1.72-1.67 (1H, m), 1.36-1.27 (2H, m), 1.24-1.15 (3H, m). ¹³C NMR (CDCl₃, 150 MHz) δ: 147.2, 138.3, 37.6, 31.5, 25.6, 25.6.

(*m*- or *p*-)Methoxyphenylboronic acid




To Mg (1.34g, 55 mmol) suspended in THF (4 mL) in 100 mL 3-necked round bottom flask, (*m*- or *p*-)bromoanisole (9.35g, 50 mmol) in THF (40 mL) was carefully added dropwise to prepare Grignard reagent. After stirring for 3 h at room temperature, this Grignard reagent was transferred to the dropping funnel by cannula and slowly added to trimethoxyborate (6.7 mL, 60 mmol) in THF (40 mL) at -78 °C. After stirring over night at room temperature, 1N HCl (150 mL) was added, and the aqueous layer was extracted with extracted with CH₂Cl₂. The combined organic layers were dried over Na₂SO₄, the solvent was removed *in vacuo*. The residue was purified by recrystallization (hexane/EtOAc) to afford mixture of boronic acid and boroxine.

Tris(3-methoxyphenyl)Boroxine⁸



The ratio of boronic acid to boroxine was determined by ¹H NMR analysis. ¹H NMR (CDCl₃, 500 MHz) δ: 7.83 (1H, d, *J* = 7.4 Hz), 7.75 (1H, d, *J* = 2.3 Hz), 7.45 (1H, t, *J* = 7.9 Hz), 7.15 (1H, dd, *J* = 7.9, 2.8 Hz), 3.92 (3H, s). ¹³C NMR (CDCl₃, 150MHz) δ: 159.2, 129.2, 128.0, 120.4, 118.4, 55.3. These peaks derive from boroxine.

Tris(4-methoxyphenyl)Boroxine⁸



The ratio of boronic acid to boroxine was determined by ¹H NMR analysis. ¹H NMR (CDCl₃, 600 MHz) δ: 8.16 (2H, d, *J* = 8.3 Hz), 7.01 (2H, d, *J* = 8.3 Hz), 3.89 (3H, s). ¹³C NMR (CDCl₃, 150MHz) δ: 163.2, 137.5, 113.5, 55.2. These peaks derive from boroxine.

5. Asymmetric 1,4-addition reactions

5-1. Preparation of a stock solution of Rh complex with chiral diene: To chiral diene **4c** (0.00165 mmol, 0.110 mL of 3.9 mg/mL solution of toluene) in toluene (0.3 mL), chlorobis(ethylene)rhodium(I) dimer (0.00075 mmol, 0.09 mL of 3.2 mg/mL solution of toluene) was added at room temperature. The mixture was stirred at room temperature over 30 minutes. Aliquot of the obtained solution (0.5 mL) was taken for asymmetric 1,4-addition reaction in homogeneous system.


5-2. A typical procedure of asymmetric 1,4-addition of arylboronic acids to nitroolefins in homogeneous system: A stirring bar, 3-methoxyphenylboronic acid (0.45 mmol as B) and (*E*)- β -nitrostyrene (44.7 mg, 0.3 mmol) were combined in a reaction tube, then toluene (900 μ L) and water (1000 μ L) were added to the mixture. This tube was flushed with argon and sealed up with a septum. Rhodium-chiral diene complex (0.1 mol%) in toluene (100 μ L) was added by gas-tight syringe and the mixture was stirred at 100 °C for 16 h under reflux conditions. After refluxing, the reaction mixture was diluted with EtOAc, washed with brine and dried over with Na₂SO₄. The solid was filtered and the filtrate was concentrated under vacuum. The conversion was determined by ¹H NMR analysis with reference to an internal standard 1,1,2,2-tetrachloroethane. The solution was concentrated under vacuum again and the residue was purified by preparative TLC (toluene/hexane = 2/1) to afford 76.3 mg of 1-methoxy-3-(2-nitro-1-phenylethyl)benzene (99% yield) as a light yellow oil. The enantioselectivity of the desired compound was determined as 91% ee by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 1/1, flow = 1.0 mL/min.

5-3: A typical procedure of asymmetric 1,4-addition of arylboronic acids to nitroolefins in heterogeneous system: A stirring bar, PI/CB Rh/Ag(1/1) (13.6 mg, 1 mol% as Rh), 3-methoxyphenylboronic acid (0.45 mmol as B), (*E*)- β -nitrostyrene (44.7 mg, 0.3 mmol), and chiral diene **4c** (0.1 mol% in 20 μ L toluene) were combined in a reaction tube, then toluene (1980 μ L) and water (400 μ L) were added to the mixture. This tube was flushed with argon and sealed up with a septum. The mixture was stirred at 100 °C for 24 h under reflux conditions. After refluxing, THF was added to the mixture. The mixture was picked up with syringe and transferred to volumetric flask through membrane filter in order to remove the residual solids and diluted to 25 mL solution by THF. The filtrate (5 mL) was taken by volumetric pipette and the solvent was removed *in vacuo*. Residual crude mixture was heated in mixture of sulfuric acid (0.2 mL) and nitric acid at 200 °C until all nitric acid was removed, the mixture was cooled to room temperature and aqua regia (0.2 mL) was added. The solution was diluted to 10 mL solution by pure water and the resulting solution was measured by ICP analysis to determine the amount of Rh that leached out. Another filtrate (20 mL) was diluted with EtOAc, washed with brine and dried over with Na₂SO₄. The solid was filtered and the

filtrate was concentrated under vacuum. The conversion was determined by ^1H NMR analysis with reference to an internal standard 1,1,2,2-tetrachloroethane. The solution was concentrated under vacuum again and the residue was purified by preparative TLC (toluene/hexane = 2/1) to afford 54.6 mg of 1-methoxy-3-(2-nitro-1-phenylethyl)benzene (90% yield) as a light yellow oil. The enantioselectivity of the desired product was determined as 92% ee by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 1/1, flow = 1.0 mL/min.


5-4: A typical procedure of recovery and reuse of PI/CB Rh/Ag: A reaction was conducted following the procedure as previously mentioned. After the reaction, the catalyst was separated by the filtration. The filtrate was diluted with EtOAc and washed with brine. The organic layer was dried over with Na_2SO_4 and column chromatography afforded the desired product. The filtered catalyst was washed with EtOAc, water and acetone successively on the funnel. The catalyst was washed in 9/1 solution of water/0.5N HCl aq. overnight and filtered. In this procedure, around 5 mg of the catalyst was trapped on the filtrate paper, so the amount of the catalyst gradually decreased. The corrected catalyst was dried under vacuum. Based on the weight of the dried catalyst, the scale of next reaction was calculated.

6. Reaction profiles in toluene/ H_2O = 1/1




Obtained reaction profiles in toluene/ H_2O = 1/1 were almost same regardless of the presence of dimethylurea.

6.1 In the presence of dimethyl urea



ESI Figure 5


6.2 In the absence of dimethyl urea




ESI Figure 6

7. Reaction profiles during recovery and reuse, after hot filtration

7.1 Reaction profiles during recovery and reuse (1st to 3rd run)




Durene (~50 mg) was added in the reaction mixture as internal standard for GC analysis.




ESI Figure 7. Reaction profiles during recovery and reuse

7.2 Reaction profiles after hot filtration at 4 h and further 2 runs with 24 h reaction time (1st to 3rd run)




Durene (~50 mg) was added in the reaction mixture as internal standard for GC analysis.




ESI Figure 8. Reaction profiles after hot filtration at 4 h and further 2 runs with 24 h reaction time

7.3 Reaction profiles after hot filtration at 6 h (1st to 3rd run)




Durene (~50 mg) was added in the reaction mixture as internal standard for GC analysis.




ESI Figure 9. Reaction profiles after hot filtration at 6 h

8. XPS analysis



| | | | | |
|---------------|---------|---------|---------|---------|
| peak top (eV) | 497.859 | 497.060 | 497.564 | 496.282 |
|---------------|---------|---------|---------|---------|

ESI Figure 10. Rh 3p_{3/2} XPS spectrum of (a) fresh catalyst (b) catalyst collected by hot filtration during induction period (at 1 h) (c) catalyst collected by hot filtration during induction period (at 5 h) (d) catalyst after recovery reuse




| chart | (a) | (b) | (c) | (d) |
|---------------------------------|---------|---------|---------|---------|
| peak top 3d _{5/2} (eV) | 368.264 | 367.913 | 367.720 | 367.279 |
| peak top 3d _{3/2} (eV) | 374.258 | 373.965 | 373.833 | 373.193 |

ESI Figure 11. Ag 3d_{5/2}, 3/2 XPS spectrum of (a) fresh catalyst (b) catalyst collected by hot filtration during induction period (at 1 h) (c) catalyst collected by hot filtration during induction period (at 5 h) (d) catalyst after recovery reuse

9. Products


(*R*)-1-Methoxy-3-(2-nitro-1-phenylethyl)benzene (**3aa**, *ent*-**3cb**)^{6, 7, 8}



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 1/1, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 500 MHz) δ: 7.34-7.30 (2H, m), 7.27-7.23 (4H, m), 6.84-6.76 (3H, m), 4.98-4.96 (2H, m), 4.89-4.86 (1H, m), 3.77 (3H, s). ¹³C NMR


(CDCl₃, 125 MHz) δ : 159.9, 140.7, 139.0, 130.0, 129.0, 127.6, 119.8, 114.0, 112.5, 79.1, 55.2, 48.9.

(R)-1-Methoxy-4-(2-nitro-1-phenylethyl)benzene (3ac, ent-3bb)^{5, 6, 7, 8}




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.32 (2H, t, J = 7.6 Hz), 7.26-7.21 (3H, m), 7.15 (2H, d, J = 8.3 Hz), 6.85 (2H, dt, J = 8.9, 2.8 Hz), 4.95 (2H, dd, J = 7.6, 2.1 Hz), 4.86 (1H, t, J = 8.3 Hz), 3.77 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 158.9, 139.5, 131.1, 129.0, 128.7, 127.53, 127.48, 114.4, 79.4, 55.2, 48.2.

(R)-1-Chloro-4-(2-nitro-1-phenylethyl)benzene (3ad)^{5, 6, 7}




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.35-7.25 (5H, m), 7.21-7.16 (4H, m), 4.95 (2H, d, J = 7.6 Hz), 4.88 (1H, t, J = 8.2 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ : 138.7, 137.7, 133.6, 129.2, 129.1, 129.0, 127.8, 127.5, 79.0, 48.3.

(R)-1-Methyl-4-(2-nitro-1-phenylethyl)benzene (3af, ent-3bd)^{5, 6, 7, 8}




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.31 (2H, t, J = 7.6 Hz), 7.25-7.20 (3H, m), 7.14-7.09 (4H, m), 4.95 (2H, d, J = 7.6 Hz), 4.86 (1H, t, J = 8.2 Hz), 2.30 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 139.5, 137.3, 136.2, 129.7, 129.0, 127.6, 127.51, 127.48, 79.4, 48.6, 21.0.

(R)-1-Methoxy-2-(2-nitro-1-phenylethyl)benzene (3ag)^{6, 7}



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.33-7.22 (6H, m), 7.06 (1H, dd, J = 7.6, 1.4 Hz), 6.91-6.87 (2H, m), 5.29-5.25 (1H, m), 5.05-4.94 (2H, m), 3.83 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 156.8, 138.9, 128.74, 128.72, 128.4, 127.9, 127.5, 127.3, 120.8, 111.0, 77.9, 55.5, 43.3.


(R)-1-Methyl-2-(2-nitro-1-phenylethyl)benzene (3ah)⁵



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR


(CDCl₃, 600 MHz) δ : 7.30 (2H, t, J = 7.6 Hz), 7.26-7.17 (7H, m), 5.11 (1H, t, J = 7.9 Hz), 5.00-4.90 (2H, m), 2.31 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 138.7, 137.1, 136.5, 131.3, 128.9, 128.0, 127.49, 127.48, 126.4, 125.8, 79.2, 45.0, 19.6.

(S)-1-Methoxy-3-(1-(4-methoxyphenyl)-2-nitroethyl)benzene (3ba)⁶




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 1/1, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.26-7.22 (1H, m), 7.15 (2H, d, J = 8.9 Hz), 6.86-6.74 (5H, m), 4.94-4.91 (2H, m), 4.82 (1H, t, J = 8.2 Hz), 3.77 (6H, s), 3.76 (6H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 160.0, 158.9, 141.1, 131.1, 130.0, 128.7, 119.7, 114.4, 113.9, 112.4, 79.4, 55.24, 55.19, 48.2.

(R)-1-Methoxy-3-(2-nitro-1-(*p*-tolyl)ethyl)benzene (3ea)⁹




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.25-7.21 (1H, m), 7.12 (4H, s), 6.83-6.75 (3H, m), 4.94 (2H, d, J = 8.2 Hz), 4.83 (1H, t, J = 7.9 Hz), 3.76 (3H, s), 2.30 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 160.0, 141.0, 137.3, 136.1, 130.0, 129.7, 127.5, 119.8, 113.9, 112.5, 79.3, 55.2, 48.6, 21.0.

(S)-1-Bromo-4-(2-nitro-1-phenylethyl)benzene (3fb)⁵




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 0.7 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.46-7.44 (2H, m), 7.35-7.31 (2H, m), 7.28-7.25 (1H, m), 7.20 (2H, d, J = 6.9 Hz), 7.13-7.10 (2H, m), 4.95 (2H, d, J = 8.2 Hz), 4.86 (1H, t, J = 8.2 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ : 138.6, 138.2, 132.2, 129.4, 129.2, 127.8, 127.5, 121.6, 78.9, 48.4.

(R)-1-(1-(4-Bromophenyl)-2-nitroethyl)-3-methoxybenzene (3fa)




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 1/1, flow = 1.0 mL/min. $[\alpha]_D^{16} = +3.5$ (c = 1.46, CHCl₃, as 90% ee). IR (neat) cm⁻¹: 2938, 2837, 1601, 1586, 1553, 1490, 1454, 1435, 1407, 1377, 1319, 1294, 1263, 1154, 1074, 1041, 1011, 828, 778, 722, 696, 664. ¹H NMR (CDCl₃, 600 MHz) δ : 7.46-7.44 (2H, m), 7.27-7.23 (1H, m), 7.11 (2H, d, J = 8.2 Hz), 6.81-6.77 (2H, m), 6.72 (1H, t, J = 2.1 Hz), 4.93 (2H, d, J = 8.9 Hz), 4.83 (1H, t, J = 8.2 Hz), 3.77 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 160.1, 140.1, 138.1, 132.2, 130.2, 129.3, 121.7, 119.7, 114.0, 112.7, 78.8, 55.2, 48.3. HRMS (DART) calculated for C₁₅H₁₅BrNO₃⁺ [$M+H^+$] 336.02353, found 336.02376.

(S)-1-Fluoro-4-(2-nitro-1-phenylethyl)benzene (3gb, ent-3ae)^{6,7,8}




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ: 7.33 (t, 2H, *J* = 7.6 Hz), 7.28-7.24 (m, 1H), 7.22-7.19 (m, 4H), 7.03-6.99 (m, 2H), 4.96-4.93 (m, 2H), 4.90 (q, 1H, *J* = 8.5 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ: 162.1 (d, *J* = 245.6 Hz), 139.0, 135.0, 129.3 (d, *J* = 8.6 Hz), 129.1, 127.7, 127.5, 115.9 (d, *J* = 21.5 Hz), 79.3, 48.2.

(R)-1-(1-(4-Fluorophenyl)-2-nitroethyl)-3-methoxybenzene (3ga)




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 1/1, flow = 1.0 mL/min. $[\alpha]_D^{16} = -8.2$ (*c* = 1.04, CHCl₃, as 91% ee). IR (neat) cm⁻¹: 3007, 2940, 2920, 2839, 1604, 1586, 1554, 1510, 1491, 1455, 1436, 1377, 1321, 1264, 1228, 1161, 1104, 1042, 875, 838, 803, 781, 739, 721, 697. ¹H NMR (CDCl₃, 600 MHz) δ: 7.25 (1H, t, *J* = 8.2 Hz), 7.22-7.19 (2H, m), 7.01 (2H, t, *J* = 8.2 Hz), 6.80 (2H, d, *J* = 8.2 Hz), 6.74-6.72 (1H, m), 4.93 (2H, q, *J* = 4.1 Hz), 4.85 (1H, t, *J* = 7.9 Hz), 3.77 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ: 162.1 (d, *J* = 245.6 Hz), 160.1, 140.5, 134.9, 130.1, 129.3 (d, *J* = 7.2 Hz), 119.7, 115.9 (d, *J* = 21.5 Hz), 114.0, 112.6, 79.2, 55.2, 48.1. HRMS (DART) calculated for C₁₅H₁₅FNO₃⁺ [*M*+H⁺] 276.10360, found 276.10470.

(S)-3-(2-Nitro-1-phenylethyl)furan (3hb)



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. $[\alpha]_D^{16} = +35.4$ (*c* = 0.72, CHCl₃, as 94% ee). IR (neat) cm⁻¹: 3608, 3583, 3146, 3064, 3032, 2919, 1766, 1553, 1498, 1454, 1432, 1379, 1199, 1160, 1076, 1026, 875, 792, 771, 732, 703, 665, 600. ¹H NMR (CDCl₃, 400 MHz) δ: 7.38 (1H, t, *J* = 1.8 Hz), 7.37-7.23 (6H, m), 6.26-6.24 (1H, m), 4.87-4.74 (3H, m). ¹³C NMR (CDCl₃, 150 MHz) δ: 143.8, 139.5, 138.5, 129.0, 127.9, 127.6, 123.9, 109.7, 79.6, 40.9. HRMS (DART) calculated for C₁₂H₁₂NO₃⁺ [*M*+H⁺] 218.08172, found 218.08162.


(S)-3-(1-(3-Methoxyphenyl)-2-nitroethyl)furan (3ha)



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. $[\alpha]_D^{16} = +23.9$ (*c* = 0.78, CHCl₃, as 95% ee). IR (neat) cm⁻¹: 3145, 3006, 2920, 2838, 1766, 1602, 1553, 1493, 1455, 1436, 1379, 1322, 1262, 1198, 1158, 1028, 874, 782, 733, 705. ¹H NMR (CDCl₃, 400 MHz) δ: 7.38 (1H, t, *J* = 1.6 Hz), 7.28-7.23 (2H, m), 6.85-6.77 (3H, m), 6.26 (1H, s), 4.86-4.70 (3H, m), 3.78 (3H, s). ¹³C

NMR (CDCl₃, 150 MHz) δ : 160.0, 143.7, 140.1, 139.5, 130.1, 123.8, 119.8, 113.9, 112.9, 109.7, 79.5, 55.2, 40.8. HRMS (DART) calculated for C₁₃H₁₄NO₄⁺ [*M*+H⁺] 248.09228, found 248.09289.


(*R*)-2-(2-Nitro-1-phenylethyl)thiophene (3ib)¹⁰



125.1, 79.9, 44.7.


The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.27 (t, 2H, *J* = 7.6 Hz), 7.23-7.20 (3H, m), 7.13 (1H, d, *J* = 4.8 Hz), 6.87-6.82 (2H, m), 5.05 (1H, t, *J* = 7.9 Hz), 4.92-4.82 (2H, m). ¹³C NMR (CDCl₃, 150 MHz) δ : 142.4, 138.8, 129.1, 128.1, 127.5, 127.0, 125.2,

(*R*)-2-(1-(3-Methoxyphenyl)-2-nitroethyl)thiophene (3ia)




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. [α]_D¹⁶ = -11.6 (*c* = 1.13, CHCl₃, as 94% ee). IR (neat) cm⁻¹: 3426, 3109, 3072, 3006, 2960, 2939, 2919, 2837, 1602, 1587, 1553, 1491, 1455, 1435, 1377, 1319, 1292, 1264, 1201, 1161, 1083, 1044, 994, 907, 875, 852, 835, 782, 703. ¹H NMR (CDCl₃, 600 MHz) δ : 7.31-7.28 (1H, m), 7.24 (1H, d, *J* = 4.8 Hz), 6.97 (1H, t, *J* = 4.5 Hz), 6.94 (1H, d, *J* = 3.4 Hz), 6.92 (1H, d, *J* = 8.2 Hz), 6.86 (2H, t, *J* = 2.7 Hz), 5.13 (1H, t, *J* = 7.9 Hz), 5.01-4.92 (2H, m), 3.81 (3H, s). ¹³C NMR (CDCl₃, 150 MHz) δ : 160.1, 142.3, 140.3, 130.1, 127.0, 125.2, 125.1, 119.7, 113.8, 113.1, 79.9, 55.2, 44.7. HRMS (DART) calculated for C₁₃H₁₄NO₃S⁺ [*M*+H⁺] 264.06944, found 264.06984.

(*R*)-1-(1-Cyclohexyl-2-nitroethyl)benzene (3jb)^{9,8}



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ : 7.23 (2H, t, *J* = 7.6 Hz), 7.18-7.15 (1H, m), 7.06 (d, 2H, *J* = 6.9 Hz), 4.70 (1H, dd, *J* = 12.4, 5.5 Hz), 4.54 (1H, dd, *J* = 12.4, 10.3 Hz), 3.21-3.17 (1H, m), 1.75-1.67 (2H, m), 1.60-1.49 (3H, m), 1.42-1.37 (1H, m), 1.22-1.13 (1H, m), 1.10-0.91 (3H, m), 0.83-0.75 (1H, m). ¹³C NMR (CDCl₃, 150 MHz) δ : 138.8, 128.5, 128.1, 127.3, 78.8, 50.2, 40.9, 31.0, 30.6, 26.13, 26.09.


(*R*)-1-(1-Cyclohexyl-2-nitroethyl)-3-methoxybenzene (3ja)



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. [α]_D¹⁶ = +33.1 (*c* = 0.79, CHCl₃, as 91% ee). IR (KBr) cm⁻¹: 3435, 3036, 3006, 2977, 2930, 2848, 1600, 1551, 1487, 1466, 1446, 1384, 1350, 1329, 1284, 1255,


1216, 1200, 1165, 1131, 1086, 1038, 1008, 991, 963, 890, 865, 804, 784, 720, 700, 652, 617, 566, 541. M.p. = 84-86 °C. ¹H NMR (CDCl₃, 600 MHz) δ: 7.20 (1H, t, *J* = 8.2 Hz), 6.77 (1H, dd, *J* = 8.2, 2.1 Hz), 6.71 (1H, d, *J* = 7.6 Hz), 6.66 (1H, s), 4.76-4.72 (1H, m), 4.61-4.56 (1H, m), 3.77 (3H, s), 3.24-3.20 (1H, m), 1.76 (2H, t, *J* = 16.2 Hz), 1.67-1.52 (3H, m), 1.47 (1H, d, *J* = 13.1 Hz), 1.27-1.19 (1H, m), 1.16-0.97 (3H, m), 0.90-0.82 (1H, m). ¹³C NMR (CDCl₃, 150 MHz) δ: 159.7, 140.5, 129.5, 120.4, 114.5, 112.2, 78.8, 55.2, 50.2, 40.9, 31.0, 30.6, 26.15, 26.10. HRMS (DART) calculated for C₁₅H₂₂NO₃⁺ [*M*+H⁺] 264.15997, found 264.16061.

(*R*)-(3-Methyl-1-nitrobutan-2-yl)benzene (3kb)^{7, 8, 9}




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ: 7.31 (2H, t, *J* = 7.6 Hz), 7.27-7.25 (1H, m), 7.16-7.13 (2H, m), 4.76 (1H, q, *J* = 6.2 Hz), 4.64 (1H, dd, *J* = 12.4, 10.3 Hz), 3.26-3.21 (1H, m), 1.96 (1H, td, *J* = 14.1, 7.1 Hz), 1.01 (3H, d, *J* = 6.2 Hz), 0.81 (3H, d, *J* = 6.9 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ: 138.6, 128.6, 128.1, 127.4, 79.1, 51.0, 31.3, 20.6, 20.2.

(*R*)-1-Methoxy-3-(3-methyl-1-nitrobutan-2-yl)benzene (3ka)




The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 3/2, flow = 1.0 mL/min. [α]_D¹⁶ = +29.9 (*c* = 0.85, CHCl₃, as 91% ee). IR (neat) cm⁻¹: 3583, 2964, 2875, 2838, 1602, 1586, 1553, 1490, 1467, 1436, 1381, 1322, 1290, 1263, 1205, 1163, 1129, 1044, 990, 876, 783, 736, 704, 664. ¹H NMR (CDCl₃, 600 MHz) δ: 7.21 (1H, t, *J* = 8.2 Hz), 6.77 (1H, dd, *J* = 8.2, 2.7 Hz), 6.72 (1H, d, *J* = 7.6 Hz), 6.67 (1H, s), 4.72 (1H, q, *J* = 6.2 Hz), 4.60 (1H, dd, *J* = 12.4, 10.3 Hz), 3.77 (3H, s), 3.20-3.15 (1H, m), 1.95-1.89 (1H, m), 0.99 (3H, d, *J* = 6.9 Hz), 0.80 (3H, d, *J* = 6.9 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ: 159.6, 140.3, 129.5, 120.3, 114.4, 112.3, 79.0, 55.2, 51.0, 31.3, 20.6, 20.3. HRMS (DART) calculated for C₁₂H₁₈NO₃⁺ [*M*+H⁺] 224.12867, found 224.12934.

(*R*)-(1-Nitrohexan-2-yl)benzene (3lb)⁷



The enantio excess was determined by HPLC analysis on a chiralcel OD-H with hexane/2-propanol = 99/1, flow = 1.0 mL/min. ¹H NMR (CDCl₃, 600 MHz) δ: 7.33 (2H, t, *J* = 7.6 Hz), 7.27-7.25 (1H, m), 7.20-7.17 (2H, m), 4.59-4.51 (2H, m), 3.47-3.41 (1H, m), 1.68 (2H, dd, *J* = 15.1, 7.6 Hz), 1.34-1.13 (5H, m), 0.84 (3H, t, *J* = 7.2 Hz). ¹³C NMR (CDCl₃, 150 MHz) δ: 139.6, 128.9, 127.53, 127.50, 81.0, 44.4, 32.7, 29.0, 22.4, 13.8.


(*R*)-1-Methoxy-3-(1-nitrohexan-2-yl)benzene (3la)




The enantio excess was determined by HPLC analysis on a chiralcel


OD-H with hexane/2-propanol = 99/1, flow = 1.0 mL/min. $[\alpha]_D^{20} = +16.2$ ($c = 0.79$, CHCl_3 , as 86% ee). IR (neat) cm^{-1} : 3003, 2957, 2932, 2861, 1602, 1587, 1552, 1490, 1457, 1436, 1379, 1319, 1261, 1193, 1160, 1122, 1047, 874, 783, 730, 701. ^1H NMR (CDCl_3 , 600 MHz) δ : 7.25 (1H, t, $J = 7.6$ Hz), 6.81-6.76 (2H, m), 6.72 (1H, t, $J = 2.1$ Hz), 4.56-4.49 (2H, m), 3.80 (3H, s), 3.43-3.38 (1H, m), 1.67 (2H, dd, $J = 15.8, 7.6$ Hz), 1.34-1.15 (4H, m), 0.84 (3H, t, $J = 7.2$ Hz). ^{13}C NMR (CDCl_3 , 150 MHz) δ : 159.9, 141.2, 129.9, 119.7, 113.7, 112.4, 80.9, 55.2, 44.3, 32.6, 29.0, 22.4, 13.8. HRMS (DART) calculated for $\text{C}_{13}\text{H}_{20}\text{NO}_3^+$ [$M+\text{H}^+$] 238.14432, found 238.14468.

10. Charts




3aa ¹H NMR






E:\personal folder\Nishino\Compounds\mproc-1.als
mproc



3aa ¹³C NMR

Sample Name : nsn363rac
OD-H, 1.0 mL/min, Hex:IsoPro= 1 : 1




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 27.005 | 4075750 | 80632 | 50.094 |
| 2 | 51.968 | 4060403 | 40411 | 49.906 |

3aa racemic




E:\personal folder\Nishino\Compounds\pprc-1.als
pprc



3ac 13C NMR

Sample Name : nsn121rac(for560)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 19.834 | 7144237 | 220552 | 50.018 |
| 2 | 24.513 | 7139029 | 176357 | 49.982 |



3ac racemic



3ad ¹H NMR




D:\Documents and Settings\Kobayashilab\Desktop\msn423pc-1.als
msn423pc



3ad 13H NMR


Sample Name : nsn425rac(for580)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 17.165 | 1572780 | 58446 | 49.873 |
| 2 | 27.795 | 1580809 | 35885 | 50.127 |



3ad racemic



3af 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn398pc-1.als
nsn398pc



3af 13C NMR

Sample Name : nsn389rac(for565and573)
OD-H, 1.0 mL/min, Hex:IPA = 9/1



1 PDA Multi 1/220nm 4nm

PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|----------|--------|--------|
| 1 | 65.149 | 11668543 | 154080 | 49.947 |
| 2 | 69.268 | 11693200 | 145159 | 50.053 |

3af racemic

3af racemic(2)


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn389rac.lcd

分析者 : System Administrator
 サンプル名 : nsn389rac
 サンプルID : nsn389rac
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3 : 2
 注入量 : 1 uL
 データファイル : nsn389rac.lcd
 メソッドファイル : product.lcm

 レポートファイル : Default.lcr
 分析日時 : 2014/07/28 13:07:28
 解析日時 : 2018/07/08 14:17:46

<クロマトグラム>




1 PDA Multi 1/220nm 4nm


ピークテーブル D:\Nishino*nsn389rac.lcd

| PDA Ch1 220nm 4nm | | | | | |
|-------------------|--------|---------|--------|---------|---------|
| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
| 1 | 18.354 | 4506665 | 149506 | 48.675 | 51.404 |
| 2 | 20.016 | 4751977 | 141338 | 51.325 | 48.596 |
| Total | | 9258641 | 290844 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height




E:\personal folder\Nishino\Compounds\nsn424p-1.als
nsn424p



3ag 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn424pc-1.als
nsn424pc



3ag 13C NMR

Sample Name : nsn448rac(for581)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 9.383 | 3670882 | 281722 | 49.859 |
| 2 | 13.778 | 3691604 | 182372 | 50.141 |

3ag racemic





E:\personal folder\Nishino\Compounds\nsn453p-1.als
nsn453p



3ah ^1H NMR

S-39


D:\Documents and Settings\Kobayashilab\Desktop\msn453pc-1.als
msn453pc



3ah 13C NMR

S-40

Sample Name : nsn454rac(for582)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 22.302 | 9517617 | 265377 | 49.852 |
| 2 | 36.590 | 9574089 | 159917 | 50.148 |


3ah racemic




E:\personal folder\Nishino\Compounds\nsn354p-1.als
nsn354p(mpOMeOMe)



3ba 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn354pc-1.als
nsn354pc(mpOMeOMe)



3ba 13C NMR

Sample Name : nsn364rac(for562)
OD-H, 1.0 mL/min, Hex:IPA = 1/1




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 24.416 | 7440327 | 166596 | 49.929 |
| 2 | 53.203 | 7461443 | 74852 | 50.071 |

3ba racemic





E:\personal folder\Nishino\Compounds\nsn383p-1.als
nsn383p



3ea ¹H NMR


S-45

D:\Documents and Settings\Kobayashilab\Desktop\nsn383pc-1.als
nsn383pc



3ea 13C NMR

Sample Name : nsn390rac(for566)
OD-H, 1.0 mL/min, Hex:IPA = 3/2





1 PDA Multi 1/220nm 4nm

PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|----------|--------|--------|
| 1 | 27.160 | 15333372 | 324629 | 49.907 |
| 2 | 56.506 | 15390255 | 149693 | 50.093 |



3ea racemic

E:\personal folder\Nishino\Compounds\nsn366p-1.als
nsn366p




3fb 1H NMR

D:\Documents and Settings\Kobayashilab\Desktop\nsn366pc-1.als
nsn366pc




3fb 13C NMR

Sample Name : nsn563
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|----------|---------|--------|
| 1 | 22.036 | 39063611 | 1050953 | 93.983 |
| 2 | 31.606 | 2500839 | 49153 | 6.017 |




E:\personal folder\Nishino\Compounds\nsn367p-1.als
nsn367p




3fa 1H NMR



D:\Documents and Settings\Kobayashilab\Desktop\nsn367pc2-1.als
nsn367pc2



Sample Name : nsn370rac(for564)
OD-H, 1.0 mL/min, Hex:IPA = 1/1




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|--------|--------|--------|
| 1 | 30.309 | 544229 | 9578 | 50.083 |
| 2 | 76.021 | 542421 | 3660 | 49.917 |

3fa racemic




E:\personal folder\Nishino\Compounds\nsn386p-1.als
nsn386p




3gb ¹H NMR

S-54




D:\Documents and Settings\Kobayashilab\Desktop\nsn386pc-1.als
nsn386pc



3gb ¹³C NMR

Sample Name : nsn401rac(for567and583)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm

PDA Ch1 220nm 4nm


| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 12.651 | 1777954 | 97729 | 49.742 |
| 2 | 22.837 | 1796402 | 53828 | 50.258 |


3gb racemic




3ga 1H NMR

E:\personal folder\Nishino\Compounds\nsn387p-1.als
nsn387p






D:\Documents and Settings\Kobayashilab\Desktop\nsn387pc-1.als
nsn387pc



3ga 13C NMR

Sample Name : nsn379(for568)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 24.180 | 2332232 | 57750 | 50.050 |
| 2 | 73.027 | 2327608 | 18250 | 49.950 |


3ga racemic




E:\personal folder\Nishino\Compounds\nsn396p.als
nsn396p



3hb 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn396pc.als
nsn396pc



3hb ¹³C NMR



Sample Name : nsn399rac(for569)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 9.984 | 3024378 | 220004 | 50.083 |
| 2 | 18.797 | 3014361 | 110705 | 49.917 |

3hb racemic


E:\personal folder\Nishino\Compounds\nsn397p.als
nsn397p



3ha 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn397pc2-1.als
nsn397pc2



3ha 13C NMR

Sample Name : nsn400rac(for570)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 13.865 | 9261027 | 446039 | 49.872 |
| 2 | 40.092 | 9308628 | 142390 | 50.128 |


3ha racemic




E:\personal folder\Nishino\Compounds\nsn411p-1.als
nsn411p



3ib 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn411pc-1.als
nsn411pc



3ib 13C NMR

Sample Name : nsn413rac(for571)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 13.584 | 6011473 | 317783 | 50.214 |
| 2 | 25.503 | 5960319 | 162043 | 49.786 |


3ib racemic




E:\personal folder\Nishino\Compounds\nsn412p-1.als
nsn412p



3ia 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn412pc-1.als
nsn412pc



3ia 13C NMR

Sample Name : nsn414rac(for572)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 18.934 | 6259445 | 215657 | 49.941 |
| 2 | 63.886 | 6274312 | 59180 | 50.059 |


3ia racemic




E:\personal folder\Nishino\Compounds\nsn409p-1.a1s
nsn409



3jb 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn409pc-1.als
nsn409pc



3jb 13C NMR

Sample Name : nsn415rac(for574)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 5.386 | 6314881 | 896462 | 49.517 |
| 2 | 7.136 | 6438185 | 655779 | 50.483 |



3jb racemic



3ja 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn410pc-1.als
nsn410pc



3ja 13C NMR

Sample Name : nsn431rac(for575)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|----------|---------|--------|
| 1 | 7.008 | 10797847 | 1033510 | 49.223 |
| 2 | 14.370 | 11138806 | 439921 | 50.777 |


3ja racemic




E:\personal folder\Nishino\Compounds\nsn417p-1.als
nsn417p



3kb 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn417pc-1.als
nsn417pc



3kb 13C NMR

Sample Name : nsn419rac(for576)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 5.391 | 4048959 | 614476 | 49.760 |
| 2 | 7.000 | 4088006 | 460129 | 50.240 |


3kb racemic




E:\personal folder\Nishino\Compounds\nsn418p-1.als
nsn418p



3ka 1H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn418pc-1.als
nsn418pc



3ka 13C NMR

Sample Name : nsn420rac(for577)
OD-H, 1.0 mL/min, Hex:IPA = 3/2




1 PDA Multi 1/220nm 4nm


PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 6.605 | 4676319 | 534198 | 49.932 |
| 2 | 12.566 | 4689130 | 258808 | 50.068 |


3ka racemic




E:\personal folder\Nishino\Compounds\nsn445p2-1.als
nsn445p2



31b ¹H NMR




D:\Documents and Settings\Kobayashilab\Desktop\nsn445p2c-1.als
nsn445p2c



31b ¹³C NMR


Sample Name : nsn445rac(for578)
OD-H, 1.0 mL/min, Hex:IPA = 99/1




1 PDA Multi 1/220nm 4nm


| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|---------|--------|--------|
| 1 | 15.559 | 1358783 | 71611 | 50.041 |
| 2 | 28.722 | 1356550 | 37948 | 49.959 |

3lb racemic




3la 1H NMR






D:\Documents and Settings\Kobayashilab\Desktop\nsn444pv-1.als
nsn444pc



3la ¹³C NMR

Sample Name : nsn446rac(for579)
OD-H, 1.0 mL/min, Hex:IPA = 99/1



1 PDA Multi 1/220nm 4nm

PDA Ch1 220nm 4nm

| Peak# | Ret. Time | Area | Height | Area% |
|-------|-----------|----------|--------|--------|
| 1 | 33.185 | 14860401 | 323933 | 49.865 |
| 2 | 93.302 | 14940705 | 102968 | 50.135 |

3la racemic

HPLC Table 3 entry 1


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn586.lcd

分析者 : System Administrator
 サンプル名 : nsn586
 サンプルID : nsn586
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 uL
 データファイル : nsn586.lcd
 メソッドファイル : product.lcm

 レポートファイル : Default.lcr
 分析日時 : 2015/01/26 14:44:28
 解析日時 : 2015/01/26 18:34:51

<クロマトグラム>



ピークテーブル D:\Nishino*nsn586.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 31.409 | 43637262 | 733400 | 95.042 | 97.189 |
| 2 | 60.023 | 2276208 | 21213 | 4.958 | 2.811 |
| Total | | 45913470 | 754613 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height


HPLC Table 3 entry 2

==== Shimadzu LcSolution 分析レポート ====

D:\Nishino*nsn588.lcd

分析者 : System Administrator
 サンプル名 : nsn588
 サンプルID : nsn588
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn588.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/26 18:36:27
 解析日時 : 2015/01/26 20:00:06

<クロマトグラム>



ピークテーブル D:\Nishino*nsn588.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 19.405 | 1284425 | 40682 | 8.166 | 10.227 |
| 2 | 24.213 | 14444805 | 357097 | 91.834 | 89.773 |
| Total | | 15729229 | 397779 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 3


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn580.lcd

分析者 : System Administrator
 サンプル名 : nsn580
 サンプルID : nsn580
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn580.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/19 11:21:48
 解析日時 : 2015/01/22 11:45:08

<クロマトグラム>



ピークテーブル D:\Nishino*nsn580.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 17.172 | 1414175 | 52857 | 2.894 | 4.978 |
| 2 | 27.721 | 47446140 | 1009054 | 97.106 | 95.022 |
| Total | | 48860315 | 1061911 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 4

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn583.lcd
 分析者 : System Administrator
 サンプル名 : nsn583
 サンプルID : nsn583
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn583.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/19 13:03:16
 解析日時 : 2015/01/22 11:46:30

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino\msn583.lcd

PDA Ch1 220nm 4nm

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 12.202 | 585173 | 33263 | 3.057 | 5.926 |
| 2 | 22.170 | 18557760 | 528086 | 96.943 | 94.074 |
| Total | | 19142933 | 561349 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 5

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn573.lcd
 分析者 : System Administrator
 サンプル名 : nsn573
 サンプルID : nsn573
 測定条件 :OD-H, 1.0 mL/min, Hex:IPA = 9/1
 注入量 : 1 uL
 データファイル : nsn573.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/24 9:50:56
 解析日時 : 2015/01/24 11:39:40

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn573.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 73.157 | 5026848 | 58687 | 7.250 | 8.328 |
| 2 | 78.126 | 64304459 | 646034 | 92.750 | 91.672 |
| Total | | 69331307 | 704721 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 6


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\%nsn581.lcd

分析者 : System Administrator
 サンプル名 : nsn581
 サンプルID : nsn581
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn581.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/19 14:30:32
 解析日時 : 2015/01/22 11:47:27

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino\%nsn581.lcd

| PDA Ch1 220nm 4nm | | | | | |
|-------------------|--------|----------|---------|---------|---------|
| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
| 1 | 9.719 | 62927 | 4498 | 0.209 | 0.357 |
| 2 | 14.351 | 30083866 | 1254794 | 99.791 | 99.643 |
| Total | | 30146792 | 1259292 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 7


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn582.lcd

分析者 : System Administrator
 サンプル名 : nsn582
 サンプルID : nsn582
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn582.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/20 16:10:30
 解析日時 : 2015/01/22 11:49:20

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn582.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 21.083 | 122173 | 3786 | 0.482 | 0.851 |
| 2 | 34.256 | 25224779 | 440914 | 99.518 | 99.149 |
| Total | | 25346951 | 444700 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 8

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn589.lcd
 分析者 : System Administrator
 サンプル名 : nsn589
 サンプルID : nsn589
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 uL
 データファイル : nsn589.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/26 11:57:23
 解析日時 : 2015/01/26 18:34:09

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn589.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 30.346 | 1383847 | 26852 | 4.206 | 9.859 |
| 2 | 60.422 | 31520135 | 245508 | 95.794 | 90.141 |
| Total | | 32903982 | 272360 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 9


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn560.lcd

分析者 : System Administrator
 サンプル名 : nsn560
 サンプルID : nsn560
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn560.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/14 18:44:11
 解析日時 : 2015/01/14 21:21:28

<クロマトグラム>



ピークテーブル D:\Nishino*nsn560.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 19.685 | 47583930 | 1441848 | 97.118 | 97.539 |
| 2 | 24.186 | 1411862 | 36373 | 2.882 | 2.461 |
| Total | | 48995792 | 1478221 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 10


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn562.lcd

分析者 : System Administrator
 サンプル名 : nsn562
 サンプルID : nsn562
 測定条件 :OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 uL
 データファイル : nsn562.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/13 11:42:34
 解析日時 : 2015/01/13 16:38:05

<クロマトグラム>



ピークテーブル D:\Nishino*nsn562.lcd


| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 23.884 | 36911877 | 835648 | 97.514 | 98.831 |
| 2 | 51.665 | 941036 | 9888 | 2.486 | 1.169 |
| Total | | 37852913 | 845536 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 11
 ===== Shimadzu LCsolution 分析レポート =====

D:\Nishino*nsn565.lcd
 分析者 : System Administrator
 サンプル名 : nsn565
 サンプルID : nsn565
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 9/1
 注入量 : 1 uL
 データファイル : nsn565.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/23 18:45:04
 解析日時 : 2015/01/24 11:39:21

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn565.lcd


| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 66.626 | 78170045 | 928085 | 95.744 | 95.747 |
| 2 | 70.863 | 3474542 | 41223 | 4.256 | 4.253 |
| Total | | 81644587 | 969308 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 12
 === Shimadzu LCsolution 分析レポート ===

D:\Nishino*nsn566.lcd
 分析者 : System Administrator
 サンプル名 : nsn566
 サンプルID : nsn566
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn566.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/15 13:29:16
 解析日時 : 2015/01/15 18:27:55

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn566.lcd

PDA Ch1 220nm 4nm

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 27.462 | 55666063 | 1089375 | 96.483 | 98.203 |
| 2 | 56.899 | 2029285 | 19936 | 3.517 | 1.797 |
| Total | | 57695348 | 1109311 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 13


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn563.lcd

分析者 : System Administrator
 サンプル名 : nsn563
 サンプルID : nsn563
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn563.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/14 20:04:13
 解析日時 : 2015/01/14 21:22:58

<クロマトグラム>



ピークテーブル D:\Nishino*nsn563.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 22.036 | 39063611 | 1050953 | 93.983 | 95.532 |
| 2 | 31.606 | 2500839 | 49153 | 6.017 | 4.468 |
| Total | | 41564451 | 1100106 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 14


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn564.lcd

分析者 : System Administrator
 サンプル名 : nsn564
 サンプルID : nsn564
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 μ L
 データファイル : nsn564.lcd
 メソッドファイル : product.lcm

 レポートファイル : Default.lcr
 分析日時 : 2015/01/13 16:36:02
 解析日時 : 2015/01/14 8:53:54

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn564.lcd

PDA Ch1 220nm 4nm

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 30.392 | 64373906 | 1091851 | 94.927 | 97.879 |
| 2 | 76.222 | 3439890 | 23659 | 5.073 | 2.121 |
| Total | | 67813796 | 1115510 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 15

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn567.lcd
 分析者 : System Administrator
 サンプル名 : nsn567
 サンプルID : nsn567
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn567.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/19 12:32:06
 解析日時 : 2015/01/22 11:46:10

<クロマトグラム>



ピークテーブル D:\Nishino*nsn567.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 12.097 | 25708740 | 1296970 | 94.571 | 96.677 |
| 2 | 21.977 | 1475761 | 44576 | 5.429 | 3.323 |
| Total | | 27184502 | 1341546 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 16

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn568.lcd
 分析者 : System Administrator
 サンプル名 : nsn568
 サンプルID : nsn568
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn568.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/15 10:58:55
 解析日時 : 2015/01/15 18:34:35

<クロマトグラム>



ピークテーブル D:\Nishino\msn568.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 24.143 | 27240837 | 652299 | 95.734 | 98.488 |
| 2 | 71.480 | 1213859 | 10016 | 4.266 | 1.512 |
| Total | | 28454696 | 662314 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 17

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn569.lcd
 分析者 : System Administrator
 サンプル名 : nsn569
 サンプルID : nsn569
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn569.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/15 15:09:14
 解析日時 : 2015/01/15 18:31:50

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn569.lcd

PDA Ch1 220nm 4nm

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 9.614 | 16246798 | 1200320 | 96.815 | 98.240 |
| 2 | 17.778 | 534475 | 21506 | 3.185 | 1.760 |
| Total | | 16781272 | 1221826 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 18

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn570.lcd
 分析者 : System Administrator
 サンプル名 : nsn570
 サンプルID : nsn570
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn570.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/15 17:15:50
 解析日時 : 2015/01/15 18:32:38

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn570.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 14.032 | 19817489 | 919554 | 97.250 | 99.005 |
| 2 | 39.380 | 560436 | 9240 | 2.750 | 0.995 |
| Total | | 20377925 | 928793 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height


HPLC Table 3 entry 19

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\Nsn571.lcd

分析者 : System Administrator
 サンプル名 : nsn571
 サンプルID : nsn571
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn571.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/16 10:55:20
 解析日時 : 2015/01/19 9:27:35

<クロマトグラム>



ピークテーブル D:\Nishino\Nsn571.lcd

| PDA Ch1 220nm 4nm | | | | | |
|-------------------|--------|----------|---------|---------|---------|
| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
| 1 | 13.329 | 23336209 | 1197206 | 96.579 | 98.122 |
| 2 | 25.040 | 826508 | 22916 | 3.421 | 1.878 |
| Total | | 24162717 | 1220123 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height


HPLC Table 3 entry 20
 ===== Shimadzu LCsolution 分析レポート =====

D:\Nishino*nsn572.lcd

分析者 : System Administrator
 サンプル名 : nsn572
 サンプルID : nsn572
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn572.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/16 12:58:37
 解析日時 : 2015/01/19 9:28:12

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn572.lcd


| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 19.173 | 39354747 | 1294702 | 98.812 | 98.947 |
| 2 | 60.999 | 1295811 | 13780 | 3.188 | 1.053 |
| Total | | 40650558 | 1308482 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 21
 ==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn574.lcd
 分析者 : System Administrator
 サンプル名 : nsn574
 サンプルID : nsn574
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn574.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/16 14:50:20
 解析日時 : 2015/01/19 9:29:25

<クロマトグラム>



ピークテーブル D:\Nishino*nsn574.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|-------|---------|---------|---------|---------|
| 1 | 5.397 | 7976508 | 1070782 | 95.055 | 96.162 |
| 2 | 7.171 | 414959 | 42734 | 4.945 | 3.838 |
| Total | | 8391468 | 1113516 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 22


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn575.lcd

分析者 : System Administrator
 サンプル名 : nsn575
 サンプルID : nsn575
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn575.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/15 18:23:50
 解析日時 : 2015/01/15 18:49:47

<クロマトグラム>



ピークテーブル D:\Nishino*nsn575.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 7.091 | 18118541 | 1564103 | 95.443 | 97.783 |
| 2 | 14.379 | 865087 | 35471 | 4.557 | 2.217 |
| Total | | 18983627 | 1599573 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 23


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn576.lcd

分析者 : System Administrator
 サンプル名 : nsn576
 サンプルID : nsn576
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn576.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/01/16 15:54:31
 解析日時 : 2015/01/19 9:30:19

<クロマトグラム>



ピークテーブル D:\Nishino*nsn576.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|-------|---------|---------|---------|---------|
| 1 | 5.380 | 8315193 | 1262757 | 94.919 | 95.923 |
| 2 | 6.990 | 445133 | 53671 | 5.081 | 4.077 |
| Total | | 8760326 | 1316428 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height


HPLC Table 3 entry 24

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn577.lcd

分析者 : System Administrator
 サンプル名 : nsn577
 サンプルID : nsn577
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 3/2
 注入量 : 1 uL
 データファイル : nsn577.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/16 17:46:45
 解析日時 : 2015/01/19 9:31:02

<クロマトグラム>



ピークテーブル D:\Nishino*nsn577.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 6.619 | 15141597 | 1550805 | 95.617 | 97.579 |
| 2 | 12.531 | 694025 | 38476 | 4.383 | 2.421 |
| Total | | 15835622 | 1589281 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 25

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn578.lcd
 分析者 : System Administrator
 サンプル名 : nsn578
 サンプルID : nsn578
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 99/1
 注入量 : 1 uL
 データファイル : nsn578.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/22 13:33:18
 解析日時 : 2015/01/22 17:32:45

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino\msn578.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|---------|--------|---------|---------|
| 1 | 15.250 | 5819057 | 299671 | 91.783 | 95.264 |
| 2 | 27.940 | 520963 | 14897 | 8.217 | 4.736 |
| Total | | 6340020 | 314568 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 3 entry 26

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn579.lcd
 分析者 : System Administrator
 サンプル名 : nsn579
 サンプルID : nsn579
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 99/1
 注入量 : 1 uL
 データファイル : nsn579.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/01/22 16:09:20
 解析日時 : 2015/01/22 18:53:40

<クロマトグラム>



ピークテーブル D:\Nishino\msn579.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 32.824 | 11742360 | 264591 | 92.835 | 97.183 |
| 2 | 90.878 | 906261 | 7671 | 7.165 | 2.817 |
| Total | | 12648621 | 272262 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 1


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn620.lcd

分析者 : System Administrator
 サンプル名 : nsn620
 サンプルID : nsn620
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 1 / 1
 注入量 : 1 uL
 データファイル : nsn620.lcd
 メソッドファイル : product.lcm

 レポートファイル : Default.lcr
 分析日時 : 2015/02/23 15:41:04
 解析日時 : 2018/07/07 17:41:45

<クロマトグラム>



ピークテーブル D:\Nishino*nsn620.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 32.722 | 27731506 | 468585 | 95.874 | 97.742 |
| 2 | 62.989 | 1193513 | 10826 | 4.126 | 2.258 |
| Total | | 28925018 | 479411 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 2

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn679.lcd
 分析者 : System Administrator
 サンプル名 : nsn679
 サンプルID : nsn679
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn679.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/05/19 10:21:34
 解析日時 : 2015/05/20 8:13:31

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn679.lcd


| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 18.588 | 2787721 | 93608 | 8.137 | 9.908 |
| 2 | 22.552 | 31472314 | 851146 | 91.863 | 90.092 |
| Total | | 34260035 | 944753 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 3
 ===== Shimadzu LCsolution 分析レポート =====

D:\Nishino*nsn681.lcd
 分析者 : System Administrator
 サンプル名 : nsn681
 サンプルID : nsn681
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn681.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/05/19 14:33:50
 解析日時 : 2015/05/20 8:16:57

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn681.lcd

PDA Ch1 220nm 4nm

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 17.036 | 1228835 | 46053 | 2.678 | 4.373 |
| 2 | 27.001 | 44652613 | 1007096 | 97.322 | 95.627 |
| Total | | 45881448 | 1053150 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 4


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn680.lcd

分析者 : System Administrator
 サンプル名 : nsn680
 サンプルID : nsn680
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn680.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/05/19 11:15:11
 解析日時 : 2015/05/20 8:24:34

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino*nsn680.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 12.737 | 659991 | 36272 | 2.855 | 5.709 |
| 2 | 23.473 | 22460303 | 599043 | 97.145 | 94.291 |
| Total | | 23120294 | 635314 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 5


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn682.lcd

分析者 : System Administrator
 サンプル名 : nsn682
 サンプルID : nsn682
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn682.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/05/19 15:54:10
 解析日時 : 2015/05/20 8:18:18

<クロマトグラム>



ピークテーブル D:\Nishino*nsn682.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 19.195 | 3054088 | 100621 | 7.300 | 8.335 |
| 2 | 20.858 | 38784218 | 1106633 | 92.700 | 91.665 |
| Total | | 41838306 | 1207254 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 6

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn703.lcd
 分析者 : System Administrator
 サンプル名 : nsn703
 サンプルID : nsn703
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn703.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/05/23 13:32:30
 解析日時 : 2018/07/07 17:47:47

<クロマトグラム>



ピークテーブル D:\Nishino\msn703.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 10.600 | 92466 | 6330 | 0.520 | 0.911 |
| 2 | 15.918 | 17683292 | 688482 | 99.480 | 99.089 |
| Total | | 17775758 | 694812 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 7

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\nsn711.lcd
 分析者 : System Administrator
 サンプル名 : nsn711
 サンプルID : nsn711
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn711.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/05/23 14:52:36
 解析日時 : 2015/05/27 8:34:56

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino\nsn711.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 22.421 | 119037 | 3471 | 0.623 | 1.092 |
| 2 | 36.407 | 18985218 | 314448 | 99.377 | 98.908 |
| Total | | 19104255 | 317920 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 8

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn647.lcd
 分析者 : System Administrator
 サンプル名 : nsn647
 サンプルID : nsn647
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 uL
 データファイル : nsn647.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/04/01 15:28:32
 解析日時 : 2015/04/01 19:35:12

<クロマトグラム>



ピークテーブル D:\Nishino\msn647.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 25.020 | 1189884 | 28629 | 4.084 | 8.815 |
| 2 | 47.938 | 27946386 | 296143 | 95.916 | 91.185 |
| Total | | 29136270 | 324773 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 9


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino\msn646.lcd

分析者 : System Administrator
 サンプル名 : nsn646
 サンプルID : nsn646
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn646.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/04/07 14:24:40
 解析日時 : 2015/04/07 19:22:09

<クロマトグラム>



ピークテーブル D:\Nishino\msn646.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 17.279 | 28757564 | 1061989 | 97.242 | 97.641 |
| 2 | 20.937 | 815648 | 25659 | 2.758 | 2.359 |
| Total | | 29573213 | 1087647 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 10


==== Shimadzu LGSolution 分析レポート ====

D:\Nishino\msn653.lcd

分析者 : System Administrator
 サンプル名 : nsn653
 サンプルID : nsn653
 測定条件 :OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 uL
 データファイル : nsn653.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/04/01 16:37:57
 解析日時 : 2015/04/01 19:35:26

<クロマトグラム>



ピークテーブル D:\Nishino\msn653.lcd


| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 21.510 | 46372457 | 1204734 | 97.489 | 98.733 |
| 2 | 43.619 | 1194448 | 15465 | 2.511 | 1.267 |
| Total | | 47566905 | 1220198 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 11
 ===== Shimadzu LCsolution 分析レポート =====

D:\Nishino\msn664.lcd
 分析者 : System Administrator
 サンプル名 : nsn664
 サンプルID : nsn664
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn664.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/05/18 15:40:00
 解析日時 : 2015/05/20 8:11:37

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:\Nishino\msn664.lcd


| PDA Ch1 220nm 4nm | | | | | |
|-------------------|--------|----------|--------|---------|---------|
| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
| 1 | 29.110 | 44842563 | 851629 | 96.597 | 98.221 |
| 2 | 59.435 | 1579681 | 15422 | 3.403 | 1.779 |
| Total | | 46422243 | 867051 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 12
 ===== Shimadzu LCsolution 分析レポート =====

D:\Nishino\msn649.lcd
 分析者 : System Administrator
 サンプル名 : nsn649
 サンプルID : nsn649
 測定条件 : OD-H, 0.7mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn649.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/04/07 12:32:48
 解析日時 : 2015/04/07 19:22:00

<クロマトグラム>



ピークテーブル D:\Nishino\msn649.lcd

| PDA Ch1 220nm 4nm | | | | | |
|-------------------|--------|----------|---------|---------|---------|
| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
| 1 | 28.725 | 53931359 | 1276409 | 94.187 | 95.559 |
| 2 | 40.444 | 3328610 | 59315 | 5.813 | 4.441 |
| Total | | 57259969 | 1335724 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 13


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn655.lcd

分析者 : System Administrator
 サンプル名 : nsn655
 サンプルID : nsn655
 測定条件 : OD-H, 1.0 mL/min, Hex:IPA = 1/1
 注入量 : 1 uL
 データファイル : nsn655.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/04/01 18:18:46
 解析日時 : 2015/04/01 19:35:37

<クロマトグラム>



ピークテーブル D:\Nishino*nsn655.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|--------|---------|---------|
| 1 | 25.452 | 45787805 | 966286 | 95.131 | 97.862 |
| 2 | 60.120 | 2343679 | 21114 | 4.869 | 2.138 |
| Total | | 48131484 | 987399 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 14

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn648.lcd
 分析者 : System Administrator
 サンプル名 : nsn648
 サンプルID : nsn648
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn648.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lor
 分析日時 : 2015/04/07 15:29:21
 解析日時 : 2015/04/07 19:22:26

<クロマトグラム>



ピークテーブル D:\Nishino*nsn648.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 12.035 | 21137616 | 1101097 | 94.881 | 96.949 |
| 2 | 22.165 | 1140398 | 34648 | 5.119 | 3.051 |
| Total | | 22278014 | 1135744 | 100.000 | 100.000 |


ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 15

==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn656.lcd
 分析者 : System Administrator
 サンプル名 : nsn656
 サンプルID : nsn656
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn656.lcd
 メソッドファイル : product.lcm
 レポートファイル : Default.lcr
 分析日時 : 2015/04/07 16:23:20
 解析日時 : 2015/04/07 19:22:39

<クロマトグラム>



ピークテーブル D:\Nishino*nsn656.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 20.486 | 45629705 | 1251814 | 95.668 | 98.289 |
| 2 | 57.935 | 2066430 | 21790 | 4.332 | 1.711 |
| Total | | 47696135 | 1273604 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 16


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn702.lcd

分析者 : System Administrator
 サンプル名 : nsn702
 サンプルID : nsn702
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn702.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/05/22 17:29:52
 解析日時 : 2015/05/27 8:31:12

<クロマトグラム>



ピークテーブル D:\Nishino*nsn702.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 14.708 | 36534446 | 1484737 | 97.043 | 98.909 |
| 2 | 42.727 | 1113117 | 16371 | 2.957 | 1.091 |
| Total | | 37647563 | 1501108 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 17


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn698.lcd

分析者 : System Administrator
 サンプル名 : nsn698
 サンプルID : nsn698
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn698.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/05/20 17:27:50
 解析日時 : 2015/05/21 15:15:34

<クロマトグラム>



ピークテーブル D:\Nishino*nsn698.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 18.344 | 40796856 | 1395739 | 96.770 | 98.958 |
| 2 | 59.573 | 1361528 | 14702 | 3.230 | 1.042 |
| Total | | 42158384 | 1410441 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 18


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn726.lcd

分析者 : System Administrator
 サンプル名 : nsn726
 サンプルID : nsn726
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn726.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/06/13 16:28:39
 解析日時 : 2015/06/16 18:31:14

<クロマトグラム>



ピークテーブル D:\Nishino*nsn726.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 6.753 | 17963571 | 1646794 | 95.654 | 97.675 |
| 2 | 13.158 | 816074 | 39200 | 4.346 | 2.325 |
| Total | | 18779645 | 1685994 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 19


==== Shimadzu LCsolution 分析レポート ====

D:*Nishino*nsn751.lcd

分析者 : System Administrator
 サンプル名 : nsn751
 サンプルID : nsn751
 測定条件 :OD-H, 1.0mL/min, Hex:IPA =3/2
 注入量 : 1 uL
 データファイル : nsn751.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lor
 分析日時 : 2015/07/09 16:27:45
 解析日時 : 2015/07/09 17:43:23

<クロマトグラム>



1 PDA Multi 1/220nm 4nm

ピークテーブル D:*Nishino*nsn751.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|----------|---------|---------|---------|
| 1 | 7.025 | 18135858 | 1667997 | 95.244 | 97.464 |
| 2 | 14.042 | 905519 | 43406 | 4.756 | 2.536 |
| Total | | 19041376 | 1711403 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

HPLC Table 9 entry 20


==== Shimadzu LCsolution 分析レポート ====

D:\Nishino*nsn731.lcd

分析者 : System Administrator
 サンプル名 : nsn731
 サンプルID : nsn731
 測定条件 : OD-H, 1.0mL/min, Hex:IPA =99/1
 注入量 : 1 uL
 データファイル : nsn731.lcd
 メソッドファイル : product.lcm

レポートファイル : Default.lcr
 分析日時 : 2015/06/15 11:07:00
 解析日時 : 2015/06/16 18:32:27

<クロマトグラム>



ピークテーブル D:\Nishino*nsn731.lcd

| ピーク# | 保持時間 | 面積 | 高さ | 面積% | 高さ% |
|-------|--------|---------|--------|---------|---------|
| 1 | 32.635 | 7489747 | 178132 | 92.728 | 96.816 |
| 2 | 81.361 | 587349 | 5858 | 7.272 | 3.184 |
| Total | | 8077096 | 183990 | 100.000 | 100.000 |

ピーク : peak 保持時間:retention time 面積:area 高さ:height

9. References

- ¹ Brown, H. C.; Mead, E. J.; Rao, B. C. S. *J. Am. Chem. Soc.* **1955**, *77*, 6209.
- ² (a) Okamoto, K.; Hayashi, T.; Rawal, V. H. *Chem. Commun.* **2009**, 4815; (b) Okamoto, K.; Hayashi, T.; Rawal, V. H. *Org. Lett.* **2008**, *10*, 4387.
- ³ Yasukawa, T.; Miyamura, H.; Kobayashi, S. *J. Am. Chem. Soc.* **2012**, *134*, 16963.
- ⁴ Bowman, R. K.; Johnson, J. S., *The Journal of Organic Chemistry* **2004**, *69*, 8537.
- ⁵ Lin, L.; Yin, W.; Fu, X.; Zhang, J.; Ma, X.; Wang, R., *Organic & Biomolecular Chemistry* **2012**, *10*, 83.
- ⁶ Kiyokawa, K.; Nagata, T.; Hayakawa, J.; Minakata, S., *Chemistry – A European Journal* **2015**, *21*, 1280.
- ⁷ Chandrasekhar, S.; Shrinidhi, A., *Synthetic Communications* **2014**, *44*, 3008.
- ⁸ Antoft-Finch, A.; Blackburn, T.; Snieckus, V., *J Am Chem Soc* **2009**, *131*, 17750.
- ⁹ Gao, J.-R.; Wu, H.; Xiang, B.; Yu, W.-B.; Han, L.; Jia, Y.-X., *J Am Chem Soc* **2013**, *135*, 2983.
- ¹⁰ Xing, J.; Chen, G.; Cao, P.; Liao, J., *European Journal of Organic Chemistry* **2012**, 1230.