

Supporting Information

Effect of Glycine Functionalization of 2D Titanium Carbide (MXene) on Charge Storage

Chi Chen,^{a,b} Muhammad Boota,^a Patrick Urbankowski,^a Babak Anasori,^a Ling Miao,^b Jianjun Jiang,^{*b} Yury Gogotsi^{*a}

a. A.J. Drexel Nanomaterials Institute, and Materials Science and Engineering Department, Drexel University, 3141 Chestnut Street, Philadelphia, PA 19104, USA.

b. School of Optical and Electronic Information, Huazhong University of Science and Technology, Wuhan, Hubei 430074, People's Republic of China.

Characterizations.

XRD patterns of the samples were obtained using a Rigaku Smart Lab (Tokyo, Japan) with a Cu K α radiation source ($\lambda = 1.5406 \text{ \AA}$).

The Raman spectra were recorded on Renishaw inVia spectrometer with a 632 nm laser as an excitation source (5% laser power).

The Fourier transform infrared (FTIR) spectra were collected by an ATR-FTIR spectrometer with a resolution of 4 cm⁻¹.

Cross-sectional images of d-Ti₃C₂T_x/glycine were obtained by using scanning electron microscopy (SEM, Zeiss Supra 50VP, Germany).

X-ray photoelectron (XPS) spectra were measured by a spectrometer (Physical Electronics, VersaProbe 5000, Chanhassen, MN) employing a monochromatic 100 μm Al K α X-ray beam to irradiate the surface of the sample. Photoelectrons were collected by a 180° takeoff angle between the sample surface and the path to the analyzer. Charge neutralization was performed using a dual-beam charge neutralizer irradiating low-energy electrons and an ion beam to avoid shift in the recorded binding energy. High-resolution spectra were taken at a pass energy of 11.75 eV with a step size of 0.05 eV. The binding energy scale of all XPS spectra was referred to the Fermi-edge (E_F), which was set to a binding energy of zero eV. The powders were placed on a double-sided

tape. The quantification using the obtained core-level intensities and peak fitting of the core-level spectra was performed using a software package (CasaXPS Version 2.3.16 RP 1.6).

Electrochemical tests

All electrochemical measurements were performed in a 3-electrode configuration. As-prepared d-Ti₃C₂T_x/amino acid freestanding films with a thickness of ~4 μm served as a working electrode, over-capacitive activated carbon film was used as a counter electrode, glassy carbon electrodes were used as current collectors and Ag/AgCl served as a reference electrode. Activated carbon electrodes composition was 90 wt. % of YP-50 activated carbon (Kuraray, Japan), 5 wt. % of carbon black and 5 wt. % of polytetrafluoroethylene.

Calculations of capacitance of electrode

$$C = (\int j dV)/(s V) \text{ [F g}^{-1}\text{]}$$

where C is gravimetric capacitance of electrode [F g⁻¹], j is current density [A g⁻¹], s is scan rate [V/s], V is voltage window [V].




Figure S1 Top views of the adsorption configurations




Figure S2 Thermogravimetric analysis of pristine $\text{Ti}_3\text{C}_2\text{T}_x$ and $\text{Ti}_3\text{C}_2\text{T}_x/\text{glycine}$ hybrid samples. We set 450 °C as the cut-off temperature, as oxidation of $\text{Ti}_3\text{C}_2\text{T}_x$ beyond this temperature leads to an increase in the sample weight. The weight loss of d- $\text{Ti}_3\text{C}_2\text{T}_x$ is due to trapped water between its layers. We used difference between the weight loss of d- $\text{Ti}_3\text{C}_2\text{T}_x/\text{glycine}$ hybrid and pristine d- $\text{Ti}_3\text{C}_2\text{T}_x$ to determine the glycine content, which is $\sim 4.65\%$, assuming the same content of water and other adsorbed species in both samples.




Figure S3 Predicted interlayer spacing for $\text{Ti}_3\text{C}_2\text{O}_2$.




Figure S4 Three possible configurations (two parallel configurations and one vertical configuration) of water intercalated $\text{Ti}_3\text{C}_2\text{O}_2$. Two parallel configurations: two hydrogen atoms of H_2O point to two different oxygen atoms of $\text{Ti}_3\text{C}_2\text{O}_2$ surface; two hydrogen atoms of H_2O point to the same oxygen atom.




Figure S5 Rate performance and capacitance retention for pristine $\text{d-Ti}_3\text{C}_2\text{T}_x$, $\text{d-Ti}_3\text{C}_2\text{T}_x/\text{glycine}$ and $\text{d-Ti}_3\text{C}_2\text{T}_x/\text{leucine}$ samples. The leucine molecule is much larger than glycine. Therefore, it occupies more reactive sites of MXene, resulting in a low capacitance.