



¹H NMR Spectrum of Stage-1




¹³CNMR Spectrum of Stage-1




Analyst:Ranjith Kumar.V

Mass spectrum of Stage-1



DSC Thermogram of Stage-1



Method Log:

- 1: Equilibrate at 50.00°C
- 2: Ramp 10.00°C/min to 200.00°C
- 3: End of method

Peak Integration

Start °C	Onset °C	Maximum °C	Stop °C	Area J/g
158.27	166.00	167.86	173.76	90.97


ELN

HPLC Chromatogram of Stage-1




Analytical Development

SAMPLE INFORMATION	
Sample Name:	0265/C01/E00502/005
Sample Type:	Unknown n
Vial:	26
Injection #:	1
Injection Volume:	10.00 ul
Sample Set Id:	1709
Sample Set Name:	300116_INT_073
Project Name:	HYD1 AD-Generics\0265 Jan 2016
Result Id:	1765 Result Set Id
Instrument Method Id:	1663
Acquired By:	divyakumarteam
Date Acquired:	1/30/2016 7:39:06 PM IST
Date Processed:	2/3/2016 8:47:17 AM IST
Processing Method:	0265_Pro
Processing Method Id:	1761
Proc. Chnl. Descr.:	W2489 ChA 245nm
System Name:	LL_AD_LC_073
Software:	Empower 3 Software Build 3471



Peak Results

	Name	RT	Area (μ Vsec)	% Area
1	Nitrobenzoic acid	3.53	13417	0.0517
2	RRT 0.556	16.53	1155	0.0045
3	C01	29.74	25898749	99.8368
4	RRT 1.142	33.96	14432	0.0556
5	RRT 1.247	37.07	10115	0.0390
6	RRT 1.344	39.96	1316	0.0051
7	RRT 1.488	44.26	1913	0.0074




SampleName 0265/C01/E00502/005

Date Acquired 1/30/2016 7:39:06 PM IST


Signature / Date:

Page: 1 of 1

¹H NMR Spectrum of Stage-2




¹³CNMR Spectrum of Stage-2




Analyst:Durga.A

Mass Spectrum of Stage-2



DSC Thermogram of Stage-2



Method Log:

- 1: Equilibrate at 50.00°C
- 2: Ramp 10.00°C/min to 200.00°C
- 3: End of method

Peak Integration

Start °C	Onset °C	Maximum °C	Stop °C	Area J/g
100.16	110.89	112.56	119.20	114.6


ELN

HPLC Chromatogram of Stage-2




Analytical Development

SAMPLE INFORMATION	
Sample Name:	0265/C02/E00541/164
Sample Type:	Unknown
Vial:	20
Injection #:	1
Injection Volume:	10.00 μ l
Run Time:	60.0 Minutes
Sample Set Name	0265_C01_60Min_160716
Sample Set ID:	3627
Project Name	HYD1_AD-Generics\0265_JULY
Result Id	3761
Method Id ****	
Acquired By:	Anjaneyulu team
Date Acquired:	07/16/2016 19:16:55 IST
Date Processed:	07/16/2016 20:52:57 IST
Processing Method	0265_PProc
Processing Method Id	3744
Proc. Chnl. Descr.:	Detector A 247nm
System Name	AL_AD_LC_39_142
Empower 3 Software Build	3471 SPs Installed:
Feature Release	2 DB ID: 2487711617



Peak Results

Name	RT	Area	% Area	RT Ratio
Peak2	21.79	4115	0.02	0.71
Peak3	24.01	6523	0.04	0.78
Peak4	28.54	979	0.01	0.93
Peak5	29.43	2587	0.02	0.96
C02	30.78	16992282	98.91	1.00
Peak6	33.40	1450	0.01	1.09
Peak7	33.75	2658	0.02	1.10
Peak8	34.46	1241	0.01	1.12
Peak9	36.90	120476	0.70	1.20
Peak10	39.60	3509	0.02	1.29
Peak11	43.24	6144	0.04	1.41
Peak12	43.95	5797	0.03	1.43
Peak13	45.96	1479	0.01	1.49
Peak14	50.08	11373	0.07	1.63
Peak15	51.59	19354	0.11	1.68




Sample Name: 0265/C02/E00541/164
Date Acquired: 07/16/2016 19:16:55 IST


Signature / Date

Page: 1 of 1


¹H NMR Spectrum of Stage-3




¹³C NMR Spectrum of Stage-3



Mass Spectrum of Stage-3



DSC Thermogram of Stage-3



Method Log:

- 1: Equilibrate at 50.00°C
- 2: Ramp 10.00°C/min to 200.00°C
- 3: End of method

Peak Integration				
Start °C	Onset °C	Maximum °C	Stop °C	Area J/g
151.74	165.10	167.48	175.46	117.3


EIN

**HPLC Chromatogram of Stage-3
(Chemical purity)**




Analytical Development

SAMPLE INFORMATION	
Sample Name:	0265/C03/E00502/169
Sample Type:	Unknown
Vial:	12
Injection #:	1
Injection Volume:	10.00 ul
Run Time:	60.0 Minutes
Sample Set Name	0265_C04_60Min_200716
Sample Set ID:	4935
Project Name	HYD1_AD-Generics\0265_JULY
Result Id	5014
Result Set Id	
Method Id ****	
Acquired By:	Anjaneyulu team
Date Acquired:	07/20/2016 11:43:07 IST
Date Processed:	07/20/2016 13:52:23 IST
Processing Method	0265_Proc17
Processing Method Id	5004
Proc. Chnl. Descr.:	Detector A 245nm
System Name	LL_AD_LC_55_176
Empower 3 Software Build	3471 SPs Installed:
Feature Release	2 DB ID: 2487711617



Peak Results

	Name	RT	Area	% Area	RT Ratio
1	Peak2	7.54	1719	0.01	0.26
2	Peak3	13.75	15152	0.09	0.47
3	Peak4	22.22	748	0.00	0.77
4	Peak5	24.30	1885	0.01	0.84
5	Peak6	26.90	3451	0.02	0.93
6	Peak7	28.40	9567	0.06	0.98
7	C03	29.00	1708079e	99.81	1.00
8	Peak8	34.65	817	0.00	1.19



Sample Name: 0265/C03/E00502/169
Date Acquired: 07/20/2016 11:43:07 IST

Signature / Date
Page: 1 of 1


HPLC Chromatogram of Stage-3 (Chiral purity)

 LAURUS Labs

SAMPLE INFORMATION


Sample Name:	0265/C03/E00502/169	Method Id ****
Sample Type:	Unknown	Acquired By: divyakumarteam
Vial:	51	Date Acquired: 07/20/2016 20:14:39 IST
Injection #:	1	Date Processed: 07/21/2016 8:42:26 IST
Injection Volume:	20.00 μ l	Processing Method 0265_C03_Rev chiral pro
Run Time:	40.0 Minutes	Processing Method Id 2682
Sample Set Name	0265_C03_chiral_75_200716	Proc. Chnl. Descr.: W2489 CHA 245nm
Sample Set ID:	2670	System Name LL_AD_LC_075
Project Name	HYD1_AD-Generics\0265_July_2	Empower 3 Software Build 3471 SPs Installed:
Result Id	2687	Feature Release 2 DB ID: 2487711617

Auto-Scaled Chromatogram



Peak Results

	Name	RT	Area	% Area	RT Ratio	USP Resolution	USP Plate Count	USP Tailing
1	Isomer	17.621	3550	0.009	0.830	=	4194.4	1.0
2	Idelalisib C03	21.239	38854856	99.991	=	2.41	1973.9	2.0



Sample Name: 0265/C03/E00502/169
Date Acquired: 07/20/2016 20:14:39 IST


Signature / Date

Page: 1 of 1

¹H NMR Spectrum of stage-4

¹H NMR of 0265-C04-E00502-066 in DMSO-D₆
Date: 10/03/2016, A.R.No:E-NMR0316/0251
(C:\Data\DATA-2016\RS-2016\Mar-2016\001/1)

LAURUS Labs




ELN Report

Analyst: Y.Sunitha

¹³CNMR Spectrum of stage-4

¹³C NMR of 0265-C04-E00502-066 in DMSO-D₆
Date: 10/03/2016, A.R.No:E-NMR0316/0259
{C:\Data\Data-2016\RS-2016\Mar-2016/002/1}
Low sample quantity


 LAURUS Labs




ELN Report

Analyst: Y.Sunitha

Mass Spectrum of stage-4



DSC Thermogram of stage-4



Method Log:

- 1: Equilibrate at 50.00°C
- 2: Ramp 10.00°C/min to 200.00°C
- 3: End of method

Peak Integration

Start °C	Onset °C	Maximum °C	Stop °C	Area J/g
118.79	131.38	141.36	151.56	62.12
159.97	162.33	167.05	173.22	2.002


ELN

HPLC Chromatogram of stage-4




Analytical Development

SAMPLE INFORMATION	
Sample Name:	0265/C04/E00502/066
Sample Type:	Unknown n
Vial:	7
Injection #:	1
Injection Volume:	10.00 ul
Run Time:	80.0 Minutes
Sample Set Name:	100316_C05
Sample Set ID:	1234
Project Name	HYD1_AD-Generic\0265_MAR_
Result Id	1337
Method Id	****
Acquired By:	Anjaneyulu team
Date Acquired:	3/10/2016 3:12:23 AM IST
Date Processed:	3/10/2016 8:57:13 AM IST
Processing Method:	0265_PRO1
Processing Method Id	1327
Proc. Chnl. Descr.:	Detector A 268nm
System Name	AL_AD_LC_32_125
Empow er 3 Software Build	3471 SPs Installed: Feature
Release 2 DB ID:	2487711617



Peak Results

	Name	RT	Area	% Area	RT Ratio
1	Peak2	21.842	2361	0.010	0.854
2	Peak3	24.840	81196	0.360	0.971
3	C04	25.573	2237864E	99.117	1.000
4	Peak4	33.118	1144	0.005	1.295
5	Peak5	35.362	20213	0.090	1.383
6	Peak6	46.946	515	0.002	1.812
7	Peak7	46.709	1828	0.008	1.827
8	Peak8	50.316	92194	0.408	1.968



Sample Name: 0265/C04/E00502/066
 Date Acquired: 3/10/2016 3:12:23 AM IST


Signature / Date

Page: 1 of 1

¹H NMR Spectrum of stage-5/ Idelalisib

1H NMR of 0265/C05/E00502/053b in DMSO-d6
Date: 07/03/2016, A.R.No: E-NMR0316/0074
{C:\Data\{Data-2015\VR-S-2016\Mar-2016\003/1}}


 LAURUS Labs




¹³CNMR Spectrum of stage-5/ Idelalisib

13C NMR of 0265/C05/E00502/053b in DMSO-d6
Date: 04/03/2016, A.R.No:E-NMRO316/0078
{C:\Data\Data-2015\RS-2016\Mar-2016\001\1}
Low Sample Quantity


 LAURUS Labs



Mass Spectrum of stage-5/ Idelalisib



DSC Thermogram of stage-5/ Idelalisib



Method Log:

- 1: Equilibrate at 50.00°C
- 2: Ramp 10.00°C/min to 300.00°C
- 3: End of method

Peak Integration

Start °C	Onset °C	Maximum °C	Stop °C	Area J/g
247.21	254.88	256.45	259.85	96.20


ELN

**HPLC Chromatogram of stage-5/ Idelalisib
(Chemical purity)**




Analytical Development

S A M P L E I N F O R M A T I O N	
Sample Name:	0265/C05/E00502/149
Sample Type:	Unknown
Vial:	2:3
Injection #:	1
Injection Volume:	10.00 μ l
Run Time:	80.0 Minutes
Sample Set Name	0265_C05_80Min_020716
Sample Set ID:	1238
Project Name	HYD1_AD-Generics\0265_JULY
Result Id	1274
Result Set Id	
Method Id ****	
Acquired By:	Anjaneyulu team
Date Acquired:	07/02/2016 12:36:03 IST
Date Processed:	07/02/2016 14:15:50 IST
Processing Method	0265_PRo1
Processing Method Id	1262
Proc. Chnl. Descr.:	Detector A 268nm
System Name	LL_AD_LC_56_177
Empower 3 Software Build	3471 SPs Installed
Feature Release	2 DB ID: 2487711617



Peak Results				
Name	RT	Area	% Area	RT Ratio
Peak2	2.45	8615	0.02	0.08
Peak3	2.91	2627	0.01	0.09
Peak4	11.96	7442	0.02	0.39
Peak5	25.68	13446	0.03	0.84
C05	30.63	45409776	99.87	1.00
Peak6	37.61	2321	0.01	1.23
Peak7	38.91	5640	0.01	1.27
Peak8	45.85	4815	0.01	1.50
Peak9	49.31	9733	0.02	1.61
Peak10	54.85	2499	0.01	1.79



Sample Name: 0265/C05/E00502/149
Date Acquired: 07/02/2016 12:36:03 IST

Signature / Date

Page: 1 of 1


HPLC Chromatogram of stage-5/ Idelalisib
(Chiral purity)



Analytical Development


SAMPLE INFORMATION	
Sample Name:	0265/C05/E00502/149
Sample Type:	Unknown n
Vial:	1
Injection #:	1
Injection Volume:	10.00 ul
Run Time:	40.0 Minutes
Sample Set Name:	0265_C05_chiral
Sample Set ID:	1007
Project Name	HYD1_AD-Generics\0265_July_2
Result Id	1031
Method Id ****	
Acquired By:	divyakumarteam
Date Acquired:	7/2/2016 11:00:00 AM IST
Date Processed:	7/2/2016 2:30:27 PM IST
Processing Method:	0265_C05_chiral pro
Processing Method Id	1024
Proc. Chnl. Descr.:	W2489 ChA 268nm
System Name	LL_AD_LC_075
Empow er 3 Softw are Build	3471 SPs Installed: Feature
Release 2 DB ID: 2487711617	

Auto-Scaled Chromatogram



Peak Results

	Name	RT	Area	% Area	RT Ratio
1	Idelalisib	15.787	11482128	99.951	
2	Enantiomer	17.317	5666	0.049	



Signature / Date