

Electronic Supplementary Information

Tuning the Compatibility to achieve Toughened Biobased Poly(lactic acid)/Poly(butylene terephthalate) Blends

Boon Peng Chang^a, Amar K. Mohanty^{*a,b}, and Manjusri Misra^{a,b}

^aBioproducts Discovery and Development Centre, Department of Plant Agriculture, Crop Science Building, University of Guelph, 50 Stone Road East, Guelph, ON N1G 2W1, Canada.

^bSchool of Engineering, Thornbrough Building, University of Guelph, 50 Stone Road East, Guelph, ON N1G 2W1, Canada.

Supporting Document (S1)




Fig. S1. Digital photographs of the development of necking propagation on the tensile fractured of the PLA/PBT blends at different content of the ESAC, (a) 30/70 and (b) 40/60 PLA/PBT blends.

Supporting Document (S2)

Thermogravimetric Analysis (TGA).

Thermogravimetric analysis (TGA) of the PLA/PBT blends was performed using a TGA Q500 from TA-Instruments, USA, under nitrogen atmosphere. The samples weights with approximately 10-13 mg were ramp heated from 30°C to 700°C with a heating rate of 10°C/min. Both TGA and derivatives of the TGA curves (DTG) were obtained from TA analysis software.




Fig. S2. (a) Thermal degradation curves and (b) DTG curves for different ratio of PLA/PBT blends.

Supporting Document (S3)

Heat deflection temperature measurement

The heat deflection temperature (HDT) measurement was carried out using dynamic mechanical analysis (DMA) Q800 from TA-Instruments, USA. The sample dimension with 50 mm x 12 mm x 3 mm (*length x width x thickness*) was setup in 3-point bending clamp mode in the device under the stress of 0.455 MPa. The samples were heated from 30 °C to 200 °C with a heating rate of 2 °C/min according to ASTM D648. The heat deflection temperature was recorded at the deflection changes of samples more than 250 μm .




Fig. S3. The heat deflection temperature for PLA/PBT blends with different content of PLA.

From Fig. S3, it can be seen that the HDT of pure PBT is approximately 130°C. The PLA/PBT blends decreases gradually with the increasing content of PLA in the blend. This is due to the low HDT temperature of PLA which is around 54.3°C. Therefore, the reduction in HDT of the PBT was observed after blending with PLA.