

Supplementary Information

Thermally Evaporated Two-Dimensional SnS as an Efficient and Stable Electron Collection Interlayer for Inverted Planar Perovskite Solar Cells

Hikmet Coskun,^a Furkan H. Isikgor,^a Zhihui Chen,^b Muhammad Imran,^{a,c} Bichen Li,^a Qinghua Xu,^b and Jianyong Ouyang ^{*a}

^a Department of Materials Science & Engineering, National University of Singapore, 7 Engineering Drive 1, 117574, Singapore

^b Department of Chemistry, National University of Singapore, 3 Science Drive 3, 117543, Singapore

^c Materials Science Laboratory, Department of Physics, Quaid-i-Azam University, Islamabad, Pakistan

* Corresponding Author: mseoj@nus.edu.sg




Figure S1. Incident photon-to-current conversion efficiency (IPCE) and integrated photocurrent density of ITO/PTAA/perovskite/C₆₀/SnS (3nm)/Ag.







Figure S2. SEM mapping for (a) Sn and (b) S of SnS film coated on ITO/PTAA/perovskite/C60.







Figure S3. X-ray diffraction patterns of 45nm C_{60} , 45nm C_{60} /8nm BCP and 45nm C_{60} /3nm SnS coated perovskite thin films kept in the air at (a) day 0, (b) day 1, (c) day 2, (d) day 5 and (e) day 10.




Figure S4. Ratio of undegraded perovskite derived from XRD spectra for 45nm C₆₀, 45nm C₆₀/3nm SnS and 45nm C₆₀/8nm BCP coated perovskite thin films, using the formula based on intensities (*I*) on Figure S3, $Perovskite (\%) = 100 \times \frac{I_{14.2^\circ}}{(I_{14.2^\circ} + I_{12.9^\circ} + I_{10.6^\circ})}$ taking day 0 as a baseline.




Figure S5. (a) Ag 3d region and (b) I 3d region of XPS spectra for ITO/PTAA/perovskite/C₆₀/Ag, ITO/PTAA/perovskite/C₆₀/BCP(8nm)/Ag and ITO/PTAA/perovskite/C₆₀/SnS(3nm)/Ag devices that are aged for 5 days at ambient atmosphere under the light.




Figure S6. J - V characteristics of PSCs, ITO/NiO_x/perovskite/C₆₀/SnS/Ag and ITO/PTAA/perovskite/C₆₀/SnS/Ag under AM1.5G illumination (100 mW cm⁻²) for reverse and forward scan directions.