

Supporting information

**Multifunctional Ag@MOF-5@chitosan non-woven cloth composites for sulfur mustard
decontamination and haemostasis**

Lin Liu,^{a‡} Enming Ping,^{a‡} Junmei Sun,^a Lijuan Zhang,^{*a} Yunshan Zhou,^{*a} Yuxu Zhong,^{*b}
Yuanyuan Zhou^a and Yong'an Wang^b

^aState Key Laboratory of Chemical Resource Engineering, Institute of Science, Beijing University of Chemical Technology, Beijing 100029, P. R. China; ^bState Key Laboratory of Toxicology and Medical Counter measures, Institute of Pharmacology and Toxicology, Academy of Military Sciences PLA China, Beijing 100850, P. R. China

Table S1. The amount of silver and MOF-5 per gram of Ag^m@MOF-5@ chitosan

m	Ag (mg)	MOF-5 (mg)
20	1.45	156.51
40	2.78	155.89
60	4.06	155.55
80	5.49	154.83
100	5.72	154.65
120	5.90	154.40

The silver content increased gradually with the concentration of silver nitrate solution, and the content of MOF-5 slightly reduced.

Table S2. Composition of the HD-containing standard solutions.

Entry	Diluted HD solution (μL)	Petroleum ether (μL)	The blue reagent (μL)	Absolute ethyl alcohol (μL)
1	0	100	200	100
2	20	80	200	100
3	40	60	200	100

4	60	40	200	100
5	80	20	200	100
6	100	0	200	100




Fig. S1. Calibration curve of UV-vis. absorbance of the HD-containing solution. Insert image is UV absorbance of HD standard solution at 445 nm versus concentration of HD.

The standard solution of HD shows a absorption peak at $\lambda_{\max} = 447$ nm in its UV-visible spectrum (Fig. S1). The calibration curve for the determination of HD is obtained by plotting absorbance ($\lambda_{\max} = 447$ nm) against the concentration of HD (Table S2 and Fig. S1), with the regression equation $y = 0.058 + 0.086 x$ ($R = 0.999$), where y is the absorbance value and x is the residual concentration of HD.



Fig. S2 Wound model with Wistar rats




Fig. S3 Powder XRD patterns of Ag²⁰@MOF-5 (line a), Ag⁴⁰@MOF-5 (line b) and Ag⁶⁰@MOF-5 (line c)




Fig. S4 GC-MS spectra of the extracted suspension from 2-CEES decontaminated by MOF-5: GC spectrum (a) and mass spectrum for 2-CEES (b). Note: chitosan and MOF-5@chitosan showed

nearly the same spectra.




Fig. S5 The GC–MS spectra of the products extracted from the 2-CEES solution after being decontaminated by $\text{Ag}^{80}\text{@MOF-5@chitosan}$: GC spectrum (a), mass spectrum for HEES (b). Note: $\text{Ag}^{80}\text{@MOF-5}$ showed nearly the same spectra.