

Supporting Information

Green Chemistry

Highly Active Niobium-Loaded Montmorillonite Catalysts for the Production of 5-Hydroxymethylfurfural from Glucose

Guo Qiu,^a Chongpin Huang,^{a*} Xiuliang Sun,^{a*} and Biaohua Chen^b

^a State Key Laboratory of Chemical Resource Engineering, Beijing University of Chemical
Technology, Beijing 100029, China. Fax: 86 10 6441 9619; Tel: 86 10 6441 2054;

E-mail: huangcp@mail.buct.edu.cn; sunxl@mail.buct.edu.cn

^b College of Environmental and Energy Engineering, Beijing University of Technology, Beijing
100124, China.

Table of Contents

Tables:

Table S1 The original data about chemical composition (wt%) of Nb-MMT from XRF.

Table S2 Elemental content (wt%) of Nb-MMT determined by XRF.

Table S3 Overview of glucose conversion to 5-HMF yield using various niobium-containing catalysts under optimal conditions.

Table S4 Summary of glucose conversion and 5-HMF yield under different condition.

Table S5 Characterization of the recycled 1Nb-MMT-900 by XRF analysis.

Table S6 5-HMF yield in two-phase solvent with different ratio of organic phase to inorganic phase.

Figures:

Fig. S1 SEM images of (a) MMT, (b) 0.25Nb-MMT, (c) 1Nb-MMT, (d) 3Nb-MMT, (e) 1Nb-MMT-500, and (f) 1Nb-MMT-900.

Fig. S2 The effect of different Nb loadings on glucose conversion and 5-HMF yield.

Fig. S3 Reusability of 1Nb-MMT-900 catalyst.

Fig. S4 XRD patterns (a), FTIR spectra (b), and XPS spectra (c) of 1Nb-MMT-900 during four consecutive runs.

Fig. S5 Glucose conversion to 5-HMF in different solvents.

Fig. S6 HPLC chromatogram of the aqueous phase of the reaction solution obtained from the conversion of glucose.

Table S1 The original data about chemical composition (wt%) of Nb-MMT from XRF

Catalyst	SiO ₂	Al ₂ O ₃	CaO	MgO	Fe ₂ O ₃	K ₂ O	Na ₂ O	P ₂ O ₅	Nb ₂ O ₅
MMT	73.99	13.95	5.82	3.00	1.72	1.20	0.25	0.07	0.00
0.25Nb-MMT	73.74	14.18	5.34	3.08	1.75	1.24	0.23	0.06	0.37
0.5Nb-MMT	74.39	13.95	4.54	3.04	1.70	1.23	0.30	0.08	0.78
1Nb-MMT	74.43	14.28	3.56	2.82	1.79	1.27	0.23	0.07	1.56
2Nb-MMT	74.78	13.89	2.24	2.84	1.66	1.19	0.23	0.05	3.12
3Nb-MMT	73.63	13.79	2.07	2.67	1.72	1.32	0.23	0.08	4.50
1Nb-MMT-500	75.02	13.66	3.18	2.73	1.71	1.22	0.27	0.04	2.17
1Nb-MMT-900	74.05	14.15	2.99	2.85	1.73	1.28	0.26	0.06	2.64

Table S2 Elemental content (wt%) of Nb-MMT determined by XRF

Catalyst	Si	Al	Ca	Mg	Fe	K	Na	P	Nb
MMT	34.53	7.38	4.16	1.80	1.20	1.00	0.18	0.03	0.00
0.25Nb-MMT	34.41	7.51	3.82	1.85	1.22	1.03	0.17	0.03	0.26
0.5Nb-MMT	34.71	7.38	3.24	1.83	1.19	1.02	0.22	0.03	0.54
1Nb-MMT	34.73	7.56	2.54	1.69	1.25	1.05	0.17	0.03	1.09
2Nb-MMT	34.90	7.35	1.60	1.70	1.16	0.99	0.17	0.02	2.18
3Nb-MMT	34.36	7.30	1.48	1.60	1.20	1.09	0.17	0.03	3.15
1Nb-MMT-500	35.01	7.23	2.27	1.64	1.20	1.02	0.20	0.02	1.52
1Nb-MMT-900	34.56	7.49	2.13	1.71	1.21	1.06	0.19	0.03	1.85

Table S3 Overview of glucose conversion to 5-HMF yield using various niobium-containing catalysts under optimal conditions ^a

Entry	Catalyst	Experimental parameter		Ref
		Conversion/%	Yield/%	
1	Nb ₂ O ₅ /H ₃ PO ₄	92.0	52.0	S1
2	Nb _x -WO ₃	100.0	56.0	S2
3	Porous NbOPO ₄	68.0	39.3	S3
4	NbO/NbP	55.0	30.8	S4
5	1Nb-MMT-900	99.0	70.5	This work

Table S4 Summary of glucose conversion and 5-HMF yield under different condition ^a

Entry	Catalyst	Experimental parameter	
		Conversion/%	Yield/%
1	1Nb-MMT-900	99.0 ± 0.8	70.5 ± 2.0
2 ^b	1Nb-MMT-900	98.7 ± 0.2	55.4 ± 1.9
3 ^c	1Nb-MMT-900	98.7 ± 0.7	50.6 ± 0.7
4 ^d	1Nb-MMT-900	91.5 ± 0.1	44.8 ± 2.6
5 ^e	1Nb-MMT-900	95.0 ± 0.4	50.4 ± 1.5
6 ^f	1Nb-MMT-900	98.4 ± 0.7	65.6 ± 1.0

^a Reaction conditions: 66.6 mM glucose, 40 mg catalyst, 170 °C, 3 h, 5 mL of reaction solution, methyl isobutyl ketone/saturated sodium chloride solution (MIBK-NaCl) = 70 : 30 (v/v). ^{b, c} The initial concentration of glucose was 100 mM and 133 mM, respectively. ^{d, e, f} The initial mass of catalyst was 10 mg, 20 mg and 60 mg, respectively.

Table S5 Characterization of the recycled 1Nb-MMT-900 by XRF analysis.

Run	Si	Al	Ca	Mg	Fe	K	Na	P	Nb
Fresh	34.56	7.49	2.13	1.71	1.21	1.06	0.19	0.03	1.85
1	34.61	7.46	2.07	1.70	1.21	1.06	0.19	0.03	1.79
2	34.53	7.58	2.00	1.71	1.21	1.05	0.17	0.03	1.71
3	34.63	7.49	2.10	1.71	1.21	1.06	0.20	0.03	1.64
4	34.63	7.51	2.03	1.71	1.21	1.04	0.19	0.03	1.60

Table S6 5-HMF yield in two-phase solvent with different ratio of organic phase to inorganic phase (conditions: 66.6 mM glucose, 40 mg 1Nb-MMT-900, 170 °C, 3 h).

Entry	Volume of solvent (ml)		Yield/%		
	MIBK	Water (NaCl)	Organic phase	Inorganic phase	Total
1	5	0	7.44	0	7.44
2	4	1	44.92	8.1	53.02
3	3.5	1.5	51.17	19.35	70.52
4	3	2	31.84	15.89	47.73
5	2.5	2.5	25.44	17.16	42.6
6	1.5	3.5	14.12	23.13	37.25
7	0	5	0	15.56	15.56




Fig. S1 SEM images of (a) MMT, (b) 0.25Nb-MMT, (c) 1Nb-MMT, (d) 3Nb-MMT, (e) 1Nb-MMT-500, and (f) 1Nb-MMT-900.




Fig. S2 The effect of different Nb loadings on glucose conversion and 5-HMF yield (conditions: 66.6 mM glucose, 40 mg 1Nb-MMT-900, 170 °C, 3 h, 5 mL of reaction solution, MIBK-NaCl =70 : 30 (v/v)).




Fig. S3 Reusability of 1Nb-MMT-900 catalyst (conditions: 66.6 mM glucose, 40 mg 1Nb-MMT-900, 170 °C, 3 h, 5 mL of reaction solution, MIBK-NaCl =70 : 30 (v/v)).




Fig. S4 XRD patterns (a), FTIR spectra (b), and XPS spectra (c) of 1Nb-MMT-900 during four consecutive runs.




Fig. S5 Glucose conversion to 5-HMF in different solvents (conditions: 66.6 mM glucose, 40 mg 1Nb-MMT-900, 170 °C, 3 h).




Fig. S6 HPLC chromatogram of the aqueous phase of the reaction solution obtained from the conversion of glucose (conditions: 66.6 mM glucose, 40 mg 1Nb-MMT-900, 170 °C, 5 min).

References

- S1. K. Nakajima, Y. Baba, R. Noma, M. Kitano, J. N. Kondo, S. Hayashi and M. Hara, *J. Am. Chem. Soc.*, 2011, **133**, 4224-4227.
- S2. C. Yue, G. Li, E. A. Pidko, J. J. Wiesfeld, M. Rigutto and E. J. Hensen, *Chemsuschem*, 2016, **9**, 2421-2429.
- S3. Y. Zhang, J. Wang, X. Li, X. Liu, Y. Xia, B. Hu, G. Lu and Y. Wang, *Fuel*, 2015, **139**, 301-307.
- S4. M. N. Catrinck, E. S. Ribeiro, R. S. Monteiro, R. M. Ribas, M. H. P. Barbosa and R. F. Teófilo, *Fuel*, 2017, **210**, 67-74.