

Supporting Information

Durable, Acid-Resistant Copolymers from Industrial By-Product Sulfur and Microbially-Produced Tyrosine

Timmy Thiounn,^[a] Andrew G. Tennyson^[a, b] and Rhett C. Smith,^{*[a]}

^[a]Department of Chemistry and Center for Optical Materials Science and Engineering Technologies (COMSET), Clemson University, Clemson, South Carolina, 29634, USA.

^[b]Department of Materials Science and Engineering, Clemson University, Clemson, South Carolina, 29634, USA

Synthesis of tetraallyltyrosine.

To a 500 mL round bottom flask equipped with a Teflon-coated magnetic stir bar was added 9.988 g (0.055 mol) of L-tyrosine and 150 mL of dimethylformamide, the solution was stirred until complete dissolution of tyrosine followed by the addition of 18.216 g (0.325 mol) of KOH. 54.6 g (0.451 mol) of allyl bromide was added drop-wise using an addition funnel, following complete addition of allyl bromide the flask was then equipped with a water-cooled reflux condenser and placed in a 60 °C oil bath and stirred for 24 h. The flask was cooled to room temperature and 100 mL of 0.5 M HCl(aq) was added to the reaction mixture and extracted with dichloromethane (4×150 mL). The organic layer was collected and washed with deionized water (4×200 mL) and the solvent was evaporated under reduced pressure. The remaining liquid was passed through a 5-cm high silica plug in a 150 mL fritted funnel using dichloromethane as the solvent. The product was collected as a yellow liquid (6.924 g, 37%).




Figure S1. Proton NMR spectrum of tetrallyltyrosine in CDCl₃.




Figure S2. Inset of ^1H NMR spectrum between 6–7.5 ppm of tetrallyltyrosine in CDCl_3 .




Figure S3. Inset of ^1H NMR spectrum between 5.5–6.5 ppm of tetrallyltyrosine in CDCl_3 .




Figure S4. Inset of ^1H NMR spectrum between 5–5.5 ppm of tetrallyltyrosine in CDCl_3 .




Figure S5. Carbon-13 NMR spectrum of tetrallyltyrosine in CDCl₃.




Figure S6: Infrared spectra of TTS_{30} (green), TTS_{50} (orange), and tetraallyltyrosine (black) between 600-1200 cm^{-1} .




Figure S7: DSC curves for TTS_{30} (blue line) and TTS_{50} (red dashed line). Curves represent the third heat/cool cycles.




Figure S8: Trials 1, 2, and 3 of TTS_{30} stress strain measurements where the red line is the propagation of the linear region of the respective stress strain curve.




Figure S9: Trials 1, 2, and 3 of TTS_{50} stress strain measurements where the red line is the propagation of the linear region of the respective stress strain curve.