

Supporting Information for

Reversible visual thermochromic coordination polymers via single-crystal-to-single-crystal transformation

Jian-Ping Ma, Shao-Chen Liu, Chao-Wei Zhao, Xiao-Meng Zhang, Chuan-Zhi Sun and
Yu-Bin Dong*

College of Chemistry, Chemical Engineering and Materials Science, Key Laboratory of Molecular and Nano Probes, Engineering Research Center of Pesticide and Medicine Intermediate Clean Production, Ministry of Education, Shandong Provincial Key Laboratory of Clean Production of Fine Chemicals, Shandong Normal University, Jinan 250014, People's Republic of China.

Email: yubindong@sdnu.edu.cn





Fig. S1 XRPD pattern of **1**.

Experimental Section. Commercially available reagents were used as received without further purification. 5-(2-pyridyl)-3-mercapto-4-amino-1, 2, 4-triazole (A) was prepared According to method of literature.¹ Infrared (IR) samples were prepared as KBr pellets, and spectra were obtained in the 400-4000 cm^{-1} range using a Perkin-Elmer 1600 FTIR spectrometer. Elemental analyses were performed on a Perkin-Elmer Model 2400 analyzer. Thermogravimetric analyses were carried out using a TA Instrument SDT 2960

simultaneous DTA-TGA under flowing nitrogen at a heating rate of 10 °C/min. ¹H NMR data were collected using an AM-300 spectrometer. Chemical shifts are reported in δ relative to TMS. The UV-vis diffuse reflectance was performed on SHIMADZU UV-2550 UV-vis spectrophotometer.

Synthesis of L.



A solution of **A** (2.28g, 12mmol), 3-(Chloromethyl)pyridine Hydrochloride (2.16g, 13.2mmol), KOH (1.6g, 15.6mmol) in 30mL MeOH, was stirred for 24 hours. The obtained sample was purified by column to generate colorless crystalline solids 2.07 g (Yield, 60.8 %). ¹H NMR (300MHz, CDCl₃, 25 °C TMS, ppm): δ 8.65(s, 1H, -C₅H₄N), 8.58(d, 1H, -C₅H₄N), 8.47(t, 1H, -C₅H₄N), 8.22 (d, 1H, -C₅H₄N), 7.84~7.82(m, 2H, -C₅H₄N), 7.35~7.33(m, 1H, -C₅H₄N), 7.39(s, 1H, -C₅H₄N), 7.29~7.20(m, 1H, -C₅H₄N), 6.20(s, 2H, -NH₂), 4.48(s, 2H, -CH₂-). IR (KBr pellet cm⁻¹): 3442(vs), 1638(s), 1591(s), 1571(s), 1465(s), 1424(vs), 1252(m), 1194(w), 1101(w), 1013(m), 957(m), 811(m), 789(m), 739(w), 712(w), 681(w), 628(w).. Elemental analysis Calcd (%) for C₁₃H₁₂N₆S: C 54.92, H 4.23, N 29.58; Found: C 54.87, H 4.18, N 29.53.

Single-Crystal Structure Determination. The variable temperature X-ray diffraction data of **1-4** were measured on Agilent Gemini E diffractometer (Mo K α radiation, λ = 0.71073 Å). The raw frame data for **1 - 4** were integrated into SHELX-format reflection files and corrected for Lorentz and polarization effects using SAINT.² Corrections for incident and

diffracted beam absorption effects were applied using SADABS.² The crystals showed no evidence of crystal decay during data collection. The structures were solved by a combination of direct methods and difference Fourier syntheses and refined against F^2 by the full-matrix least squares technique, using the SHELXTL software package.³ The asymmetric unit contains the Cu atom, one coordinated $C_{13}H_{12}N_6S$ ligand, a uncoordinated $SO_3CF_3^-$ of crystallization. All non-hydrogen atoms were refined with anisotropic displacement parameters. Hydrogen atoms attached to refined atoms were placed in geometrically idealized positions and refined using a riding model. Crystal data, data collection parameters, and refinement statistics for **1**, **2**, **3** and **4** are listed in Tables 1.

Table S1. Crystal data collection and structure refinement for compounds **1-4**.

compound	1	2	3	4
empirical formula	$C_{28}H_{24}CuF_6N_{12}O_6S_4$	$C_{28}H_{24}CuF_6N_{12}O_6S_4$	$C_{28}H_{24}CuF_6N_{12}O_6S_4$	$C_{28}H_{24}CuF_6N_{12}O_6S_4$
formula weight	930.37	930.37	930.37	930.37
temp (K)	298(2)	323(2)	353(2)	298(2)
crystal system	Monoclinic	Monoclinic	Monoclinic	Monoclinic
space group	$P2(1)/n$	$P2(1)/n$	$P2(1)/n$	$P2(1)/n$
a (Å)	9.2150(3)	9.2224(7)	9.2249(9)	9.2121(8)
b (Å)	18.8491(5)	18.8786(13)	18.8564(13)	18.8386(13)
c (Å)	10.4290(3)	10.4661(8)	10.4413(11)	10.4187
α (deg)	90	90	90	90
β (deg)	100.392(3)	100.366(7)	100.292(10)	100.408(9)

γ (deg)	90	90	90	90
V (Å ³)	1781.75(10)	1792.5(2)	1787.0(3)	1778.3(3)
Z	2	2	2	2
ρ_{calc} (g/cm ³)	1.734	1.724	1.729	1.737
$F(000)$	942	942	942	942
data/restraints/params	3318 / 1 / 259	3348 / 0 / 259	3332 / 0 / 259	3312 / 0 / 259
GOF on F^2	1.048	1.081	1.079	1.060
final R indices [$I >$	R1 = 0.0333	R1 = 0.0434	R1 = 0.0444	R1 = 0.0488
2sigma(I)]	wR2 = 0.0725	wR2 = 0.0823	wR2 = 0.0874	wR2 = 0.0847

Table S2. Interatomic Distances (Å) and Bond Angles (°) with esds () for **1**.

Cu(1)-N(3)=1.9754(18)	Cu(1)-N(3)#1=1.9754(18)	Cu(1)-N(2)#2=2.126(2)
Cu(1)-N(2)#3=2.126(2)	Cu(1)-N(1)#1=2.390(2)	Cu(1)-N(1)=2.390(2)
N(2)-Cu(1)#4=2.126(2)		
N(3)-Cu(1)-N(3)#1 = 180.00(7)	N(3)-Cu(1)-N(2)#2 = 90.45(8)	
N(3)#1-Cu(1)-N(2)#2 = 89.55(8)	N(3)-Cu(1)-N(2)#3 = 89.55(8)	
N(3)#1-Cu(1)-N(2)#3 = 90.45(8)	N(2)#2-Cu(1)-N(2)#3 = 180.00(9)	
N(3)-Cu(1)-N(1)#1 = 105.09(7)	N(3)#1-Cu(1)-N(1)#1 = 74.91(7)	
N(2)#2-Cu(1)-N(1)#1 = 87.29(7)	N(2)#3-Cu(1)-N(1)#1 = 92.71(7)	
N(3)-Cu(1)-N(1) = 74.91(7)	N(3)#1-Cu(1)-N(1) = 105.09(7)	
N(2)#2-Cu(1)-N(1) = 92.71(7)	N(2)#3-Cu(1)-N(1) = 87.29(7)	
N(1)#1-Cu(1)-N(1) = 180.0	C(1)-N(1)-C(5) = 117.6(2)	
C(1)-N(1)-Cu(1) = 131.84(19)	C(5)-N(1)-Cu(1) = 110.19(15)	
C(12)-N(2)-C(13) = 117.7(2)	C(12)-N(2)-Cu(1)#4 = 119.20(16)	
C(13)-N(2)-Cu(1)#4 = 123.11(17)		

Symmetry transformations used to generate equivalent atoms:
#1 -x+1,-y,-z+1 #2 x-1/2,-y+1/2,z-1/2 #3 -x+3/2,y-1/2,-z+3/2 #4 -x+3/2,y+1/2,-z+3/2

Table S3. Interatomic Distances (Å) and Bond Angles (°) with esds () for **2**.

Cu(1)-N(3) = 1.977(2)	Cu(1)-N(3)#1 = 1.977(2)	Cu(1)-N(2)#2 = 2.132(3)
Cu(1)-N(2)#3 = 2.132(3)	Cu(1)-N(1) = 2.380(3)	Cu(1)-N(1)#1 = 2.380(3)
N(2)-Cu(1)#4 = 2.132(3)		

N(3)-Cu(1)-N(3)#1 = 180.00(14)	N(3)-Cu(1)-N(2)#2 = 90.51(10)
N(3)#1-Cu(1)-N(2)#2 = 89.49(10)	N(3)-Cu(1)-N(2)#3 = 89.49(10)
N(3)#1-Cu(1)-N(2)#3 = 90.51(10)	N(2)#2-Cu(1)-N(2)#3 = 180.00(11)
N(3)-Cu(1)-N(1) = 74.98(10)	N(3)#1-Cu(1)-N(1)=105.02(10)
N(2)#2-Cu(1)-N(1)=92.72(10)	N(2)#3-Cu(1)-N(1)=87.28(10)
N(3)-Cu(1)-N(1)#1=105.02(10)	N(3)#1-Cu(1)-N(1)#1=74.98(10)
N(2)#2-Cu(1)-N(1)#1=87.28(10)	N(2)#3-Cu(1)-N(1)#1=92.72(10)
N(1)-Cu(1)-N(1)#1=180.0	

Symmetry transformations used to generate equivalent atoms:

#1 -x+1,-y,-z+1 #2 x-1/2,-y+1/2,z-1/2 #3 -x+3/2,y-1/2,-z+3/2 #4 -x+3/2,y+1/2,-z+3/2

Table S4. Interatomic Distances (Å) and Bond Angles (°) with esds () for **3**.

Cu(1)-N(3) = 1.970(2)	Cu(1)-N(3)#1 = 1.970(2)	Cu(1)-N(2)#2 = 2.140(3)
Cu(1)-N(2)#3 = 2.140(3)	Cu(1)-N(1)#1 = 2.372(3)	Cu(1)-N(1) = 2.372(3)
N(2)-Cu(1)#4 = 2.140(3)		

N(3)-Cu(1)-N(3)#1 = 180.00(10)	N(3)-Cu(1)-N(2)#2 = 89.36(10)
N(3)#1-Cu(1)-N(2)#2 = 90.64(10)	N(3)-Cu(1)-N(2)#3 = 90.64(10)
N(3)#1-Cu(1)-N(2)#3 = 89.36(10)	N(2)#2-Cu(1)-N(2)#3 = 180.0
N(3)-Cu(1)-N(1)#1 = 104.87(10)	N(3)#1-Cu(1)-N(1)#1 = 75.13(10)
N(2)#2-Cu(1)-N(1)#1 = 92.95(10)	N(2)#3-Cu(1)-N(1)#1 = 87.05(10)
N(3)-Cu(1)-N(1) = 75.13(10)	N(3)#1-Cu(1)-N(1) = 104.87(10)
N(2)#2-Cu(1)-N(1) = 87.05(10)	N(2)#3-Cu(1)-N(1) = 92.95(10)
N(1)#1-Cu(1)-N(1) = 180.00(10)	

Symmetry transformations used to generate equivalent atoms:

#1 -x+1,-y,-z+1 #2 -x+3/2,y-1/2,-z+3/2 #3 x-1/2,-y+1/2,z-1/2 #4 -x+3/2,y+1/2,-z+3/2

Table S5. Interatomic Distances (Å) and Bond Angles (°) with esds () for **4**.

Cu(1)-N(3)#1=1.972(3)	Cu(1)-N(3)=1.972(3)	Cu(1)-N(2)#2=2.121(3)
Cu(1)-N(2)#3=2.121(3)	Cu(1)-N(1)=2.387(3)	Cu(1)-N(1)#1=2.387(3)
N(2)-Cu(1)#4=2.121(3)		

N(3)#1-Cu(1)-N(3) = 180.00(12)	N(3)#1-Cu(1)-N(2)#2 = 89.52(12)
N(3)-Cu(1)-N(2)#2 = 90.48(12)	N(3)#1-Cu(1)-N(2)#3 = 90.48(12)
N(3)-Cu(1)-N(2)#3 = 89.52(12)	N(2)#2-Cu(1)-N(2)#3 = 180.00(12)
N(3)#1-Cu(1)-N(1) = 105.19(11)	N(3)-Cu(1)-N(1) = 74.81(11)
N(2)#2-Cu(1)-N(1) = 92.77(11)	N(2)#3-Cu(1)-N(1) = 87.23(11)
N(3)#1-Cu(1)-N(1)#1 = 74.81(11)	N(3)-Cu(1)-N(1)#1 = 105.19(11)
N(2)#2-Cu(1)-N(1)#1 = 87.23(11)	N(2)#3-Cu(1)-N(1)#1 = 92.77(11)
N(1)-Cu(1)-N(1)#1 = 180.000(1)	

Symmetry transformations used to generate equivalent atoms:

#1 -x+1,-y,-z+1 #2 x-1/2,-y+1/2,z-1/2 #3 -x+3/2,y-1/2,-z+3/2 #4 -x+3/2,y+1/2,-z+3/2

Reference

(1) Reid, J.-R.; Heindel, N.D. *J. Heterocyclic. Chem.* **1976**, *13*, 925.

(2) Bruker Analytical X-ray Systems, Inc.: Madison, WI, **1998**.

(3) Sheldrick, G. M. SHELXTL Version 5.12; Bruker Analytical X-ray Systems, Inc., Madison, Wisconsin, USA, **1997**.