

Supporting Information

Dendrite-free reversible Li plating/stripping in adiponitrile-based electrolytes for high-voltage Li metal batteries

Manasi Mwemezi,^{‡a} S. J. Richard Prabakar,^{‡a} Su Cheol Han,^a Jung Yong Seo,^a Woon Bae Park,^{*a} Jin-Woong Lee,^b Kee-Sun Sohn^{*b} and Myoungho Pyo^{*a}

^a Department of Printed Electronics Engineering, Sunchon National University, Chonnam 57922, Republic of Korea

E-mail: wbpark@scnu.ac.kr, mho@sunchon.ac.kr

^b Faculty of Nanotechnology and Advanced Materials Engineering, Sejong University, Seoul 05006, Republic of Korea

E-mail: kssohn@sejong.ac.kr

[‡] These authors contributed equally to this work

Fig. S1 (CV in EC:DEC) -----	2
Fig. S2 (Effect of NO ₂ concentrations) -----	3
Fig. S3 (XRD pattern of precipitates) -----	4
Fig. S4 (XRD pattern of Li ₂ O) -----	4
Fig. S5 (Cyclic voltammogram in LiTFSI) -----	5




Fig. S1. Cyclic voltammograms for Li plating/stripping on SS in 0.25 M LiBF₄/EC:DEC (ethylene carbonate : diethyl carbonate, 3:7). Scan rate = 0.2 mVs⁻¹. Coin cell (Li || SS).




Fig. S2. Cyclic voltammograms for Li plating/stripping on SS in 0.25 M LiBF_4/ADN with $\text{Li}/\text{Li}_2\text{O}$ treated in (A) 0.5, (B) 1.0, and (C) 2.0 wt% NO_2BF_4 . Scan rate = 0.2 mVs^{-1} . Coin cell ($\text{Li}/\text{Li}_2\text{O} \parallel \text{SS}$).




Fig. S3. (left) XRD pattern of precipitates produced during Li plating/stripping with bare Li (described in Fig. 3A). Inset shows a FESEM image of precipitates. The precipitates are composed of spherical particles of ca. 100 nm in diameter, which can block the separator in a coin cell set-up (Figure 1B). (right) XPS spectrum of precipitates.




Fig. S4. XRD pattern of a powdery sample obtained from the surface film generated by immersing Li foil in NO_2BF_4 /ADN. The surface film was gently rubbed with a soft rod to avoid the inclusion of a large quantity of underlying Li metal.




Fig. S5. Cyclic voltammograms for Li plating/stripping on SS coupled with Li/ Li_2O in 1.0 M LiTFSI/ADN. Scan rate = 0.2 mVs⁻¹. Coin cell (Li/ Li_2O || SS).