

## Electronic Supplementary Information

# Synthesis of arene-functionalized fused heterocyclic scaffolds *via* a regioselective cascade 1,4-conjugate addition/5-*exo-dig* annulation strategy


Xinwei He,<sup>a\*</sup> Demao Wang,<sup>a</sup> Yanan Liu,<sup>a</sup> Mengdi Wu,<sup>a</sup> Yangzilin Kong,<sup>a</sup> Qiang Tang,<sup>a</sup> Yiping Wang,<sup>a</sup> Chenli Fan,<sup>b</sup> Yongjia Shang<sup>a\*</sup>

<sup>a</sup>Key Laboratory of Functional Molecular Solids, Ministry of Education, Anhui Laboratory of Molecule-Based Materials (State Key Laboratory Cultivation Base), College of Chemistry and Materials Science, Anhui Normal University, Wuhu 241000, P.R. China

<sup>b</sup>School of Material Engineering, Wuhu Institute of Technology, Wuhu, 241002, People's Republic of China

### Table of contents

1. Table S1. Optimization of the reaction conditions-----	S2
2. X-ray crystallographic data of compound <b>3aa</b> -----	S3
3. X-ray crystallographic data of compound <b>5aa</b> -----	S4
4. X-ray crystallographic data of compound <b>10aa</b> -----	S5
5. <sup>1</sup> H, <sup>13</sup> C and/or <sup>19</sup> F NMR spectra for all compounds-----	S6

**Table S1.** Optimization of the reaction conditions.<sup>a</sup>


entry	catalyst (x equiv.)	solvent	time (h)	temp. (°C)	yield(%) <sup>b</sup>
1	FeCl <sub>3</sub> (0.2)	MeCN	4	80	0
2	AlCl <sub>3</sub> (0.2)	MeCN	4	80	0
3	ZnCl <sub>2</sub> (0.2)	MeCN	4	80	0
4	Cu(OTf) <sub>2</sub> (0.2)	MeCN	4	80	0
5	Zn(OTf) <sub>2</sub> (0.2)	MeCN	4	80	0
6	DMAP (1.0)	MeCN	4	80	11
7	DBU (1.0)	MeCN	4	80	8
8	DABCO (1.0)	MeCN	4	80	32
9	Cs <sub>2</sub> CO <sub>3</sub> (1.0)	MeCN	4	80	30
10	NaHCO <sub>3</sub> (1.0)	MeCN	4	80	35
11	TMG (1.0)	MeCN	4	80	43
12	TMG (1.0)	MeCN	8	80	46
13	TMG (1.0)	MeCN	10	80	47
14	TMG (1.0)	MeCN	12	80	48
15	TMG (1.0)	MeCN	20	80	45
16	TMG (1.0)	MeCN	32	80	46
17	TMG (0.5)	MeCN	12	80	40
18	TMG (1.5)	MeCN	12	80	53
19	TMG (2.0)	MeCN	12	80	45
20	TMG (3.0)	MeCN	12	80	41
21	TMG (1.5)	MeCN	12	90	60
22	TMG (1.5)	DCE	12	90	12
23	TMG (1.5)	THF	12	90	n.r.
24	TMG (1.5)	EtOAc	12	90	n.r.
25	TMG (1.5)	DMSO	12	90	n.r.
26 <sup>c</sup>	TMG (1.5)	MeCN	12	90	55
27 <sup>d</sup>	TMG (1.5)	MeCN	12	90	64
28 <sup>e</sup>	TMG (1.5)	MeCN	12	90	59

<sup>a</sup>Reaction conditions: propargylamine **1aa** (0.1 mmol), 4-hydroxy-6-methylpyridin-2(1H)-one **4** (0.1 mmol), and catalyst (20 mol%) in solvent (2 mL) under air atmosphere. <sup>b</sup>Isolated yields.

<sup>c</sup>The amount of **1aa** was 2.0 equivalences.

<sup>d</sup>The amount of **1aa** was 3.0 equivalences. <sup>e</sup>The amount of **1aa** was 4.0 equivalences.

## 2. X-ray crystallographic data of compound 3aa




The purified compound **3aa** is dissolved in a mixed solvent of dichloromethane and *n*-hexane, and placed in a dark cabinet to slowly evaporate. After several days, a colourless bulk crystal is obtained. The X-ray crystal-structure determinations were obtained on a Bruker Smart CCDC APEX-2 diffractometer (graphite- monochromated Mo  $K\alpha$  radiation,  $\lambda=0.71073$  nm) at 300 K.

**Figure S1.** ORTEP drawing of compound **3aa** (30% probability for the thermal ellipsoid).

**Table S1.** Crystal data and structure refinement for compound **3aa**.

CCDC number	2295482
Identification code	220330a_0m_a
Empirical formula	C <sub>21</sub> H <sub>16</sub> O <sub>4</sub>
Formula weight	332.34
Temperature	300.00 K
Wavelength	0.71073 Å
Crystal system	triclinic
Space group	P-1
Unit cell dimensions	a = 8.460(7) Å $\alpha$ = 79.660(10) $^\circ$ . b = 11.802(9) Å $\beta$ = 83.815(11) $^\circ$ . c = 17.491(14) Å $\gamma$ = 89.445(11) $^\circ$ .
Volume	1708(2) Å <sup>3</sup>
Z	4
$\rho_{\text{calc}}$	1.292 g/cm <sup>3</sup>
$\mu$	0.089 mm <sup>-1</sup>
F(000)	696.0
Crystal size	0.21 × 0.2 × 0.19 mm <sup>3</sup>
2 $\Theta$ range for data collection	2.38 to 55.034 $^\circ$ .
Index ranges	-10 ≤ h ≤ 10, -15 ≤ k ≤ 15, -22 ≤ l ≤ 22
Reflections collected	19706
Independent reflections	7626 [R <sub>int</sub> = 0.0428, R <sub>sigma</sub> = 0.0646]
Data / restraints / parameters	7626 / 0 / 455
Goodness-of-fit on F <sup>2</sup>	0.995
Final R indexes [I >= 2 $\sigma$ (I)]	R <sub>1</sub> = 0.0545, wR <sub>2</sub> = 0.1180
Final R indexes [all data]	R <sub>1</sub> = 0.1211, wR <sub>2</sub> = 0.1415
Largest diff. peak/hole	0.13 and -0.20 e.Å <sup>-3</sup>

### 3. X-ray crystallographic data of compound 5aa




The purified compound **5aa** is dissolved in a mixed solvent of dichloromethane and *n*-hexane, and placed in a dark cabinet to slowly evaporate. After several days, a colourless bulk crystal is obtained. The X-ray crystal-structure determinations were obtained on a Bruker Smart CCDC APEX-2 diffractometer (graphite- monochromated Mo *K* $\alpha$  radiation,  $\lambda=0.71073$  nm) at 300 K.

**Figure S1.** ORTEP drawing of compound **5aa** (30% probability for the thermal ellipsoid).

**Table S1.** Crystal data and structure refinement for compound **5aa**.

CCDC number	2295483
Identification code	20221017i
Empirical formula	C <sub>21</sub> H <sub>17</sub> NO <sub>3</sub>
Formula weight	331.36
Temperature	300.00 K
Wavelength	0.71073 Å
Crystal system	monoclinic
Space group	P2 <sub>1</sub> /c
Unit cell dimensions	a = 6.9547(6) Å $\alpha$ = 90°. b = 19.975(2) Å $\beta$ = 90.477(4)°. c = 12.2707(14) Å $\gamma$ = 90°.
Volume	1704.6(3) Å <sup>3</sup>
Z	4
$\rho_{\text{calc}}$	1.291 g/cm <sup>3</sup>
$\mu$	0.087 mm <sup>-1</sup>
F(000)	696.0
Crystal size	0.29 × 0.26 × 0.23 mm <sup>3</sup>
2 $\Theta$ range for data collection	5.26 to 54.952°.
Index ranges	-9 ≤ h ≤ 8, -25 ≤ k ≤ 25, -15 ≤ l ≤ 15
Reflections collected	30892
Independent reflections	3885 [R <sub>int</sub> = 0.1407, R <sub>sigma</sub> = 0.0746]
Data / restraints / parameters	3885 / 0 / 229
Goodness-of-fit on F <sup>2</sup>	1.022
Final R indexes [I>=2σ (I)]	R <sub>1</sub> = 0.0549, wR <sub>2</sub> = 0.1119
Final R indexes [all data]	R <sub>1</sub> = 0.1343, wR <sub>2</sub> = 0.1430
Largest diff. peak/hole	0.27 and -0.21 e.Å <sup>-3</sup>

#### 4. X-ray crystallographic data of compound 10aa



The purified compound **10aa** is dissolved in a mixed solvent of dichloromethane and *n*-hexane, and placed in a dark cabinet to slowly evaporate. After several days, a colourless bulk crystal is obtained. The X-ray crystal-structure determinations were obtained on a Bruker Smart CCDC APEX-2 diffractometer (graphite- monochromated Mo  $K\alpha$  radiation,  $\lambda=0.71073$  nm) at 300 K.


**Figure S1.** ORTEP drawing of compound **10aa** (30% probability for the thermal ellipsoid).

**Table S1.** Crystal data and structure refinement for compound **10aa**.



CCDC number	2295484
Identification code	230523c_sq
Empirical formula	C21H17NO3
Formula weight	331.36
Temperature	300.00 K
Wavelength	0.71073 Å
Crystal system	tetragonal
Space group	I4 <sub>1</sub> /a
Unit cell dimensions	a = 23.118(12) Å $\alpha$ = 90°. b = 23.118(12) Å $\beta$ = 90°. c = 14.243(9) Å $\gamma$ = 90°.
Volume	7612(9) Å <sup>3</sup>
Z	16
$\rho_{\text{calc}}$	1.157 g/cm <sup>3</sup>
$\mu$	0.078 mm <sup>-1</sup>
F(000)	2784.0
Crystal size	0.09 × 0.08 × 0.07 mm <sup>3</sup>
2 $\Theta$ range for data collection	3.358 to 49.5°.
Index ranges	-27 ≤ h ≤ 27, -27 ≤ k ≤ 25, -16 ≤ l ≤ 16
Reflections collected	26587
Independent reflections	3248 [R <sub>int</sub> = 0.1790, R <sub>sigma</sub> = 0.0923]
Data / restraints / parameters	3248 / 320 / 267
Goodness-of-fit on F <sup>2</sup>	1.014
Final R indexes [I>=2σ (I)]	R <sub>1</sub> = 0.0862, wR <sub>2</sub> = 0.1958
Final R indexes [all data]	R <sub>1</sub> = 0.2022, wR <sub>2</sub> = 0.2671
Largest diff. peak/hole	0.14 and -0.18 e.Å <sup>-3</sup>


**5.  $^1\text{H}$ ,  $^{13}\text{C}$  and/or  $^{19}\text{F}$  NMR spectra for all compounds**

**2-Benzyl-3-(2-hydroxyphenyl)-6-methyl-4*H*-furo[3,2-*c*]pyran-4-one (3aa)**




**2-(4-Fluorobenzyl)-3-(2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ab)**









### 2-(4-Chlorobenzyl)-3-(2-hydroxyphenyl)-6-methyl-4*H*-furo[3,2-*c*]pyran-4-one (3ac)




### 2-(4-Bromobenzyl)-3-(2-hydroxyphenyl)-6-methyl-4*H*-furo[3,2-*c*]pyran-4-one (3ad)




**3-(2-Hydroxyphenyl)-6-methyl-2-(4-(trifluoromethyl)benzyl)-4*H*-furo[3,2-*c*]pyran-4-one (3ae)**








**2-([1,1'-Biphenyl]-4-ylmethyl)-3-(2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one  
(3af)**




**3-(2-Hydroxyphenyl)-6-methyl-2-((4'-propyl-[1,1'-biphenyl]-4-yl)methyl)-4*H*-furo[3,2-*c*]pyran-4-one (3ag)**




**2-(3-Fluorobenzyl)-3-(2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ah)**




—112.6919





Parameter	值
1 Data File Name	E:/New-新仪器谱图数据/22-2-hxw-F/22/fid
2 标题	22-2-hxw-F.22.fid
3 Comment	
4 Origin	Bruker BioSpin GmbH
5 Owner	nmrsu
6 Site	
7 Instrument	Avance NEO 400
8 Author	
9 Solvent	CDCl <sub>3</sub>
10 Temperature	295.3
11 Pulse Sequence	zgig
12 Experiment	1D
13 Probe	Z163739_0511 (PI HR-BBO400S1-BBF/H/D-50-ZSP)
14 Number of Scans	16
15 Receiver Gain	101.0
16 Relaxation Delay	1.0000
17 Pulse Width	12.0000
18 Presaturation Frequency	
19 Acquisition Time	0.7209
20 Acquisition Date	2022-11-23T03:33:53
21 Modification Date	2022-11-23T03:34:14
22 Class	
23 Spectrometer Frequency	376.48
24 Spectral Width	90909.1
25 Lowest Frequency	-83106.3
26 Nucleus	19F
27 Acquired Size	65536
28 Spectral Size	131072
29 Digital Resolution	0.69




### 2-(3-Chlorobenzyl)-3-(2-hydroxyphenyl)-6-methyl-4*H*-furo[3,2-*c*]pyran-4-one (3ai)





**2-(3-Bromobenzyl)-3-(2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (product 3aj)**





### 3-(2-Hydroxyphenyl)-6-methyl-2-(thiophen-2-ylmethyl)-4*H*-furo[3,2-*c*]pyran-4-one (3ak)





**2-Benzyl-3-(2-hydroxy-5-methylphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ba)**




**2-(4-Chlorobenzyl)-3-(2-hydroxy-5-methylphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3bc)**




**2-(4-Bromobenzyl)-3-(2-hydroxy-5-methylphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3bd)**





**3-(2-Hydroxy-5-methylphenyl)-6-methyl-2-(4-methylbenzyl)-4*H*-furo[3,2-*c*]pyran-4-one  
(product 3bl)**




**3-(2-Hydroxy-5-methylphenyl)-6-methyl-2-((4'-propyl-[1,1'-biphenyl]-4-yl)methyl)-4H-furo[3,2-c]pyran-4-one (3bg)**




**2-(4-Fluorobenzyl)-3-(2-hydroxy-5-methoxyphenyl)-6-methyl-4*H*-furo[3,2-*c*]pyran-4-one (3cb)**









**2-(4-Chlorobenzyl)-3-(2-hydroxy-5-methoxyphenyl)-6-methyl-4H-furo[3,2-*c*]pyran-4-one  
(3cc)**




**2-(4-Bromobenzyl)-3-(2-hydroxy-5-methoxyphenyl)-6-methyl-4*H*-furo[3,2-*c*]pyran-4-one  
(3cd)**






**2-Benzyl-3-(5-fluoro-2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (product 3da)**







### 3-(5-Fluoro-2-hydroxyphenyl)-6-methyl-2-(4-methylbenzyl)-4*H*-furo[3,2-*c*]pyran-4-one (3dl)








**2-Benzyl-3-(5-chloro-2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ea)**




**3-(5-chloro-2-hydroxyphenyl)-2-(4-fluorobenzyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3eb)**




Parameter	值
1 Data File Name	E:\New-新仪器谱图数据\23-1-hwx-F\1\f1
2 标题	23-1-hwx-F.1.fid
3 Comment	
4 Origin	Bruker BioSpin GmbH
5 Owner	nmrsu
6 Site	
7 Instrument	Avance NEO 400
8 Author	
9 Solvent	CDCl3
10 Temperature	295.1
11 Pulse Sequence	zgig
12 Experiment	1D
13 Probe	Z163739_0511 (PI HR-BB040051-BBF/ H/D-SQ-Z SP)
14 Number of Scans	16
15 Receiver Gain	101.0
16 Relaxation Delay	1.0000
17 Pulse Width	12.0000
18 Presaturation Frequency	
19 Acquisition Time	0.7209
20 Acquisition Date	2023-02-22T22:1.98
21 Modification Date	2023-02-22T22:1.02
22 Class	
23 Spectrometer Frequency	376.48
24 Spectral Width	90909.1
25 Lowest Frequency	-83106.3
26 Nucleus	19F
27 Acquired Size	65536
28 Spectral Size	131072
29 Digital Resolution	0.69




**3-(5-chloro-2-hydroxyphenyl)-2-(4-chlorobenzyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ec)**




**2-(4-Bromobenzyl)-3-(5-chloro-2-hydroxyphenyl)-6-methyl-4H-furo[3,2-*c*]pyran-4-one  
(product 3ed)**





**3-(5-Chloro-2-hydroxyphenyl)-6-methyl-2-(4-methylbenzyl)-4H-furo[3,2-c]pyran-4-one (3el)**





**3-(5-Chloro-2-hydroxyphenyl)-2-(4-methoxybenzyl)-6-methyl-4H-furo[3,2-c]pyran-4-one  
(3em)**





**2-Benzyl-3-(5-bromo-2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3fa)**





**3-(5-Bromo-2-hydroxyphenyl)-2-(4-chlorobenzyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3fc)**





**3-(5-Bromo-2-hydroxyphenyl)-2-(4-bromobenzyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3fd)**




**2-Benzyl-3-(2-hydroxy-5-iodophenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ga)**




**2-Benzyl-3-(3,5-dibromo-2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3ha)**





**2-Benzyl-6-(*tert*-butyl)-3-(2-hydroxyphenyl)-4*H*-furo[3,2-*c*]pyran-4-one (3aab)**




## 2-Benzyl-3-(2-hydroxyphenyl)-6-methylfuro[3,2-*c*]pyridin-4(5*H*)-one (5aa)




**2-(4-Fluorobenzyl)-3-(2-hydroxyphenyl)-6-methylfuro[3,2-*c*]pyridin-4(5*H*)-one (5ab)**








**2-(4-Chlorobenzyl)-3-(2-hydroxyphenyl)-6-methylfuro[3,2-c]pyridin-4(5H)-one (5ac)**




**2-(4-Bromobenzyl)-3-(2-hydroxyphenyl)-6-methylfuro[3,2-c]pyridin-4(5H)-one (5ad)**




**2-([1,1'-Biphenyl]-4-ylmethyl)-3-(2-hydroxyphenyl)-6-methylfuro[3,2-*c*]pyridin-4(5*H*)-one  
(5af)**




**3-(2-Hydroxyphenyl)-6-methyl-2-((4'-propyl-[1,1'-biphenyl]-4-yl)methyl)furo[3,2-*c*]pyridin-4(5*H*)-one (5ag)**




**2-(4-Fluorobenzyl)-3-(2-hydroxy-5-methylphenyl)-6-methylfuro[3,2-*c*]pyridin-4(5*H*)-one  
(5bb)**




Parameter	值
1 Data File Name	E:\New-新仪器谱图数据\23-1-hwx-F\6.fid
2 标题	23-1-hwx-F.6.fid
3 Comment	
4 Origin	Bruker BioSpin GmbH
5 Owner	nmrsu
6 Site	
7 Instrument	Avance NEO 400
8 Author	
9 Solvent	CDCl <sub>3</sub>
10 Temperature	295.6
11 Pulse Sequence	zgig
12 Experiment	1D
13 Probe	Z163739_0511 (PI HR-BB040051-BBF/ H/D-SQ-ZSP)
14 Number of Scans	16
15 Receiver Gain	101.0
16 Relaxation Delay	1.0000
17 Pulse Width	12.0000
18 Presaturation Frequency	
19 Acquisition Time	0.7209
20 Acquisition Date	2023-03-16T21:42:49
21 Modification Date	2023-03-16T21:42:04
22 Class	
23 Spectrometer Frequency	376.48
24 Spectral Width	90909.1
25 Lowest Frequency	-83106.3
26 Nucleus	19F
27 Acquired Size	65536
28 Spectral Size	131072
29 Digital Resolution	0.69





**2-Benzyl-3-(2-hydroxy-5-methylphenyl)-6-methylfuro[3,2-*c*]pyridin-4(5*H*)-one (5ca)**




**3-(5-Bromo-2-hydroxyphenyl)-6-methyl-2-(4-methylbenzyl)furo[3,2-c]pyridin-4(5H)-one  
(product 5fl)**




## 2-Benzyl-3-(2-hydroxyphenyl)-4H-furo[3,2-c]chromen-4-one (7)




**4-(2-Hydroxyphenyl)-2-phenyl-4H,5H-pyrano[3,2-c]chromen-5-one (8)**




**2-(Cyclohex-2-en-1-yl)-4-(2-hydroxyphenyl)-7-methyl-4H,5H-pyrano[4,3-*b*]pyran-5-one (8a)**




**4-(2-Hydroxyphenyl)-7-methyl-2-pentyl-4H,5H-pyrano[4,3-*b*]pyran-5-one (8b)**




**(Z)-3-(2-Aminophenyl)-2-benzylidene-6-methyl-2,3-dihydro-4H-furo[3,2-c]pyran-4-one  
(10aa)**




**(Z)-3-(2-Aminophenyl)-2-(4-bromobenzylidene)-6-methyl-2,3-dihydro-4H-furo[3,2-c]pyran-4-one(10ad)**




**(Z)-3-(2-Amino-5-fluorophenyl)-2-benzylidene-6-methyl-2,3-dihydro-4H-furo[3,2-c]pyran-4-one(10da)**








**(Z)-3-(2-Amino-5-bromophenyl)-2-benzylidene-6-methyl-2,3-dihydro-4H-furo[3,2-c]pyran-4-one(10fa)**





**2-Benzyl-3-(2-methoxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (11)**




**2-Benzyl-3-(2-(benzyloxy)phenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (12)**






**2-Benzyl-3-((diphenylphosphoran-2-yloxy)phenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (13)**





## 2-(2-benzyl-6-methyl-4-oxo-4H-furo[3,2-c]pyran-3-yl)phenyl trifluoromethanesulfonate (14)





**2-Benzyl-3-(2-hydroxyphenyl)-6-methyl-4H-furo[3,2-c]pyran-4-one (3aa-d)**

