

Alteration of the cellulose nanocrystal surface chemistry for guided formation of polymer brush

Supporting Information

Lauren Geurds, Katarzyna Kępa, Jan Lauko, Alan E. Rowan and Nasim Amiralian

Australian Institute of Bioengineering and Nanotechnology (AIBN), University of Queensland, Brisbane, Queensland, Australia

Contents:

Figure S1	CNC-BiBB discoloration and physical appearance	S2
Figure S2	FTIR CNC-BiBB	S2
Figure S3	¹³ C NMR CNC-BiBB	S3
Figure S4	Thermogravimetric analysis CNC-BiBB	S3
Figure S5	XRD CNC-BiBB	S4
Figure S6	CNC-BiBB reaction discoloration due to base	S4
Figure S7	¹ H NMR spectroscopy wash	S5
Figure S8	Thermogravimetric analysis for CNC and CNC grafted PtBA systems	S6
Table S1	Thermogravimetric analysis of CNC and CNC grafted PtBA systems decomposition temperatures	S6




Figure S1, Samples of A) unmodified CNCs, B) CNC-CVD, C) CNC-BiBB discolored, and D) CNC-C-BiBB-1 after freeze-drying.




Figure S2, FT-IR spectra of CNC (Black) and ATRP initiator modified samples A) CNC-CVD 24 and 48 h. B) CNC-C-BiBB-1 and CNC-BiBB-2. C) CNC-C-BiBB-3 and -4. D) CNC-C-BiBB-5 and -6. E) CNC-C-BiBB-7, -8, and 9.




Figure S3, ^{13}C NMR of CNC (Black) and ATRP initiator modified samples A) CNC-CVD 24 and 48 h. B) CNC-C-BiBB-3 and -4. C) CNC-C-BiBB-5 and -6. D) CNC-C-BiBB-7, -8, and 9.




Figure S4, Thermogravimetric analysis for unmodified CNC (Black) and ATRP initiator-modified samples CNC-C-BiBB-3 to 9. Inset represents the samples decomposition area for all samples represented.




Figure S5, XRD profiles of unmodified CNC (Black) and ATRP initiator modified samples A) CNC-C-BiBB-3 and -4. B) CNC-C-BiBB-5 and -6. C) CNC-C-BiBB-7, -8, and 9. Depending on the treatment conditions, the modified CNC particles exhibit peaks consistent with cellulose I morphology.




Figure S6, The discoloration reaction mixture of CNC-CVD, BiBB, and pyridine in DMF in which the amount of pyridine was changed. CNC-C-BiBB-6 A) start of the reaction, B) after 48 hours. CNC-C-BiBB-5 C) start of the reaction, D) after 48 hours.




Figure S7, ¹H NMR spectra of the washed layers in CDCl₃ for SI-ATRP of tBA on CNC-C-BiBB-5 (CNC-PtBA1).




Figure S8, Thermogravimetric analysis for unmodified CNC (Black), CNC-C-BiBB-5 (Green), CNC-PtBA₃ (Pink) and CNC-PtBA₄ (Blue). Inset represents the samples decomposition area for all samples represented.

Table S1: Thermogravimetric analysis of decomposition temperatures

Sample	Reaction conditions			Results	
	DS	Eq tBA	Time	T _{onset} [°C]	T _{max} [°C]
CNC				260	296
CNC-C-BiBB-3				202	220
CNC-PtBA ₁	7.0%	1000	15 h	182	200
CNC-PtBA ₂	10%	500	6 h	176	188
CNC-PtBA ₃	7.5%	1000	4 h	137	183
CNC-PtBA ₄	10 %	250	2 h	129	149