

Synthesis of efficient bi-anchoring bifuran/biphenyl derivatives for dye-sensitized solar cell applications.

Heba M. El-Shafeai, Safa A. Badawy, Mohamed A. Ismail, Ehab Abdel-Latif, Ahmed A. Fadda, Mohamed R. Elmorsy*

Department of Chemistry, Faculty of Science, Mansoura University, 35516 Mansoura, Egypt, *E-mail: m.r.elmorsy@mans.edu.eg, m.r.elmorsy@gmail.com

Supplementary Material








Figure S1: Compound HB-1 Infrared (IR) spectra



Heba Elshafeay- HA-2134- C13

Figure S3: Compound HB-1 ¹³C-NMR (DMSO-*d*₆)/Bruker 100 MHz





Figure S4: Compound HB-1 Mass spectrum.







Figure S5: Compound HB-2 Infrared (IR) spectra









Figure S8: Compound HB-3 Infrared (IR) spectra





Figure S9: Compound HB-3 $^1\text{H-NMR}$ ($\text{DMSO-}d_6$)/JEOL 500 MHz





Figure S11: Compound HB-3 Mass Spectrum





Figure S12: Compound HB-4 infrared (IR) spectra.





Figure S14: Compound HB-4 Mass Spectrum





Figure S15: Compound HB-5 Infrared (IR) spectra





Figure S16: Compound HB-5 ¹H-NMR (DMSO-*d*₆)/JEOL 500 MHz






Figure S17: Compound HB-5 $^1\text{H-NMR}$ ($\text{D}_2\text{O}/\text{DMSO-}d_6$)/JEOL 500 MHz







Figure S19: *Compound HB-5* Mass Spectrum.




Figure S20: Mass fragmentation pattern of biphenyl dye **HB-5**.





Figure S21: Compound HB-6 Infrared (IR) spectra





Figure S22: Compound HB-6 ¹H-NMR (DMSO-*d*₆)/JEOL 500 MHz





Figure S23: Compound HB-6 Mass Spectrum.





Figure S24: Compound HB-7 Infrared (IR) spectra.





Figure S25: Compound HB-7 ¹H-NMR (DMSO-*d*₆)/Bruker 400 MHz





Figure S26: Compound HB-7 Mass Spectrum.





Figure S27: Compound HB-8 Infrared (IR) spectra







Figure S28: Compound HB-8 $^1\text{H-NMR}$ ($\text{DMSO-}d_6$)/ JEOL 500 MHz

Figure S29: Compound HB-8 Mass Spectrum.




Fig. (S30): UV-Vis. absorption of N3.




Fig. (S31): UV-Vis. absorption of N3 on TiO₂.




Fig. (S32): binding modes of HB-1-8 on TiO₂.




Figure S33: FTIR spectrum of compound HB-1 over TiO₂.




Figure S34: FTIR spectrum of compound HB-2 over TiO₂.




Figure S35: FTIR spectrum of compound HB-3 over TiO₂.




Figure S36: FTIR spectrum of compound HB-4 over TiO₂.




Figure S37: FTIR spectrum of compound HB-5 over TiO₂.




Figure S38: FTIR spectrum of compound HB-6 over TiO₂.




Figure S39: FTIR spectrum of compound HB-7 over TiO₂.




Figure S40: FTIR spectrum of compound HB-8 over TiO₂.




Figure S41: The cyclic voltammetry plots of co-sensitizers HB-1-8.




Figure S42: Molecular electronic potential diagram (MEP) of bifuran/biphenyl sensitizers **HB-1-8**.

2. Experimental Section:

2.1. Materials and methods:

The chemicals and solvents necessary for the chemical reactions and synthetic procedures were acquired from Sigma-Aldrich, TCI America, Alfa Aesar, and Acros chemical companies and utilized exactly as supplied. The measured melting points (uncorrected) are just in degrees Celsius, employing a Gallenkamp electric melting point instrument. A Thermo Scientific Nicolet iS10 FTIR spectrometer was used for recording the IR spectra (KBr). Nuclear magnetic resonance (NMR) spectra were obtained on a Bruker NMR spectrometer/ or A JEOL spectrometer using DMSO- d_6 as a solvent at 400, 500 MHz (^1H -NMR) and 100, 125 MHz (^{13}C -NMR) with an internal standard (TMS), chemical shifts are given as δ /ppm. A Shimadzu Qp-2010 Plus (GC-MS) and Thermo Scientific ISQ (GC-MS) spectrometers were used for recording mass spectra of the newly synthesized compounds. The elemental analysis data was collected using the Perkin Elmer 2400 analyzer. The UV-Visible spectra were measured by using the high-performance double beam spectrophotometer (T80 series).

3. Cell preparations and photovoltaic characterizations

3.1. TiO_2 electrode preparation

A double-layer TiO_2 photoelectrode (10 + 5) μm in thickness with a 10 μm thick nanoporous layer and a 5 μm thick scattering layer (area: 0.25 cm^2) was prepared using a reported method. Fluorine-doped tin oxide (FTO) coated glasses (Nippon Sheet Glass Co., Japan) with a sheet resistance of 8-10 ohm/\square and an optical transmission of greater than 80% in the visible range were screen printed using anatase TiO_2 colloids (particle size ~ 13 nm) obtained from commercial sources (Ti-Nanoxide D/SP, Solaronix). Nanocrystalline TiO_2 thin films were deposited onto the conducting glass by screen-printing, which was then sintered at 500 $^\circ\text{C}$ for 1 h. The film thickness was measured with a Surfcom 1400A surface profiler

(Tokyo Seimitsu Co. Ltd.). The electrodes were impregnated with a 0.05 M titanium tetrachloride solution and sintered at 500 °C. The films were further treated with 0.1 M HCl(aq) before examination.

The dye solutions of the main sensitizer N3 (0.2 mM) and HB1-8 (0.2 mM) were prepared in 1:1:1 mixture of acetonitrile, tert-butyl alcohol and dimethyl sulfoxide (DMSO). The electrodes were immersed in the dye solutions and then kept at 25 °C for 20 h to adsorb the dye onto the TiO₂ surface.

For preparing the counter electrode, pre-cut TCO glasses were washed with water followed by 0.1M HCl in EtOH, and sonication in acetone bath for 10 min. These washed TCO were then dried at 400 °C for 15 min. Thin layer of Pt-paste (Solaronix, Platisol T/SP) on TCO was printed and the printed electrodes were then cured at 450 °C for 10 min.

3.2. Fabrication of dye-sensitized solar cell

Photovoltaic and incident photon-to-current efficiency (IPCE) measurements were made on sandwich cells, which were prepared using TiO₂ coated working electrodes and platinum coated counter electrodes and were sealed using a 40 μm Syrlyn spacer through heating of the polymer frame. The redox electrolyte (Solaronix, Iodolyte HI-30) consisted of a solution of 0.6 M DMPII, 0.05 M I₂, 0.1 M LiI and 0.5 M TBP in acetonitrile.

3.3. Photovoltaic measurements

Photovoltaic measurements of sealed cells were made by illuminating the cell through the conducting glass from the anode side with a solar simulator (WXS-155S-10) at AM 1.5 illuminations (light intensity: 100 mW cm⁻²).

3.4. Incident photon to current efficiency (IPCE) conversion

IPCE measurements were made on a CEP-2000 system (Bunkoh-Keiki Co. Ltd.). IPCE at each wavelength was calculated using Equation 1, where I_{SC} is the short-circuit photocurrent density (mA. cm⁻²) under monochromatic irradiation, q is the elementary charge, λ is the wavelength of incident radiation in nm and P_0 is the incident radiative flux in W/m².

$$IPCE(\lambda) = 1240 \left(\frac{I_{SC}}{q\lambda P_0} \right) \quad (1)$$

3.5. Electrochemical impedance spectroscopy (EIS)

The electrochemical impedance spectra were measured with an impedance analyzer potentiostat (Bio-Logic SP-150) under illumination using a solar simulator (SOL3A, Oriel) equipped with a 450 W xenon lamp (91160, Oriel). EIS spectra were recorded over a frequency range of 100 mHz to 200 kHz at room temperature. The applied bias voltage was set at the V_{OC} of the DSSCs, with AC amplitude set at 10 mV. The electrical impedance spectra were fitted using Z-Fit software (Bio-Logic).

3.6. Cyclic voltammetry

Cyclic voltammetry (CV) was performed in DMF with the electrolyte 0.1 M [TBA][PF₆] at a scan rate of 50 mV s⁻¹. The working electrode used is the Glassy carbon, Pt wire represented the counter electrode, and the reference electrode is Ag/Ag⁺ in ACN. Fc/Fc⁺ was introduced as internal reference.

4. Molecular Modeling

Equilibrium molecular geometries of **HB1-8** calculated using the Becke's three parameter hybrid functional, Lee–Yang–Parr's gradient corrected correlation functional (B3LYP) and *d*-polarized 6–311G [1, 2, 3, 4]. The geometry optimization calculations were followed by energy calculations using time-dependent density functional theory (TD-DFT) utilizing the energy, functional B3lyp and the basis set *d*-

polarized 6–311G. The solvent (DMF) effect was accounted for by using the conductor-like polarizable continuum model (C-PCM), implemented in Gaussian 09.

References

- [1] G. Melikian, F. Rouessac, C. Alexandre, Synth Commun. 1993, 23, 2631
- [2] A. D. Becke, Phys. Rev. A **1988**, 38, 3098.
- [3] C. T. Lee, W.T. Yang, R.G. Parr, Phys. Rev. B. **1988**, 37, 785
- [4] N. Godbout, D.R. Salahub, J. Andzelm, E. Wimmer, Optimization of Gaussian-type basis-sets for local spin-density functional calculations .1. Boron through neon, optimization technique and validation. Can. J. Chem.-Rev. Can. Chim. **1992**, 70, 560-571.