

## Rapid Synthesis of MOF CaBTC using an ultrasonic irradiation method and its derivative materials for CO<sub>2</sub> capture

Xiaoqi Jin<sup>\*a</sup>, Zongqun Li<sup>a</sup>, Jinlong Ge<sup>a</sup>, Linlin Zhu<sup>a</sup>, Caiyan Liu<sup>a</sup>, Qiu Li<sup>a</sup>, Jing Liu<sup>b</sup>, Chenlin Yin<sup>b</sup>, Gaoyu Su<sup>b</sup>

<sup>a</sup> School of Materials and Chemical Engineering, Bengbu University, Bengbu, Anhui, China

<sup>b</sup> Bengbu Zhongheng New Material Technology Co. LTD, Bengbu, Anhui, China

### Supplementary Information





Figure S1: XRD patterns of Ca/CN-2 and Ca/CN-8( ✚ CaO ● C)






Figure S2: SEM images of Ca/CN-2 , Ca/CN-8, CaBTC@PDA-5, CaO, CaO/C and elements mapping (Ca, O, C, N) for CaBTC@PDA-5, CaO, CaO/C




Fig. S3: Raman spectra of CaO/C and CaO/CN-5.

Fig. S3 presents the Raman spectra of CaO/C and CaO/CN-5. As shown in Fig. S3 (a), the Raman spectrum of CaO/C exhibited two adsorption peaks at  $1340\text{ cm}^{-1}$  and  $1586\text{ cm}^{-1}$ , which were attributed to the disordered carbon (D) band and graphite band (G), respectively [1]. The intensity ratio of  $I_D / I_G$  value was 1.13, and the sharp adsorption peak at  $1083\text{ cm}^{-1}$  was assigned to calcium carbonate [2]. In addition, the adsorption peak of calcium carbonate was not detected in the CaO/CN-5 sample, and the other characteristic peaks of the CaO/CN-5 sample were consistent with those of the CaO/C sample. The intensity ratio of  $I_D / I_G$  value increased to 1.21. According to the above results, the CaO/C and CaO/CN-5 samples presented a certain degree of graphitization of the CaBTC MOF derivate obtained by the pyrolysis method.

## References

- [1] Wang J-G, Liu H-Z, Sun H-H, Hua W, Wang H-W, Liu X-R, Wei B-Q, One-pot synthesis of nitrogen-doped ordered mesoporous carbon spheres for high-rate and long-cycle life supercapacitors, *Carbon* 2018; 127, 85. <https://doi.org/10.1016/j.carbon.2017.10.084>.
- [2] Schmid T, Dariz P, Shedding light onto the spectra of lime: Raman and luminescence bands of CaO, Ca(OH)<sub>2</sub> and CaCO<sub>3</sub>, *J Raman Spectrosc* 2015; 46, 141. <https://doi.org/10.1002/jrs.4622>.

Table S1. Elemental content of based on the evaluation of XPS spectra

Samples	C1s (At%)	Ca2p (At%)	O1s (At%)	N1s (At%)
CaBTC	61.01	5.72	33.27	—
CaBTC@PDA-5	60.69	1.39	23.27	14.65
Ca/CN-5	85.57	1.04	4.38	9.01
Ca/C	83.72	3.66	12.62	—




Fig. S4: TG curves of Ca/CN-2 and Ca/CN-8




Fig. S5: CO<sub>2</sub> adsorption-desorption isotherms of Ca/CN-2 and Ca/CN-8