

Heterometallic coordination polymers incorporating dipyrromethane based heteroleptic copper and cobalt complexes: to Ag- π or not?

Antoine, Béziau, Stéphane A. Baudron* and Mir Wais Hosseini*

Laboratoire de Chimie de Coordination Organique, UMR CNRS 7140, Université de Strasbourg, F-67000, Strasbourg, France.

Email : hosseini@unistra.fr, sbaudron@unistra.fr

Electronic Supplementary Information

PXRD diagrams were collected on a Bruker D8 diffractometer using monochromatic Cu-K α radiation with a scanning range between 4 and 40° using a scan step of 2°/mn.




Fig 1. Simulated (black) and experimental (red) X-Ray diffraction powder pattern for CP 5. The difference in intensities results from preferential orientation.




Fig. 2. Simulated (black) and experimental (red) X-Ray diffraction powder pattern for CP 6. The difference in intensities results from preferential orientation.