

Coordination effect-regulated CO₂ capture with alkali metal onium salts/crown ether system

Zhen-Zhen Yang, De-en Jiang, Xiang Zhu, Chengcheng Tian, Suree Brown, Chi-Linh Do-Thanh, Liang-Nian He* and Sheng Dai*

Table of Contents

	page
1. General experimental methods	S2
2. Synthesis of alkali metal onium salts	S2
3. Characterization of ProK/18-crown-6/PEG300 and 4-Cl-PhOK/18-crown-6/PEG300 (¹ H, ¹³ C NMR and FT-IR) before and after CO ₂ capture	S2
4. Scanning thermogravimetric analysis (TGA) and reusability of the 4-Cl-PhOK/18-crown-6/PEG300 system	S4
5. IR spectra of other absorption systems before and after CO ₂ capture	S5

1. General experimental methods:

Caution

Experiments using compressed gas (CO₂) are potentially hazardous and must only be carried out by using the appropriate equipment and under rigorous safety precautions.

Materials

All the reagents used in this work are purchased from Sigma-Aldrich Company and directly used without further purification. CO₂ with a purity of 99.99% is commercially available.


Experimental methods

¹H and ¹³C NMR spectra were recorded on a Varian Mercury 300 MHz spectrometer (¹H NMR, 300 MHz, ¹³C NMR, 75 MHz) in CDCl₃, the chemical shifts were referenced to the residual solvent. FTIR data were obtained using a Bio-Rad Excalibur FTS-3000 spectrometer.

General procedure for absorption and desorption of CO₂

In a typical procedure, CO₂ capture was carried out in a glass container with an inner diameter of 10 mm. The absorbents were charged into the reactor at room temperature. Then, a needle was used for CO₂ bubbling, which was inserted in the bottom of the flask. The absorption reaction was conducted at 25 °C with a CO₂ bubbling rate of 80 mL/min. The amount of CO₂ absorbed was determined by an analytical balance with an accuracy of ±0.0001 g every five minutes. In a typical desorption of CO₂, N₂ of atmospheric pressure is bubbled through the absorption system at 50 °C using the same equipment and procedure as CO₂ capture. Absorption/desorption is determined by several cycles of repeated experiments.

2. Synthesis of alkali metal onium salts:



The alkali metal onium salts were prepared from the neutralization of various amino acids or phenols with alkali metal hydroxides. For example, in a typical procedure for the synthesis of ProK, equimolar proline was added to an ethanolic solution of KOH. Then, the mixture was stirred at room temperature for 24 h. Subsequently, EtOH was distilled off at 70 °C under vacuum. The obtained solid was washed with ethyl ether three times and dried under vacuum at 80 °C for 24 h.

3. Characterization of ProK/18-crown-6/PEG300 and 4-Cl-PhOK/18-crown-6/PEG300 (¹H, ¹³C NMR and FT-IR) before and after CO₂ capture

18-crown-6

¹H NMR (CDCl₃, 300 MHz) δ 3.64 (s, 24H);

ProK

¹H NMR (CDCl₃, 300 MHz) δ 3.77 (t, ³J = 7.8 Hz, 1H), 3.21-3.29 (m, 1H), 2.96-3.05 (m, 1H), 2.11-2.21 (m, 1H), 1.81-1.99 (m, 3H);

ProK/18-crown-6

¹H NMR (CDCl₃, 300 MHz) δ 3.61-3.62 (m, 25H), 3.05-3.13 (m, 1H), 2.81-2.89 (m, 1H), 2.03-2.16 (m, 1H), 1.86-1.97 (m, 1H), 1.58-1.72 (m, 2H);

ProK/18-crown-6/PEG300

^1H NMR (CDCl_3 , 300 MHz) δ 3.44-3.58 (m, 78H), 2.94-3.01 (m, 1H), 2.73-2.82 (m, 1H), 1.92-2.04 (m, 1H), 1.79-1.88 (m, 1H), 1.49-1.65 (m, 2H); ^{13}C NMR (CDCl_3 , 75 MHz) δ 177.7, 77.2, 72.0, 71.9, 69.3-69.7, 61.0, 60.2, 60.1, 46.0, 30.4, 25.1.

ProK/18-crown-6/PEG300 + CO_2

^1H NMR (CDCl_3 , 300 MHz) δ 3.98 (s, 1H), 3.56-3.70 (m, 82H), 3.19-3.29 (m, 2H), 2.25 (s, 1H), 1.97-2.09 (m, 1H), 1.70-1.79 (m, 2H); ^{13}C NMR (CDCl_3 , 75 MHz) δ 175.9, 157.7, 77.2, 72.3, 72.1, 69.5-70.0, 60.8, 60.5, 46.4, 28.9, 24.1.

4-Cl-PhOK

^1H NMR (CDCl_3 , 300 MHz) δ 7.11 (s, 1H), 7.08 (s, 1H), 6.71 (s, 1H), 6.68 (s, 1H);

4-Cl-PhOK/18-crown-6



^1H NMR (CDCl_3 , 300 MHz) δ 6.86-6.90 (m, 2H), 6.53-6.57 (m, 2H), 3.60 (s, 84H);

4-Cl-PhOK/18-crown-6/PEG300

^1H NMR (CDCl_3 , 300 MHz) δ 6.99 (s, 1H), 6.96 (s, 1H), 6.76 (s, 1H), 6.73 (s, 1H), 3.56-3.70 (m, 140H); ^{13}C NMR (CDCl_3 , 75 MHz) δ 165.1, 129.2, 128.0, 119.0, 115.8, 77.2, 72.3, 72.2, 72.18, 69.5, 69.9, 60.4-60.6.

4-Cl-PhOK/18-crown-6/PEG300+ CO_2

^1H NMR (CDCl_3 , 300 MHz) δ 6.95-6.99 (m, 2H), 6.73-6.76 (m, 2H), 3.55-3.70 (m, 94H); ^{13}C NMR (CDCl_3 , 75 MHz) δ 158.7, 157.4, 128.0, 120.3, 117.2, 77.2, 71.9, 69.4-69.8, 60.5.






Figure S1. (a) ¹H NMR spectra (CDCl₃, 300 MHz) of 18-crown-6, 4-Cl-PhOK, 4-Cl-PhOK/18-crown-6 and 4-Cl-PhOK/18-crown-6/PEG300+CO₂ (from top to bottom); (b) ¹³C NMR spectra (CDCl₃, 75 MHz) of 4-Cl-PhOK/18-crown-6/PEG300 before (top) and after (bottom) CO₂ absorption. (c) FT-IR spectrum of 4-Cl-PhOK/18-crown-6/PEG300 before (black line) and after (blue line) CO₂ absorption.

4. Scanning thermogravimetric analysis (TGA) and reusability of the 4-Cl-PhOK/18-crown-6/PEG300 system




Figure S2. (a) Scanning thermogravimetric analysis (TGA) results for 4-Cl-PhOK /18-crown-6/PEG300+CO₂ with a 10 °C min⁻¹ temperature ramping rate to 500 °C. (b) Six consecutive cycles of CO₂ absorption (◆ 15 min, 25 °C, CO₂) and release (◇ 20 min, 80 °C, N₂) by 4-Cl-PhOK/18-crown-6/PEG300 system, data were obtained every 5 min.

5. IR spectra of other absorption systems before and after CO₂ capture

