This journal is (c) The Royal Society of Chemistry 2010

## Supplementary data

## Carbon nanotubes decorated with Pt nanoparticles via electrostatic self-assembly: a highly active oxygen reduction electrocatalyst

Sheng Zhang,<sup>1,2</sup> Yuyan Shao,<sup>2</sup> Geping Yin,<sup>\*,1</sup> Yuehe Lin <sup>\*, 2</sup>

1. School of Chemical Engineering & Technology, Harbin Institute of Technology, Harbin 150001, China, 2. Pacific Northwest National Laboratory, Richland WA 99352, USA.

*Electrochemical measurements*: The electrochemical tests were carried out in a standard threeelectrode system controlled with a CHI660C station (CH Instruments, Inc., USA) with Pt wire and Hg/Hg<sub>2</sub>SO<sub>4</sub> as the counter electrode and reference electrode, respectively. The working electrodes were prepared by applying catalyst ink onto the pre-polished glass carbon disk electrodes.<sup>1</sup> The total loading of catalyst was 15  $\mu$ g (3  $\mu$ g Pt). The linear sweep voltammograms (LSV) for oxygen-reduction reaction (ORR) is measured with a Pine rotator system (Pine Instruments Company, USA) in oxygen-saturated 0.5 M H<sub>2</sub>SO<sub>4</sub> solution between 1.0 V and 0.25 V at a scan rate of 10 mV s<sup>-1</sup>. The background current was measured similarly in an N<sub>2</sub> atmosphere without rotation. The durability tests were carried out in N<sub>2</sub>-saturated 0.5 M H<sub>2</sub>SO<sub>4</sub> solution with potential step method (1.4V \_ 10 s - 0.85 V \_ 5 s).<sup>1</sup> CVs in N<sub>2</sub>-purged 0.5 M H<sub>2</sub>SO<sub>4</sub> solution and LSV in O<sub>2</sub>-saturated 0.5 M H<sub>2</sub>SO<sub>4</sub> solution were recorded before and after the degradation test.

All the tests were conducted at room temperature. All potentials were reported versus reversible hydrogen electrode (RHE).

This journal is (c) The Royal Society of Chemistry 2010

Reference:

 Y. Y. Shao, R. Kou, J. Wang, V. V. Viswanathan, J. H. Kwak, J. Liu, Y. Wang, Y. H. Lin, J. Power Sources, 2008, 185, 280-286.