

Supporting Information (SI)

Synthesis of Uniform Microporous Polymer Nanoparticles and Their Applications for Hydrogen Storage

*Buyi Li, Xin Huang, Liyun Liang and Bien Tan**

School of Chemistry and Chemical Engineering, Huazhong University of Science and Technology, Wuhan, 430074, China.

E-mail: bien.tan@mail.hust.edu.cn.; Fax: +86 27 87543632; Tel: +86 27 87558172

Total number of Pages: 8

Total number of Figures: 6

Total number of Tables: 1

Table of Content

Figure S1. TEM images for precursor emulsion with 45 nm.

Figure S2. TEM images for MPNs with 45 nm.

Figure S3. FT-IR Spectroscopy of “Davankov Resins” and MPNs.

Figure S4. Volumetric H₂ adsorption isotherms and desorption isotherms for “Davankov Resins” and MPNs with 60 nm and their mixture up to 1.13 bar at 77.3 K. The inset shows the detail of the adsorption isotherm in the low-pressure regime.

Figure S5. Nitrogen adsorption isotherm and desorption isotherm for “Davankov Resins” and MPNs with 60 nm and their mixture at 77.3 K.

Figure S6. Pore size distributions for “Davankov Resins” and MPNs with 60 nm and their mixture using DFT methods (slit pore models, Differential Pore Volume vs. Pore Width).

Table S1. Packing density, surface area, pore structure and H₂ uptakes for “Davankov Resins” and MPNs with 60 nm and their mixture.




Fig. S1 TEM image for precursor emulsion with 45 nm was taken on a Tecnai G20 microscope (FEI Corp. USA) instrument operated at an accelerating voltage of 200 kV.




Fig. S2 TEM image for MPNs with 45 nm was taken on a Tecnai G20 microscope (FEI Corp. USA) instrument operated at an accelerating voltage of 200 kV.




Fig. S3 Samples were analyzed with Bruker VERTEX 70 FT-IR Spectroscopy and ATR Accessory under ambient conditions in the wave number range of 4000-400 cm⁻¹.




Fig. S4 Volumetric H_2 adsorption isotherms and desorption isotherms for “Davankov Resins” and MPNs with 60 nm and their mixture (volume ratio, 1:1) up to 1.13 bar at 77.3 K.




Fig. S5 Nitrogen adsorption isotherm and desorption isotherm for “Davankov Resins” and MPNs with 60 nm and their mixture (volume ratio, 1:1) at 77.3 K.




Fig. S6 Pore size distributions for “Davankov Resins” and MPNs with 60 nm and their mixture (volume ratio, 1:1) using DFT methods (slit pore models, Differential Pore Volume vs. Pore Width).

Table S1 Packing density, surface area, pore structure and H₂ uptakes for “Davankov Resins” and MPNs with 60 nm and their mixture (volume ratio, 1:1).

No.	Particle size (nm) ^[a]	Packing density (g/cm ³)	S _{BET} ^[b] (m ² /g)	S _L ^[c] (m ² /g)	V _m ^[d] (cm ³ /g)	V _t ^[e] (cm ³ /g)	V _m ^[f] (cm ³ /g)	V _t ^[f] (cm ³ /g)	H ₂ uptake (g/L) ^[g]	H ₂ uptake (wt%) ^[g]
1	100μm ^[h]	0.344	1460	1965	0.48	0.97	0.41	0.83	4.54	1.32
4	60	0.257	1463	1975	0.54	2.13	0.45	1.35	3.93	1.53
7 ^[i]	N.D. ^[j]	0.384	1492	2024	0.53	1.40	0.41	0.85	5.45	1.42

Note.

[a] DLS (Dynamic Light Scattering) results;

[b] Brunauer-Emmett-Teller surface area;

[c] Langmuir surface area;

[d] Micropore volume determined from the N₂ isotherm at P/P₀ = 0.050;

[e] Total pore volume determined from the N₂ isotherm at P/P₀ = 0.995;

[f] Slit pore model used in DFT calculations;

[g] Determined volumetrically using a Micromeritics ASAP 2020 M analyzer at 77.3 K and 1.13 bar;

[h] The particle size was estimated according to the FE-SEM image;

[i] Sample 7 is mixture of “Davankov Resins” and MPNs with 60 nm in volume ratio of 1:1;

[j] N.D. means the sample was not determined in this parameter.