

Electronic Supplementary Information

Breathing Effects of CO₂ Adsorption on Flexible 3D Lanthanide Metal-Organic Frameworks

Bin Mu, Feng Li, Yougui Huang, and Krista S. Walton*

*School of Chemical & Biomolecular Engineering, Georgia Institute of Technology, Atlanta, Georgia 30332
USA*

E-mail: krista.walton@chbe.gatech.edu

Contents

1. Synthesis procedure for compound **1** (S2)
2. Thermal gravimetric analysis (S2)
3. Powder X-ray thermodiffraction (S2)
4. Single-crystal X-ray crystallography (S3)
5. Supplementary figures and schemes (S4-S5)
6. Elemental analysis and FTIR pattern (S6)

1. Synthesis

All the reagents and solvents were purchased from commercial sources and used without further purification. Solvothermal reactions were carried out in digestion bomb reactors. Exact amounts of $\text{La}(\text{NO}_3)_3 \cdot 6\text{H}_2\text{O}$ (1.8 mmol) and 1,3,5-Tris(4- carboxyphenyl)benzene acid (0.6 mmol) were dissolved in 30 mL dimethylformamide (DMF). The mixture solution was heated at 95 °C for 48 hours. Then the colorless crystal $[\text{La}(\text{BTB})(\text{H}_2\text{O}) \cdot 3\text{DMF}]_n$ (**1**) was obtained.

2. TGA

Thermogravimetric analyses were carried out with a NETZSCH STA 449 F1 Jupiter® TGA-DSC at a heating rate of 10 °C/min under helium atmosphere with 20 mL/min flow rate. The examined temperature range was 30 – 750°C. The as-synthesized sample (**1**) was exposed to air for 1 day before testing. The solvent-exchanged sample (**1'**) was exposed to air for less than 6 hours before testing, while the activated sample (**1''**) was exposed to air for less than 30 min.

3. Powder X-Ray Thermodiffraction

Powder X-ray thermodiffraction experiments were carried out at an X'Pert Pro work station equipped with high-speed RTMS detector and TTK-450 temperature/environment control chamber provided by PANalytical Company over a temperature range of 25 – 350°C. While heating, each scan was performed every 20°C until 200°C, and then scanning was intensified to every 10°C until reaching the maximum temperature of 350°C. After the temperature was maintained at 350°C for 30 minutes, scanning commenced for decreasing temperature and was recorded every 50°C until arriving at room temperature.

4. **Single-crystal X-ray crystallography:** Single-crystal XRD data of compound **1** was collected on a Rigaku Mercury CCD area-detector single crystal diffraction system with CuK α radiation (λ = 1.54178 Å). The structure was solved by the Direct Method of SHELXS-97 and refined by full-matrix least-squares techniques using the SHELXL-97 program. Non-hydrogen atoms were refined with anisotropic temperature parameters.

Compound	1
Chemical Formula	C ₃₆ H ₃₈ N ₃ O ₁₀ La
Formula weight	811.61
Crystal system	hexagonal
Space group	P6 ₃ 22
<i>a</i> (Å)	16.5428(4)
<i>b</i> (Å)	16.5428(4)
<i>c</i> (Å)	24.3988(15)
α (°)	90.00
β (°)	90.00
γ (°)	120.00
<i>V</i> (Å ³)	5782.5(4)
<i>D_c</i> (g/cm ³)	1.017
Abso. coef. (mm ⁻¹)	8.806
<i>Z</i>	6
<i>T</i> (K)	296(2)
Wavelength (Å)	1.54178
<i>F</i> (000)	1740
Goodness-of-fit on <i>F</i> ²	1.080
<i>R</i> ₁ indices [<i>I</i> > 2.0 σ (<i>I</i>)]	0.0550
<i>wR</i> ₂ indices [<i>I</i> > 2.0 σ (<i>I</i>)]	0.1508
<i>R</i> ₁ indices (all data)	0.0565
<i>wR</i> ₂ indices (all data)	0.1522

$$R_1 = \sum |F_o| - |F_c| / \sum |F_o| \quad wR_2 = [\sum w(F_o^2 - F_c^2)^2 / \sum w(F_o^2)^2]^{1/2}$$





Figure S1. Coordination Environment of La atom



Scheme S1. Connecting mode of BTB ligand




Figure S2. Inorganic helical chain composed of La and O




Figure S3. 3D framework in compound **1** along *c* axis

6. Elemental analysis and FTIR pattern: Elemental analyses were carried out on an Elementar Vario EL III analyzer. Infrared (IR) spectrum was recorded with PerkinElmer Spectrum One as KBr pellets in the range 4000-400 cm^{-1} . Anal.Calcd for $\text{C}_{36}\text{H}_{38}\text{N}_3\text{O}_{10}\text{La}$: C, 53.28; H, 4.72; N, 5.18. Found: C, 53.26; H, 4.74; N, 5.19. IR(KBr pellet/ cm^{-1}): 3431(s), 1663(vs), 1582(vs), 1526(s), 1254(m), 1095(m), 1016(m), 859(s), 784(vs), 706(m), 670(m), 553(w).




Figure S6. FTIR Spectrum of Compound **1**.